DOGUMENT RESUME

ED 212 798

CE 031 192

TITLE

Aircraft Environmental System Mechanic, 2-9. Block IV--Utility Systems and Flight Line Maintenance. Military Curriculum Materials for Vocational and Technical Education.

INSTITUTION

Chanute AFB Technical Training Center, Ill.; Ohio State Univ., Columbus. National Center for Research

in Vocational Education.

SPONS AGENCY

Office of Vocational and Adult Education (ED),

Washington, D.C.

PUB DATE.

[82],

509p.; For related documents see CE 031 189-191.

EDRS PRICE DESCRIPTORS

MF02/PC21 Plus Postage.

*Aviation Mechanics; *Ayiation Technology; Aviation Vocabulary; High Schools; Learning Activities; Learning Modules; Leason Plans; Postsecondary Education: Programed Instruction: *Programed*

Education; Programed Instruction; *Programed Instructional Materials; Teaching Methods; *Technical

Education; Vocational Education; Workbooks

, identifiers

*Aircraft Environmental Systems; Military Curriculum

Project

ABSTRACT

This publication contains a teaching guide and student instructional materials for conducting a high school or adult vocational education course to train persons to perform duties as an aircraft environmental systems mechanic. The instructional design for this course is self-paced and/or small group-paced. Instructor materials contained in the course guide include lesson plans detailing training equipment needed, training methods, multiple instructor requirements, and instructional guidance. The student material includes a workbo: and programmed texts with review exercises. A bibliography and glossary of terms are provided to aid both teacher and students. The course includes information on organizational and field maintenance of aircraft pressurization, air conditioning, and air starter, systems, and life raft inflation equipment. The course is composed of four parts (see note). Block IV (contained in this document) is composed of nine lessons requiring 114.5 hours of instruction. Topics covered are the following: gaseous oxygen systems; liquid oxygen systems; liquid refrigeration systems and components; inspection maintenance of oxygen systems (liquid); cryotainer systems maintenance; liferaft inflation equipment; fire exlinguisher system maintenance; flight line mainténance and inspections; and removal and replacement of system components. (KC)

Reproductions supplied by EDRS are the best that can be made from the original document.

Military Curriculum Materials for Yocational and Technical Education

TREE IN - UTILITY SYSTEM MECHANIC, 2-9

HARRY LINE MAINTENANCE



THE MATRIMAL CENTER
FLOR RESEARCH IN VOCATIONAL EDUCATION
THE REPORT NO ADMITTANCE OF THE PROPERTY NOTAL COLUMN US, 0140 432K

reproduction quality.

NA. NONAL INSTITUTE OF EQUICATION

2

MILITARY CURRICULUM MATERIALS

The military-developed curriculum materials in this course package were selected by the National Center for Research in Vocational Education Military Curriculum Project for dissemination to the six regional Curriculum Coordination Centers and other instructional materials agencies. The purpose of disseminating these courses was to make curriculum materials developed by the military more accessible to vocational educators in the civilian setting.

The course materials were acquired, evaluated by project staff and practitioners in the field, and prepared for dissemination. Materials which were specific to the military were deleted, copyrighted materials were either omitted or approval for their use was obtained. These course packages contain curriculum resource materials which can be adapted to support vocational instruction and curriculum development.

The National Center Mission Statement

The National Center for Research in Vocational Education's mission is to increase the ability of diverse agencies, institutions, and organizations to solve educational problems relating to individual career planning, preparation, and progression. The National Center-fulfills its mission by:

- Generating kpgwledge through research
- Developing educational programs and products
- Evaluating individual program needs' and outcomes
- Installing educational programs and products
- Operating in formation systems and services
- Conducting leadership development and training programs


FOR FURTHER INFORMATION ABOUT Military Curriculum Materials
WRITE OR CALL

Program Information Office

The National Center for Research in Vocational.
Education
The Ohlo State University
1960 Kenny Road, Columbus, Ohlo 43210
Telephone: 614/486-3655 or Toll Free 800/
848-4815 within the continental U.S.
(except Ohio)



RESEARCH IN VOCATIONAL EDUCATION



Military Curriculum Materials Dissemination Is . . .

an activity to increase the accessibility of military-developed curriculum materials to yocational and technical educators.

This project, funded by the U.S. Office of Education, includes the identification and acquisition of curriculum materials in point form from the Coast Guard, Air Force, Army, Marine Corps and Navy.

Access to military curriculum materials is provided through a "Joint Memorandum of Understanding's between the U.S. Office of Education and the Department of Defense.

The acquired materials are reviewed by staff and subject matter specialists, and courses deemed applicable to vocational and technical education are selected for dissemination.

The National Center for Research in Vocational Education is the U.S. Office of Education's 'designated representative to acquire the materials and conduct the project activities.

Project Staff:

Wesley E. Budke, Ph.D., Director National Center Clearinghouse Shirley A. Chase, Ph.D. Project Director (

What Materials Are Available?

One hundred twenty courses on microfiche (thirteen in paper form) and descriptions of each have been provided to the vocational Curriculum Coordination Centers and other instructional materials agencies for dissemination.

Course materials include programmed instruction, curriculum outlines, instructor guides, student workbooks and technical manuals.

The 120 courses represent the following sixteen vocational subject areas:

Food Service Agriculture Aviation Health Building & `Heating & Air Conditioning _ Construction Trades Machine Shop Management & Clerical **O**ccupations Supervision Communications Meteorology & Drafting: Navigation Electronics Photography | Engine Mechanics **Public Service**

The number of courses and the subject areas represented will expand as additional materials with application to vocational and technical education are identified and selected for dissemination.

How Can These Materials Be Obtained?

Contact the Curriculum Coordination Center in your region for information on obtaining materials (e.g., availability and cost). The will respond to your request directly or refer you to an instructional materials agency closer to you.

CURRICULUM COORDINATION CENTERS

EAST CENTRAL, Rebecca S. Douglass Director 100 North First Street Springfield, IL 62777 217/782-0759 NGRTHWEST William Daniels Director Building 17 Airdustrial Park Olympia, WA 98504 206/753-0879

SOUTHEAST

MIDWEST
Robert Patton
Director
1515 West Sixth Ave.
Stillwater, OK 74704
405/377-2000

James F. Shill, Ph.D.
Director
Mississippi State University
Drawer DX
Mississippi State, MS 39762
601/325-2510

NORTHEAS?
Joseph F. Kelly, Ph.D.
Director
225 West State 5 reet,
Trenton, NJ 08625
609/292 6562

WESTERN
Lawrence.F. H. Zane, Ph.D.
Director
1776 University Ave.
Honolulu, HI 96822
808/948-7834



∵6

Developed by:

United States Air Force.

Development and Review Dates:

October 17, 1978

Occupational Area

Aviation

Target Audliendes:

Grades 11 - adult

Print-Pages

3122

Availability: ERIC

National Center Clearinghouse

Contents:	Type of Materials:	Lesson Plans:	Programmed Text:	Student	Handouts:	Text . Materials:	Audio-Visuals:	Instructional Design:	Performance A Objectives:	Tests:	Review Exercises:	Auditional Materials Required:	Type of Instruction:	Group Instruction:	Individualized:	-
Block I -	4							=					,—			
Fundamentals	•	٠,	٠	•					•	,	•	•	Ϊ,,	•	•	
Block II -						,	,			-						•
Air Conditioning Systems	•	′•	•	•	,	•	X		•		•			•	•	-
Block III -	·		,									4			٥	(
Aircraft Environmental Systems Units	-	•	٠ ،			•	·x		•		•	X_		0	•	
Block IV -		_	•						1,11	,	, .	\				
Utility Systems and Flight Line Maintenance.		•	•	•	• ,	•	X		•		:	x		• ,	•	_
•			¥,				,	r			,	,	٠,			•
•		,			,	·						`		·		
	,				,				·				1		_	
				,	•		7	,	-7-1	•			,			•
	·			1			٧.		:				•			_

X Materials are recommended but not provided.



THE NATIONAL CENTER
FOR RESEARCH IN VOCATIONAL EDUCATION



OSU

1960, Kenny Road Calumbus, Ohio 43215 (614) 486-3655

Course Description

The instructional design for this course is self-paced and/or small group paced. This course trains personnel to perform duties as an Aircraft Environmental Systems Mechanic.

It includes organizational and field maintenance of aircraft pressurization, air conditioning, and air starter systems, and life raft inflation equipment.

- Block I Fundamentals contains 24 lessons requiring 1/5 hours of instruction.

 These are: safety; aircraft familiarization; physics; electron theory;
 magnetism; DC generation and basic circuit symbols and terms; wiring
 diagram fundamentals; control and protective devices; multimeter; Kirchoff's
 current law; Kirchoff's voltage law; Ohm's law; series circuits; parallel
 circuits; series-parallel circuits; switching circuits; DC motors and
 control circuit; temperature control circuits; alternating current;
 capacitance; inductance; AC motors and control circuits; solid state
 devices; magnetic amplifiers; and trainer aircraft air conditioning system.
- Afr Conditioning Systems consists of 8 lessons convering h24 hours of instruction. These are: fighter cabin air conditioning system; rain removal system; equipment air conditioning system; temperature control system tester; bomber air conditioning system; decade resistor functions and windshield amplifier bench check; cargo bleed air and anti-icing system; and cargo air conditioning system.
- Block III Aircraft Environmental Systems Units contains 13 lessons covering 102
 hours of instruction. These are the following: tools, hardware, safetying devices, and wire repair; maintenance of moisture separators; maintenance of bleed air distribution ducting; air turbine motor maintenance; turbine refrigeration devices; advanced fighter/bomber air source control system; advanced fighter/bomber air conditioning system; advanced fighter/bomber windshield clearing system; maintenance of air control units; anti-Guit system; canopy seal system; pressurization systems; and cabin pressure leakage check.
- Block IV Utility Systems and Flight Line Maintenance consists of 9 lessons requiring 114.5 hours of instruction. These lessons are entitled: gaseous 02 systems; liquid 02 systems; liquid refrigeration systems and components; inspection maintenance of 02 systems (liquid); cryotainer systems maintenance; liferaft inflation equipment, fire extinguisher system maintenance; flight line maintenance; removal and replacement of system components.

This course contains both teacher and student materials. Printed instructor materials include plans of instruction detailing training equipment needed, training methods, multiple instructor requirements and instructional guidance. The student material includes workbook, and programmed texts with review exercises. A bibliography and glossary of terms have been provided to aid both the instructor and the student. In Blocks I and III, lessons on Orientation, Security, Progression in Career Freld, Maintenance Management, and the Technical Order Publications Systems have been deleted because of military specific materials.

Technical Training

Aircraft Environmental Systems Rechanic

PRINCIPLES OF GASEOUS OXYGEN AND SAFETY

12 January 1979



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE
DO NOT USE ON THE JOB

instructional system. The materials contained herein have been validated using students enrolled in the 3ABR42331 course. Ninety percent of the students taking this text have either achieved or surpassed the criteria called for in the lesson objective. The average student required 1.5 hours to complete this text.

OBJECTIVES:

To help you understand the operation of the components and the necessity of the oxygen system, this programmed text covers the physic-logical effects of an oxygen deficiency. In addition, safety in handling oxygen equipment is also covered. You will be required to accomplish the following objectives.

1. Select without error, safety precautions pertaining to the use and handling of gaseous oxygen.

Instructions

This programmed text presents material in small steps called "frames." After each frame you will find a number of statements and you are asked to select the statement/s that are true. Read the material in each frame before making a selection. The answers to each frame can be found at the top of the next page. If you select the correct answers, continue to the next frame. If you are wrong or in doubt, fead the material again and correct yourself before continuing.

Supersedes 3ABR42331-PT-401, 25 August 1977.


OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/TTGU-P - 600; TTVSA - 1



11

As the earth turns on its axis and goes in a path around the sun, it is forever accompanied by a gaseous sea of air called "atmosphere." Min lives at the bottom of this sea. Raise him a few miles from the bottom and he suffers from internal pressures, becomes unconscious or dies. Man can live many days with no food, a few days with no water, bu. only a few minutes with no air. The atmosphere, a mixture of gases, is made up of 21% oxygen, 78% nitrogen, and 1% other gases. The percentage of this composition of air does not change with altitude, however, its density decreases fast with altitude. The air gets "thin" because less pressure is applied as altitude increases.



Canopy of Atmosphere.

Check the following statement/s that are true.

1.	Without air, a man can live only a few minutes.
2.	Twenty-one percent of the atmos: oxygen.
3.	As altitude increases, pressure increases.
4.	The same composition of air is present at any altitude.
	Air gets thin at higher altitudes because less pressure is applie to it.

Frame/2

Since man can not live in the "thin" air at high altitude, the aircraft cabin is pressurized to as near sea level as it can be. This lets man go a little higher but not high enough. Changes in pressure have an important effect on humans, and at higher altitudes a loss of pressure can cause the "bends." Oxygen equipment must be used to stop this from happening. Also think of what would happen if pressurization was logt. We know that oxygen is required at higher altitudes in order to live. The type of oxygen aviators need must be free of the other elements found in the air we breathe on earth, such as dust, moisture, etc.



Complete the following statements by filling in the proper word.

- At high altitudes a sudden drop in cabin pressure can cause ______.
 If cabin pressurization was lost at high altitudes the flight crew would need ______ to survive.
- 3. Temperature and _____ constantly change during flight.

Frame 3

Oxygen is one of the most abundant substances in the world. As previously stated, 21% of the air we breathe is oxygen. In its free state, oxygen is a gas with no odor, color, or taste but is very active chemically and will combine with nearly all other elements. Atoms of free oxygen usually combine in twos to form molecules, with the chemical symbol 02. Oxygen is not combustible but will readily support combustion.

Gaseous oxygen can be changed to a liquid by a process of compression and expansion.

Check the following statement/s that are true.


1.	Twenty-one percent of the atmosphere is oxygen.
2.	The chemical symbol for gaseous oxygen molecule is 02.
3.	One oxygen atom usually makes an oxygen molecule.
4.	Oxygen is a gas that is odorless, colorless, and tasteless.
5.	Oxygen will not support combustion.
6.	Gaseous oxygen can be turned into a liquid.

Answers to Frame 3:

• •

Frame 4

When too much of a loss of oxygen occurs in the human body and the body tissue is permanently damaged, a person is said to be suffering from anoxia. Anoxia is the absence of oxygen in the right quantity. This condition could be caused by an oxygen system that failed or some other gas that took the place of the oxygen in a closed in area. With no oxygen, the ruman body stops its work in a few seconds. As an environmental systems mechanic it will be your job to make sure that the oxygen system is doing its job right. See the sketch for the basic rules in using oxygen.



AT NIGHT USE OXYGEN FROM THE GROUND UP

Refer to the illustration above to complete the following statements.

- 1. Without oxygen, unconsciousness and death will occur at feet.
- 2. Without oxygen, day time efficiency is not affected but night vision is subnormal at _____ feet.
- A pressure-demand oxygen system is needed to operate at full efficiency at _____ feet.

Frame 5

We determined that anoxia was permanent damage as a result of inadequate oxygenation of the blood. Hypoxia is not enough oxygen in the blood stream. To work normally, the body needs a well balanced supply of oxygen all of the time. Hypoxia has various effects on the human body at different altitudes (see chart). Hypoxia is dangerous because it creeps up on a person without his knowing it. If a pilot does not know the signs of hypoxia, he will either crash the aircraft or die from being starved for oxygen.

symptoms of HYPOXIA!

25 to 43 THOUSAND FEET	15 to 45 SEC'S.	IMMEDIATE . UNCONSCIOUSNESS! (with little or no warning!)
20 to 25 THOUSAND FEET	5 MIN'S.	SAME SYMPTOMS AS "15 to 16" DNLY MORE PRONOUNCED WITH EVENTUAL UNCONSCIOUSNESS
15 to 18 CMACOHT FEET	½ HOUR	IMPAIRMENT OF JUDGMENT * AND VISION, HIGH SELF CONFIDENCE DISREGARD FOR SENSORY PENCEPTIONS, POOR COORDINATION, SLEEPINESS, DIZZ:NESS, PIRS ONALITY CHANGES—AS IN A MILD DRUNK-CYANOSIS (BLUING)
10 to 1.4 THOUSA: 10 FEET	HOURS	HEADACHE, FATIGUE, LISTLESSNESS *



Check	the	following	statement/s	that	are	true.
CHECK	CILE	TOTTOMITTE	acacement/s	CHAC	are	CIUE.

- 1. Hypoxia is a deficiency of oxygen in the blood.
- 2. The symptoms of hypoxia cannot be recognized.
- ____3. At 35 to 40,000 feet, unconsciousness occurs with little or no warning.
 - ____4. The body requires a balanced supply of oxygen.

Frame 6


With anoxia and hypoxia we found the body to be with no oxygen or a deficiency in oxygen. Going in the opposite direction, we find that hyperventilation is breathing too much which produces too much oxygen in the body leading to an abnormal loss of carbon dioxide, from the blood. The extreme signs of hyperventilation are muscular contractions and complete loss of body control. A person's body gets stiff and he will "freeze." An example of hyperventilation would be a man who is running a foot race. When he stops he will feel dizzy, be breathing deeply and his body will be partially out of control. A pilot may experience hyperventilation from getting excited in an emergency or from an attack by enemy aircraft. It is possible that he will "freeze" at the controls and crash. As a rule, hyperventilation is not serious and will pass in a few minutes.

Check the following statement/s that are true.

1.*	Hyperventilation is overbreathing.
·2.	Hyperventilation will kill in seconds like anoxia.
<u> </u>	It's possible for a pilot to "freeze" at the controls from hyperventilation.
4.	Normally, hyperventilation is not serious and will pass.
5.	Hyperventilation is the opposite of anoxia.

Frame 7

Aviators' breathing oxygen is made through a process called "distillation," where moisture and other impurities are taken but of the air as it is wormed and cooled. Moisture is especially harmful to oxygen systems because it will freeze at 32 degrees F and all valves and regulators are then useless. Aviators' oxygen is refined until it is 99.5% moisture free. Do not substitute this with any other oxygen. Oxygen made for hospital use is only 98% moisture free and welding oxygen is about 70% moisture free.



Testing Oxygen in Cylinder to Assure 99.5% Purity.

Complete the following statements by filling in the proper word.

- 1. Aviators' oxygen is _____ % moisture free.
- 2. Moisture will, at 32°F, _____ in the oxygen system components.
- 3. Aviators' oxygen is produced through a process called
- 4. Hospital oxygen is only _____ % moisture free.

Answers to Frame 7: 1. 99.5 2. freeze 3. distillation 4. 98


Frame 8

In the preceding frames we covered the physiological effects of oxygen deficiency. Let's review this information now. Circle the letter of the answer that is correct for each of the following statements.

- 1. Man can live only a few minutes with no
 - a. air.
 - b. food.
 - c. water.
- 2. The atmosphere is
 - a. 78% oxygen.
 - b. 78% other gases.
 - c. 28% oxygen.
 - d. 28% other gases.
- 3. At high altitudes a sudden drop in pressure can cause
 - a. anoxia.
 - b. hypoxia.
 - c. bends.
- 4. At 10,000 feet night vision is subnormal without
 - a. nitrogen.
 - b. oxygen.
- 5. A deficiency of oxygen in the blood is called
 - a. anoxia.
 - b. hypoxia.
 - c: hyperventilation.

Frame 9

Gaseous oxygen is stored under high pressure in cylinders made of steel with no seams. They measure 8 1/2 inches by 51 inches. To determine the difference in aviators breathing oxygen from other gases, the cylinders are painted a dark green color with a 3 inch band of white near the valve end. To further identify these cylinders the words "AVIATORS BREATHING OXYGEN" are stenciled on the cylinder in block letters. All of these methods of identification are for one purpose: to make sure that no other gas is put in an oxygen system.



Check the following statement/s/that are true.

- _____1. To distinguish aviators' oxygen from other gases, the cylinders are painted green.
- 2. Gaseous oxygen is stored under high pressure.
- 3. A 3-inch white band is painted around the bottom of each cylinder.

Frame 9 (Continued)

4. The words AVIATORS BREATHING ONYGEN is stenciled on each cylinder.


5. All cylinder identification is to make sure that no other gas is put in an oxygen system.

6. Gaseous oxygen cylinders are made of seamless steel.

Answers to Frame 9: ___/ 1. __/ 2.

Frame 10

As said before, the gaseous oxygen cylinder is made of steel with no seams. The control valve on the cylinder is hand wheel operated and the outlets are set at 90 degree angles to the cylinders (see below). This is to stop the rocket action of the cylinder if the valve should be opened accidentally or if the rupture disc (safety disc) blows out. The rupture disc is a thin piece of gold plated steel which will not corrode and become weak. The disc is designed to blow out if thermal expansion raises the cylinder pressure above 2200 psi. The valve outlet threads are designed so that other gas cylinders cannot be connected to oxygen recharging equipment. The type of gas (oxygen) the valve was designed for is stamped on the side of the valve. A metal cap is screwed on over the valve during handling or shipment to protect it (see cap in frame 2). Never use oil origresse on oxygen valves or fittings.



7644 Frame 10, (Continued)

Select, by placing a checkmark in the blank, those items are pafety factors.

- 1. To prevent rocketing, the valve outlets are at 90° angles to the cylinder.
- 2. The oxygen valve contains a gold plated rupture disc.
- Other gas cylinders can be connected to oxygen recharging equipment.
- 4. The rupture disc is designed to take care of thermal expansion in the cylinder.



Frame 11

The Interstate Commerce Commission (ICC) requires that all high pressure compressed gas cylinders be given a hydrostatic test once in every five years (quinquennially). The test pressure used must be 5/3 times the working pressure of the cylinder. Maximum service pressure for oxygen storage cylinders is 2015 psi; therefore the cylinders are subjected to a total pressure of 3400 psi. This test is made up of water being forced under high pressure in the cylinders to stretch it slightly. The cylinder being tested is put in water and the water displaced by the expansion is marked. When the pressure is let out the water level should go back to the starting point. If it does not, the cylinder has stretched permanently and must be rejected. The test date is stamped on the neck of the cylinder (see frame 9).

Check the following statement/s that are true.

- 1. A hydrostatic test is performed on all high pressure compressed gas cylinders quinquennially.
- 2. During the hydrostatic test the water level of the water tank should go back to the starting level when the pressure in the gas cylinder is released.
- The hydrostatic test pressure used in a compressed gas cylinder must be 5/3 times the working pressure of the cylinder.

Answers to Frame 11: $\sqrt{1}$. $\sqrt{2}$. $\sqrt{3}$

Frame 12

While you are in the Air Force, you will be going to a number of safety briefings, lectures, and movies to point out the hazards and safety precautions you should take while working on the flight line. The Air Force spends a lot of man-hours each month to make you "think" safety. In your job, you will be working with oxygen which requires that you use safety each and every day, on all jobs. In the following frames safety precautions peculiar to gaseous oxygen will be covered. You will be required to know these safety precautions so you can select them from a list of safety precautions without any error. You must be able to apply them without looking them up.




NO RESPONSE REQUIRED

One of the most important safety rules that you should know about oxygen is that it makes other materials burn very fast. In other words, it supports combustion. This characteristic, in addition to the fact that oxygen is handled under pressure in excess or 2000 psi, gives just cause for strict adherence to all safety rules. This

text will go over some of the basic rules. ,

The area where oxygen cylinders are stored should be well ventilated to prevent a harmful accumulation or explosive concentration of gas.



This is Not a Bomb Explosion.

Check the following statement/s that are true.

- _____1. Oxygen makes other materials burn rapidly.
- _____2. High pressure gas of any kind is a hazard.
- 3. Oxygen should not be allowed to accumulate in a confined
- 4. Oxygen itself does not burn but supports combustion.



Frame 14

when storing oxygen cylinders, they should be protected from extreme temperatures. They should at no time be stored closer than 50 feet to highly flammable materials. Oxygen cylinders should also be kept from all other gases in storage. Explosions and fires have been the result of mistaking oxygen for other gases that are used for fuel cell purging, putting air in tires, etc. So remember, never mix oxygen with petroleum base products; "you may not be here to tell about it."



Check the safety precautions.

- 1. Tygen cylinders should be protected from high temperatures.
 - -2. O vgen and petroleum base products must not be mixed.
- _____3. Oxygen and other gases should be separated during storage.
 - 4. Oxygen should be stored at least 50 feet from flammable materials.
- 5. Oxygen can be mistaken for other gases.

Answers to Frame 14:

1. <u>* 2. / 3. / 4.</u>

Frame 15

Oxygen cylinders should be handled with care. If the cylinder control valve is accidentally broken off, the cylinder will become a "rocket." Damaged cylinders are also subject to explosion. Do not open the control valve with the outlet pointing at you or anyone else because the high pressure gas will cut your skin or destroy your eyesight. It is also possible to rupture the internal organs of your body if oxygen is directed into the mouth or ears. The hand wheel on the valve should be operated by hand only.



Check the safety precautions.

- 1. All oxygen cylinders should be handled with care.
- 2. When opening the cylinder control valve, it should be pointed away from you.

2647
Answers to Frame 15: $\sqrt{1}$. $\sqrt{2}$.

Frame 16

When working near oxygen, all tools, clothes, and equipment must be kept free of grease and oil. Spontaneous combustion may take place when oil and oxygen mix. More dangerous than spontaneous combustion is the use of oxygen near a fire or equipment that will make a spark. Smoking near an oxygen area is a sure way to get blown up. Do not smoke right after being in an oxygen area or after servicing an aircraft because your clothes may have some oxygen trapped in them. Allow a few minutes for your clothes to air out.



Check the safety precautions.

- 1. Smoking in an oxygen area is a dangerous practice.
- 2. When working around ox, gen, clothes, tools, and equipment must be free of oil and grease.

Frame 17 😅

Let's roview some of the safety precautions that were covered in the past three frames. If you did not answer this frame correctly go back and reread the past three frames. In safety there is no room for error.

Cnec	k tue Baseods oxiden sateth biecancions.
1.	Oxygen cylinders should be handled with care.
	Wear the correct protective clothing (face shield, neoprene apron, non-absorbent gloves) when handling the oxygen cylinders.
<u> </u>	Oxygen cylinders should be protected against high temperatures
4.	Do not smoke where oxygen is being used.
5.	Select the proper tool for the job.
6.	Do not mix oxygen with petroleum base products.
7.	Oxygen should be stored at least 50 feet from flammable materials.
8.	The control valve of an oxygen cylinder should be pointed away from you when it is opened.
	many and arctartion must be even then carrieing the sirciaft

Answers	to	Frame	17:	 2.	<u>/_</u> ,3.	/ . 4.	5.	. √ 6
Frame 1		•	,	 <u>√</u> 8.	9.	ı		

Before servicing an aircraft with oxygen, it should be "grounded." Aircraft build up static electricity during flight and could cause a spark when touched with the oxygen equipment. A proper ground wire will eliminate this. No power should be on the aircraft during servicing and the external power unit should be moved out of the area.




Check the oxygen safety precautions.

- _____1. The sircraft should be grounded before it is serviced with oxygen.
- _____2. When servicing the aircraft with gaseous oxygen, wear profective clothing.
- _____3. No power should be on the aircraft during servicing.

Answers to Frame 18: √ 1.

Frame 19

As previously stated, oxygen is stored in cylinders under high pressure. Most gaseous oxygen systems are low pressure systems (450 PSI). In this case, a pressure reducer will have to be used (see illustration). This will prevent the high pressure from exploding the aircraft cylinders. The pressure reducer is part of the low pressure servicing cart and should always be used.



REDUCER HANDLE

I-RESSURE

Check the oxygen safety precautions.

- ____1. A pressure reducer is required when servicing a low pressure oxygen system.
- 2. Low pressure gaseous oxygen pressure is 650 psi.

Oxygen is a harmless gas if handled correctly. Do not take any short cuts that eliminate a safety rule just to get the job done. You should respect a dangerous item because you recognize its ability to destroy, and not just because romebody said it was dangerous. Remember, with oxygen the safe way is the best way.

Now check your understanding of the safety precautions involved with gaseous oxygen. Remember if you miss cay of these items you should go back to frame 13, restudy each frame, then check yourself again. In safety there is no room for error.

Check the oxygen safety precautions. Do not smoke where oxygen is being used. Oxygen cylinders should be protected against high temperature. 2. 3. Oxygen cylinders should be handled with care. Trichloroethylene should be used outdoors or in a well ventilated building. Combustible trash must be placed in closed metal containers. Do not mix oxygen with petroleum base p oducts. 6. 7. The safe distance behind an operating jet engine is 200 feet. 8. . Oxygen cylinders should be stored at least 50 feet from flammable materials. 9. The aircraft should be grounded before it is serviced with oxygen. The control valve of an oxygen cylinder should always be 10. pointed away from you when it is opened. Ear protectors should be worn whenever the aircraft is 11. serviced with gaseous oxygen. No power should be on the aircraft while servicing with 12. gaseous oxygen. Protective clothing (face shield, rubber apron, non-absorbent 13. gloves) must be worn when servicing the aircraft with gaseous oxygen. A pressure reducer must be used when servicing a low pressure 14. oxygen system.

Ma 25 feet.

The safe distance in front of an operating jet engine intake

<u>√</u> 6. ____7. <u>√</u> 8. <u>√</u> 9. <u>√</u> 10.



3ABR42331-PT-401A

Technical Training

Aircraft Environmental Systems Mechanic

b LOW AND HIGH-PRESSURE GASEOUS OXYGEN SYSTEMS

10 February 1976



USAF SCHOOL OF APPLIED AEROSPACE SCIENCES 3370th Technical Training Group Chanute Air Force Base, Illinois

- Designed For ATC Course Use

DO NOT USE ON THE 208

FOREWORD

This programmed text was prepared for use in the 3ABR42231 Instructional System. The material contained herein has been validated using 36 42010 students emrolled in the 3ABR42231 course. Ninety percent of the students taking this text surpassed the criteria called for in the approved lesson objective. The average student required 45 minutes to complete the text.

OBJECTIVES

After completing this programmed text, you will be able to:

- 1. Explain the principles of operation of low-pressure oxygen systems.
- 2. Describe pressure and flow indicators used in low-pressure oxygen systems.
- 3. Explain the principles of operation of high-pressure oxygen systems.
- 4. Describe pressure and flow indicators used in high-pressure oxygen systems.

INSTRUCTIONS

This programmed text presents material in small steps called "frames." After each step you are asked to select the correct statement or match some statements. Read the material presented and make your response as directed in the frame. The correct answer to each frame can be found on the top of the next page. If your answer is correct proceed to the next frame; if you are wrong or in doubt, read the material again and correct yourself before continuing.

Supersedes 3ABR42231-PT-401A, 18 September 1972.


OPR: TAS

DISTRIBUTION: X

TAS - 150; TTVGC - 1



Many types of oxygen systems are used on aircraft. A system consists of two sections: the supply or storage section with its connecting plumbing, and the distribution section which includes the regulators. The type of system used in a given aircraft is determined by the type of regulator that is used. Oxygen regulators are grouped into three types: demand, pressure demand, and continuous flow. Any of the three types of regulators can be used with any type of supply system. The types of supply systems are low and high pressure gaseous oxygen, and low and high pressure liquid oxygen.




Check the following statement/s that are true.

- 1. The type of oxygen system is determined by the regulator used.
- 2. Any of the three types of regulators can be used with any of the supply systems.
- 3. Normally there are five sections in an oxygen system.
- 4. The three types of regulators are demand, pressure demand, and continuous flow.

2656
Answers to Frame 1: 1. 2. 3. 4

F. ... 2

The low pressure gaseous oxygen system is used on the old type transport and cargo aircraft. The cylinders are mounted with straps in sections of the aircraft where space is available. They carry a maximum charge of 450 psi and are considered to be full between 400 and 450 psi.* The pressure should not be allowed to drop below 50 psi. This is to prevent contamination of the cylinder due to mossture that will accumulate in the cylinder. Low pressure cylinders are made shatterproof by welding metal bands to the outer side. The cylinders are made of stainless steel or a low alloy steel and are painted yellow to identify them as low pressure.



Typical Low-Pressure Cylinders (Painted Yellow)

Check the following statement/s that are true.

1.	All low pressure cylinders are painted yellow.
2.	Maximum service pressure for low pressure cylinders is 450
	psi.
3.	At least 50 psi should always be left in the cylinders.
4.	Low pressure cylinders are not shatterproof.
5.	Low pressure cylinders are considered full at 400 psi.

38


۱ د

Answers to Frame 2: $\sqrt{1}$, $\sqrt{2}$, $\sqrt{3}$, $\sqrt{4}$, $\sqrt{5}$.

Frame 3.

Low pressure systems use 5/16-inch aluminum tubing. The tubing used in all oxygen systems has the size numbered in 1/16-inch increments. A number 5 tubing Was an outer diameter of 5/16-inch, a number 3 would be 3/16-inch, etc. All tubing carrying oxygen is color coded with green tape to distinguish it from other tubing in the aircraft. During manufacture the tubing used is heat treated for strength and treated also to prevent corrosion. Two kinds of connections are used in oxygen systems: flared tube connections, and pipe thread connections.

The fittings used in low pressure systems are made of aluminum alloy and painted blue to identify the material. These are "AN" standard (Army-Navy) fittings. The pipe thread end of the fitting screws into cylinders, regulators, and gages. The coneseat end connects the flared tubing.



Double Flared Connection


AN Standard Fitting (Painted Blue)

- 1. If you asked for a piece of rumber 5 tubing, you would get 5/16.
- 2. Low pressure systems use number 5 aluminum tubing.
- 3. The flared tubing is connected to the pipe thread fitting.
- 4. All tubing carrying oxygen is color coded green.

Answers to Frame 3: √ 1. √ 2. √ 3. √ 4

Frame 4


The tubing is braced with clamps every 15 inches apart and at each bend all through the aircraft. This helps to reduce tubing vibration and also helps to prevent chafing of the tubing. Oxygen cubing should be installed with at least a two-inch clearance between electrical wiring or any control cables. The tubing is bent when necessary to insure that this clearance is maintained. The tubing may run within 1/2-inch of electrical wiring so long as more insulation is used on the wires, but this is the absolute minimum.



- 1. Tubing should be clamped every 15 inches and at each bend.
- 2. A two-inch clearance should be maintained between tubing and electrical wires and control cables.
- 3. 1/2-inch is the absolute minimum clearance on oxygen tubing.

Clock valves are used in a gen systems that have more than one cylinder. A check valve helps to prevent a complete loss of oxygen if part of the system is damaged. Check valves may be in many styles to meet the need of the installation. An arrow on the side of the check valve shows the direction of free flow. If cylinder "A", in the illustration, ruptured, the oxygen in cylinder "B" would not go out through the hole because of check valve number 3. Check valves must be installed so that all cylinders can be filled from a single filler valve, all cylinders will feed the regulator, and if one cylinder ruptures, the other cylinders will not drain out through it.





FILLER VALVE

CHECK VALVE

FILLER TUBING

DISTRIBUTION TUBING

STATION OUTLET

- 1. The arrow on a check valve indicates direction of free flow.


 2. Check valves are not required if more than one cylinder is used.
- 3, Check valves are installed so that all cylinders can be filled from one valve.

3660Answers to Fram 5: 1. 2. 3

Frame 6

Filler valves are used when filling the oxygen system. They are usually mounted near the outer surface of the aircraft in a recessed well and under an access cover. Each filler valve has a dust plug attached to the valve by a chain. The plug can be removed by turning the handle. When the dust plug is removed, a recharge adapter on the servicing home is put in the filler valve to fill the system. The filler valve is nothing more than a spring loaded check valve that is unseated by the recharge adapter and seals when the adapter is removed.






- 1. A filler valve is a spring loaded check valve.
- 2. The recharge adapter unseats the filler valve.
- _____3. The filler valve is located on the outer surface of the aircraft.
- 4. A wrench is required to connect the recharge adapter.

Frame 7.

A separate gage may be used in some low pressure oxygen systems to show cylinder or system pressure. This will depend on the type of regulator that is used. Some regulators have a pressure gage build in them. One of the indicators used is the K-1 bourdon tube-operated type. The bourdon tube is hollow and in the shape of a "C." Pressure put on the inside of the tube will try to straighten it out. The pointer is linked through levers to the bourdon tube. The dial face is marked off in 50 psi graduations and the 0-100 psi range is lined out to attract attention to these pressure readings. Most gages have a red mark on the glass cover at 450 psi to point out the maximum service pressure. The gage is found in the cockpit in a readily visible location.



K-1 Pressure Gage





- ____1. The K-1 pressure gage is bourdon tube-operated.
- 2. Some regulators have a pressure gage built in.
- 3. The K-1 pressure gage is electrically operated.
- 4. The pointer is connected through levers to the bourdon tube.
- 5. Pressure in the hollow bourdon tube tends to straighten it out and deflects the needle.

1667 Answers to Frame 7: \ \ 1. \ \ 2. \ 3. \ \ 4. \ \ 5

Trame 8

A separate flow indicator is used in some low pressure oxygen systems to show that oxygen is flowing through the regulator. Some regulators have a flow indicator built in them. The A-3 flow indicator is the type used as a separate flow indicator. The A-3 indicates by a blinking action when the user inhales through the oxygen mask. The blinker "sye" is actuated by a disphragm in the unit. The flow indicator does not show how much oxygen is flowing or that the us r is getting enough oxygen, it just talls the user that he is receiving a flow.




A-3 Flow Indicator

- 1. The A-3 indicates oxygen flow through the regulator.
- 2. "Blinker" is the correct name for the A-3.
- 3. The hinker eye operates from a disphragm.
- ____4. Some regulators have a built in flow, indicator.
- 5. The A-3 does not indicate the amount of oxygen flowing.

Frame 9

Shown is a low pressure oxygen system with all the units that have been covered in the text. This system uses the D-2 shatterproof cylinder, various style check valves, number 5 aluminum tubing, low pressure filler valve, flow indicator, and pressure gage. The size and amount of cylinders used depends upon the need of the particular aircraft that the system is used on.



2664 Answer to Frame 9: None Required.

Frame 10

The high pressure oxygen system has the same principle of operation as the low pressure system. Its one advantage is that more oxygen can be stored in a smaller space; however, the oxygen is stored at a high pressure (1,800 psi). The same maintenance procedures and safety rules apply to both the high and low pressure oxygen systems. Care must be taken when opening lines in a high pressure system. Make sure they have been drained to prevent possible Lody damage from the high pressure. High pressure gaseous oxygen systems are not widely used, but they will be your responsibility.

Check the following statement/s that are true.

1. More oxygen can be stored in a smaller space using a high pressure system.

2. High pressure oxygen is particularly dangerous.

3. High pressure oxygen systems are widely used.


4. In general, the same safety precautions apply to low and high pressure systems.

2

Answers to Frame 10: $\sqrt{1}$, $\sqrt{2}$, 3, $\sqrt{4}$

Frame 11


Find these listed units in the illustration shown: the high pressure filler valve, the pressure reducing valves, the system shutoff valves, the pressure gages, and the cylinder connection points. The check valves, which are not shown, are the next items in the plumbing. These items and the plumbing will be covered in this text.



Amswer to Frame 11: None Mequired.

Frame 12

Study this simplified diagram of the same system that was given in the last frame. Note the two separate systems. The two cylinders shown on the lift side of the system supply the oxygen to the regulators on that side. The left side has its own system shutoff valve pressure reducer valve, and cylinder pressure gage. The right side has two pressure reducing valves that are hooked in parallel. The cylinders for both sides are filled from a common filler valve.



Check the following statement/s that are true.

1.	In the schematic s	hown, there are	two separate hi	gh pres-
	sure systems.			1

2. All cylinders are filled from a common filler valve.


3. The components are completely different in each system.

4. The right hand side has two pressure reducing valves in parallel.

Answers to Frame 12: 1. 2. 3. 4.

Frame 13

The high pressure oxygen cylinders are made of forged seamless steel and are wire-wrapped to make them shatterproof. The service pressure for the cylinders is from 1,800 to 1,850 psi. These high pressure cylinders are painted green. An automatic valve is put, on the release end of the cylinder to let the cylinder be removed without discharging, for maintenance on the system. A fusible safety plug is in the automatic valve to dump pressure if the temperature gets between 208° and 220°F. A hydrostatic test is required on these high pressure cylinders every five years to determine their condition. The test date is stamped on the neck of the cylinder.



- 1. 1,850 pei would be the maximum service pressure.

 2. High pressure cylinders are wire-wrapped to make them shatterproof.

 3. All high pressure cylinders are painted green.


 4. The automatic valve allows the cylinder to be removed without discharging.

 5. A fusible plug is built into the automatic valve.

 6. The high pressure cylinders are made of aluminum.
 - _7. The furtble safety plug will melt at a temperature of 208° to 220°F.


Frant 14

The tubing used in high pressure waseous oxygen systems is either 3/16-inch or 5/16-inch stainless steel. Aluminum tubing will not stand the high pressure. The high pressure stainless steel tubing requires a flareless type fitting called Ermeto fitting. The fitting consists of a close which is present on the end of the tubing before the tubing is put in a flareless seat. If you overtighten an Ermeto fitting while trying to stop a leak, it usually will leak more. A torque wrench should always be used.



- 1. High pressure systems use stainless steel tubing.
- 2. Ermeto fittings are flareless fittings.
- 3. You can stop an Ermeto fitting from leaking by increasing the torque.
- 4. A torque wrench should always be used on an Ermeto fitting.

The high pressure filler valve is hand wheel operated and separates the filler connection from the cylinders. This valve must be open when the system is filled with oxygen and is closed at all other times. The filler connection is used to hook the rcharging equipment to the aircraft system. The type of filler valva connection shown in one illustration is flange mounted to the aircraft and in the other it is part of the valva. Because of the high pressure used quick disconnects are not used when the system is recharged. The system check valves serve the same purpose as in the low pressure oxygen system, but are made to stand higher pressures. Remember, check valves stop a reverse flow.




1·	The	filler	valve	18	opened	only	for	filling	the	system.

- 2. Quick disconnects are used when recharging high pressure systems.
- _____3. The filler valve separates the filler connection and cylinders.
- 4. The check valves are used to prevent reverse flow.

Answers to Frame 15: $\sqrt{1}$. 2. $\sqrt{3}$. $\sqrt{4}$.

Frame 16

A separate pressure reducing valve is used in high pressure caygen systems to drop the cylinder pressure from 1,800 psi to 300 to 400 psi before it goes in the regulator. This valve has a reflief section that vents the pressure overboard if the reducing section fails to work. This is a safety feature to stop the regulators from rupturing if the valve fails to work. The major parts are a metal diaphragm and a coil spring assembly.




- The pressure reducer drops the cylinder pressure from 1,800 psi to between 300 to 400 psi.
- If the pressure reducing valve malfunctions and the relief valve vents the pressure overboard, the regulator will rupture.
- The major parts of a pressure reducer valve are a metal diaphragm and a coil spring assembly.
- The pressure reducer valve contains a relief section.

Answers to Frame 16: $\sqrt{1}$. $\sqrt{3}$. $\sqrt{4}$.

Frame 17

The system shutoff valve used in the high pressure oxygen system is placed between the cylinders and the pressure reducing valve. This is a manual hand wheel operated valve that is normally safety-wired to the open position. In case of an emergency this valve can be closed to isolate the distribution system from the cylinders. It can also be used when maintenance is done on the system. The valve should always be left in the open position and safety-wired. The position that the shutoff valve is in (on or off) can be seen through a window in the top of the control knob.




1.	The	system	shutoff	valve	is	hend	wheel	operated.
----	-----	--------	---------	-------	----	------	-------	-----------


- _____2. The shutoff valve is always closed.
- _____3. The shutoff valve is located between the cylinders and pressure reducing valve.
- 4. The valve is normally in the open position and safety-wired.

Answers to Frame 17: $\sqrt{1}$. 2. $\sqrt{3}$. $\sqrt{4}$.

Frame 18

A pr ssure gage is used to show cylinder pressure. Some aircraf have two systems and both pressure gages are shown. Keep in mind that this is cylinder pressure and not reduced pressure. The gage is tapped into the syteem before the pressure reducing valve. The gage is bourdon tube operated and reads from 0 to 2,000 psi, with increments of 200 psi marked off on the dial. The regulator that is used on the C-130 aircraft has a flow indicator built in to let the user know that oxygen is flowing through the regulator. When the user takes a breath of oxygen, a "flag" attached to a disphragm shows through a glass window on the face of the regulator.





TANK PRESSURE GAGES


OXYGEN REGULATOR

1.	The	pressure	gage	indicates	cylinder	pressure.
					•	

- The diagram above shows two separate pressure gages.
- The flow indicator on the C-130 is part of the regulator. 3.
- 4. The flow indicator on the C-130 is the A-3.
- The pressure gage is bourdon tube-operated.

Frame 19

Match the letter shown at each component with the correct name of that component from the list below.



- Oxygen Filler Valve 6. 1. Oxygen Filler Connection 2. System Shutoff Valve Automatic Valve Assembly 7. ___3. Ox/gen Flow Indicator Cylinder Pressure Gage 8. Pressure Reducing Valve 4. Check Valves 9.
- 5. Stainless Steel Tubing 10. High Pressure Cylinders

2674

Answers to Frame 19: C 1. H 2. A 3. J 4. E 5
F 6. D 7. B 8. I 9. G 10.

²⁰ 56

69-0636

Technical Training

Aircraft Environmental Systems Mechanic

DEMAND OXYGEN EQUIPMENT

3 August 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

DO NOT USE ON THE JOB



This programmed text was prepared for use in the 3ABR42331 Instructional System. The material contained herein has been validated using thirty-one students enrolled in the 3ABR42331 course. Ninety percent of the students taking this text surpassed the criterion called for in the approved lesson objective. The average student required 50 minutes to complete the text.

OBJECTIVES

After completing this programmed text, you will be able to:

1. Relate four (4) of five (5) demand oxygen system components , with their purpose.

INSTRUCTIONS

This programmed text presents material in small steps called "frames."

After each frame you will find a number of statements and you are asked to select the statement/s that are true. Read the material in each frame before making a selection. The answers to each frame can be found at the top of the next page. If you select the correct answers, continue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before continuing.

Supersedes 3ABR42331-PT-313, 2 June 1970.


OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCGTG/TTGU-P - 600; TTVSA - 1



In the illustration below, D-2 low pressure gaseous oxygen cylinders are being used in the supply section of this system. Do we call this a gaseous oxygen system? No. Oxygen systems are usually referred to by the type of regulator installed in the distribution section of the system. The system shown has the A-12A diluter DEMAND regulator installed and we call this a DEMAND oxygen system. If the system below has a continuous flow regulator installed, it would be referred to as a continuous flow system, etc. Other components of the demand system are the A-14 demand mask, A-3 flow indicator, K-1 pressure gage, and the mask-to-regulator hose.


DEMAND OXYGEN SYSTEM



- 1. (Usually an oxygen system is referred to by the type of regulator installed.
- The A-12A regulator is the diluter demand type.
- 3. The A-12A regulator is used only with liquid oxygen systems.
- 4. The A-14 demand mask is used with the A-12A regulator.



The A-12A diluter demand regulator gets its name from the fact that it delivers oxygen to your lungs in response to the suction of your own breath, that is, on demand. To prolong the duration of the supply, the oxygen is automatically diluted (mixed) in the regulator with suitable amounts of air up to a certain altitude. The A-12A is one of the oldest oxygen regulators in use and we will discuss it first because the newer regulators are patterned after the A-12A; this will become apparent as we continue. For a better understanding of the A-12A, mentally match the list of components with the numbers in the arrowed circles.




- 1. Air Metering Port.
- 2. Diluter Control Cam.
- 3. Emergency Valve.
- 4. Demand Diaphragm.
- 5. Check Valve.

- 6. Pressure Reducing Valve.
- 7. Demand Valve.
- 8. Ameroid.
- 9. Oxygen Metering Port.
- 10. 2nd Stage Relief Valve.

Type A-12A Diluter Demand Oxygen Regulator (Aro).

- 1. The A-12A delivers oxygen on demand.
- 2. The A-12A delivers 100% oxygen at all times.
- 3. Air is mixed with the oxygen in the regulator up to a certain altitude.

As we have stated, the A-12A is a diluter demand regulator. This simply means that air and oxygen are mixed (diluted) and supplied to the user when he/she inhales (demands) oxygen. When the user inhales, he/she closes a valve in the mask and opens a valve in the regulator. When he/she exhales, this process is reversed. Starting where the oxygen enters the regulator from the supply section you find the pressure weducing g mechanism. The pressure reducing valve (6) is attached through levers to a rubber diaphragm. (See schematic.) As the pressure of the oxygen increases in this first stage chamber, it forces the diaphragm down and the attached lever closes the pressure reducing valve (6). 40 to 60 psi on the diaphragm closes the valve and it remains closed until the pressure d drops from the oxygen being used. Note the spring attached to the center of the diaphragm will also help pull it up which will open the valve.




- Air Metering Port.
- 2. Diluter Control Cam.
- 3. Emergency Valve.
- 4. Demand Diaphragm.
- Check Valve.

- 6. Pressure Reducing Valve.
- 7. Demand Valve.
- 8. Ameroid.
- 9. Oxygen Metering Port.
- 10: 2nd Stage Relief Valve. .

Type A-12A Diluter Demand Oxygen Regulator (Aro).

- 1. 40 to 60 psi closes the pressure reducing valve.
- 2. The user does not have to inhale to get oxygen from the A-12A.
- 3. First stage reducing is 40 to 60 psi.

We now have 40 to 60 psi in the first stage chamber. The only way for the oxygen to get out of here is up around the demand valve (7). (See schematic.) The demand valve (7) is controlled through levers attached to the demand disphragm (4). The demand disphragm is controlled in turn by the breathing of the user. Cabin pressure acts on the upper side of the demand disphragm (4). As the user inhales oxygen is drawn from the bottom side of the disphragm. This allows cabin pressure to force the disphragm down. The connecting levers then open the demand valve (7) and more oxygen is allowed in the upper or 2nd stage chamber. Once the 2nd stage chamber pressure equals the cabin pressure, oxygen pressure raises the disphragm enough to close the demand valve. The above sequence is the way 1st stage pressure is reduced for pilot use.




- 1. Air Metering Port.
- 2. Diluter Control Cam.
- 3. Emergency Valve.
- 4. Demand Diaphragm.
- 5. Check Valve.

- 6. Pressure Reducing Valve.
- 7. Demand Valve.
- 8. Aneroid.
- 9. Oxygen Metering Port.
- 10. 2nd Stage Relief Valve.

- 1. The demand valve is controlled by the demand diaphragm.
- 2. The demand diaphragm is controlled by the user.
- Oxygen enters the second stage chamber through the demand valve.
- 4. The demand diaphragm directly controls the pressure reducing valve.

When the user inhales (jemands oxygen) the oxygen leaves the 2nd stage chamber thorugh the oxygen metering port (9), and travels to the user in the mask-to-regulator hose. At the same time, cabin air is allowed to mix with (dilute) the oxygen. The air enters through the check valve (5); then a specified amount is metered through the air metering port (1). Note that the oxygen metering port and air metering port are attached to a common lever which moves up or down. The diluter control cam (2) has two positions which are selected by the diluter lever, (see illustration). With the diluter lever positioned to "normal oxygen," the ameroid (8) will control the movement of the common lever: And as cabin altitude increases, the ameroid will expand an gradually close off the air metering port. At 32,000 feet the air metering port will be completely closed and the user will get 100% oxygen automatically



- 1. Air Metering Port.
- 2 Diluter Control Cam.
- Emergency Valve.
- 4. Demand Diaphragm.
- 5. Check Valve.


- 6. Pressure Reducing Valve.
- 7. Demand Valve.
- 8. Ameroid.
- 9. Oxygen Metering Port.
- 10. 2nd Stage Relief Valve.

- 1. Up to 32,000 feet, air and oxygen are mixed.
- 2. The check valve (5) shuts off the air at 32,000 feet.
- 3. With the diluter lever in normal oxygen, the aneroid controls the air.
- 4. Above 32,000 feet, the user automatically gets 100% in the normal oxygen position.

Answers to Frame 5: 1. / 2. .3.

Frame 6

As we have stated, with the diluter lever in "NORMAL OXYGEN," the ameroid (8) will control the amount of air entering the regulator and at 32,000 feet it closes air metering port. When the diluter lever is manually placed in the "100% OXYGEN" position, the diluter control cam (2) swings down as indicated in the schematic and engages a strip of metal attached to the common lever and forces the lever down. This action overrides the aneroid and closes off the air metering port (I). This action supplies the user with 100% oxygen anytime he/she so desires.




- 1. Air Metering Port.
- 2. Diluter Control Cam.
- 3. Emergency Valve.
- 4. Demand Diaphragm.
- 5. Check Valve.

- 6. Pressure Reducing Valve.
- 7. Demand Valve.
- 8. Ameroid.
- 9. Oxygen Metering Port.
- 10. 2nd Stage Relief Valve.

- 1. The diluter lever allows the user to select 100% oxygen at anytime.
- 2. The diluter lever moves the diluter control cam.
- 3. The diluter lever overrides the aneroid when placed in 100% oxygen.
- __ 4. The diluter lever controls the first stage reducing.

The only section of the A-12a are have not covered is the EMERGENCY VALVE (3). This is a hand-wheel operated valve that opens an orifice as shown in the schematic. When the emergency valve (3) is turned out, oxygen will flow through this machined orifice in a continuous flow to the user. Should pressure build up in the regulator, a 2nd stage relief valve will open at 30 to 41 inches of water pressure to relieve it. The emergency valve is provided in case the regulator malfunctions or the user is unable to breathe normally. Remember, the normal function of this regulator requires that the user demand (inhale).



- 1. Air Metering Port.
- 2. Diluter Control Cam.
- 3. Emergency Valve.
- 4. Demand Diaphragm.
- 5. Check Valve.

- 6. Pressure Reducing Valve.
- 7. Demand Valve.
- 8. Ameroid.
- 9. Oxygen Metering Port.

- 1. The emergency valve allows the user to get a continuous flow of oxygen.
- The 2nd stage relief valve opens at 30 to 41 inches of water pressure.
- 3. The emergency valve will open automatically.
- 4. The normal function of the A-12A requires the user to inhale.




SELF TEST QUIZ

In each question, circle the letter that identifies the correct ensuer. Check your answers on the top of the next page.

- 1. The second stage relief valve in the A-12A will open and relieve pressure at
 - a. cabin pressure.
 - b. 5 psi.
 - c. 15 inches of mercury.
 - d. 30 to 41 inches of water.
- 2. The A-12A oxygen regulator is a
 - a. diluter demand regulator.
 - b. pressure demand regulator
 - c. continuous flow regulator.
 - d. diluter pressure demand regulator.
- 3. A complete oxygen system with the A-12A regulator installed would be referred to as a
 - a. high pressure oxygen system.
 - b. diluter oxygen system.
 - c. demand oxygen system.
 - d. low pressure oxygen system.
- 4. The pressure reducing mechanism in the A-12A oxygen regulator reduces cylinder pressure to
 - a. 40 to 60 inches of water.
 - b. 40 to 60 inches of mercury.
 - c. 40 to 60 psi.
 - d. cabin pressure.
- 5. If the user of the A-12A regulator became injured or for some other reaso could not breathe normally, he would
 - a. put the diluter lever in "normal oxygen."
 - b. use a walk-around bottle.
 - c. open the emergency valve.
 - d. place the diluter lever in "100% oxygen."
- 6. In the A-12A demand regulator, the demand disphragm opens and closes the demand valve in direct response to
 - a. atmospheric pressure.
 - b. the setting of the diluter lever.
 - c. the aircraft altitude,
 - d. the breathing of the user.

Instructions:

Place the number of the part in the list below in the correct arrowed circle.




- 1. Air Metering Port.
- 2. Diluter Control Cam.
- 3. Emergency Valve.
- 4. Demand Diaphragm.
- 5. Check Valve.

- 6. Pressure Reducing Walve.
- 7. Demand Valve.
- 8. Aneroid.
- 9. Oxygen Metering Port.
- 10. Diluter Lever.
- 11. Relief Valve.

Type A-12A Diluter Demand Oxygen Regulator (Aro).

2676 Answers to Frame 9:



- 1. Air Metering Port.
- 2. Dilnter Control Cam.
- 3. Emergency Valve.
- 4. Demand Diaphragm.
- 5. Check Valve.


- 6. Pressure Reducing Valve.
- 7. Demand Valve.
- 8. Aneroid.
- 9. Oxygen Metering Port.
- 10. Diluter Lever.
- 11. Relief Valve.

Type A-12A Diluter Demand Oxygen Regulator (Aro).

No response required.



The A-14 or A-14A demand mask is used with the A-12A demand oxygen regulator. The demand mask has a single outlet valve (1). This is a one-way check valve consisting of a circular flap of rubber which opens the outlet when the user exhales and closes it when he inhales. Proper regulator operation depends upor how well the mask fits and how well it is functioning. Oxygen masks are normally maintained by Personal Equipment Specialists and by the user. Knowing how they function will help you understand more clearly the oxygen regulators.



A-14A Demand Mask.

- 1. The A-14 mask has a single outlet valve.
- 2. Regulator operation is affected by the mask.
- 3. The demand mask is used with a demand regulator.
- 4. Any mask can be used with any regulator.

A other part of the demand oxygen system is the flow indicator and pressure gage. These two indicators are located close to the oxygen regulator and should be clearly visible to the user. The A-3 flow indicator is disphragm operated and "blinks" at the user as he/she breathes. This lets the user know that oxygen is flowing through the regulator. The K-1 pressure gage is bourdon tube operated. As pressure inside the tube tends to straighten it, the pointer is moved through a system of levers. The pressure gage lets the user know how much oxygen is in the system that he/she is breathing from.






A-3 Flow Indicator,

K-1 Pressure Gage.

and

- The K-1 pressure gage is bourdon tube operated.
- The A-3 flow indicator operates from a bourdon tube.
- 3. The flow indicator "blinks" as the user breathes.
- 4. The flow indicator and pressure gage are located near the regulator.

Shown below is the flexible tubing or hose used to deliver the oxygen from the regulator to the mask. The plain end of the mask to regulator tube assembly (right below) is clamped to the outlet elbow of the demand regulator. The other end of the hose contains a clothing clip, dust cap, and female part of a quick disconnect. The male part of the quick disconnect is attached to hose connected to the demand mask (left below). A leakproof connection is made when both halves of the quick disconnect are joined.




- 1. One end of the mask to regulator tube has a cloth; , clip and a dust cap.
- 2. The male part of the quick disconnect is attached to the mask hose.
- ___ 3. The quick disconnect will always leak.

Answers to Trame 121 1. 2. 2. 3.

Frame 13


Other than the station regulators like the A-12A, regulators are also used on small portable cylinders called "walk-around bottles." These bottles are carried on the larger type aircraft where crew members have to leave their station regulators to perform various duties while the aircraft is in flight. The older combination A-13 demand regulator and D-2 cylinder will supply oxygen for about 30 minutes before it has to be recharged from the aircraft main system. The A-13 demand regulator has no air inlet and supplies 100% oxygen on demand. The D-2 cylinder is serviced with 400 to 450 psi of oxygen. The carrying bag is used with this combination because of the weight of the D-2 cylinder.



- 1. Walk-around bottles would be needed on fighter aircraft.
- 2. The A-13 is a straight demand regulator.
- 3. The D-2 cylinder is filled from the aircraft system.
- 4. The A-13 regulator supplies 100% oxygen on demand.



The regulators used on walk-around bottles function the same as station regulators (A-12A) but are constructed somewhat different. The newer A-15 diluter demand regulator and A-6 cylinder are also part of the demand coxygen equipment. All portable regulators are constructed similar to the A-15 below with a 0 to 500 psi pressure gage, direct oxygen mask connection, filter fitting and clothing clip. The A-15 has an air inlet which tells us it's a diluter demand type. The A-6 cylinder is not as heavy as the D-2 cylinder previously discussed and a clothing clip is provided to attach it to the flying suit of the user. The A-6 is also serviced to 400-450 psi. The user has to constantly watch the pressure gage on walk-around bottles and recharge the cylinder before it is empty.



- 1. The A-15 is a portable, diluter demand regulator.
- On ws -around bottles, the cylinder is serviced through the regulators.
- 3. Portable regulators are constructed the same as station regulators.
- 4. The above unit is attached to the clothing of the user.

Answers to Frame 14 1. \checkmark 2. \checkmark 3. 4. \checkmark

Frame 15


This concludes our discussion on demand oxygen equipment. The equipment covered in this text will be available in the classroom or oxygen lab for you to handle and inspect. Remember, oxygen equipment is depended upon by the user as his main life support at high altitudes. Failure of this equipment for a 15 second period may be fatal to the user. Also, while you are working with and handling oxygen and equipment, don't forget the safety precautions that apply to oxygen.

SELF TEST QUIZ

Circle the correct answer and check your answer on the next page.

- 1. The A-15 portable regulator differs from the A-13 portable regulator in that the
 - a. A-15 has a demand function only.
 - b. A-15 is diluter demand.
 - c. A-13 has a filler fitting.
 - d. A-13 has a pressure gage.
- The type of oxygen mask used with the A-12A regulator in a demand oxygen system is the
 - a. Al3 pressure mask.
 - b. Al4 demand mask.
 - c. K-1 diluter mask.
 - d. A-3 mask.
- 3. The A-6 portable cylinder is used in combination with the
 - a. \-15 diluter demand regulator.
 - b. A-12A pressure regulator.
 - c. A-13A dilu regulator.
 - d. A-14 fixed regulator.
- 4. The A-13 and A-15 oxygen regulators are
 - a. both diluter demand.
 - b. station regulators like the A-12A.
 - c. used on walk-around bottles.
 - d. constructed the same as the A-12A.

Remember Your Oxygen Safety



Keep all petroleum products (oil, grease, fuel, etc) oway from oxygen equipment.

Make sure that body, clathing, and protective equipment are clean and free of petroleum products (hair oil is a petroleum product) before perfuming maintenance on axygen system.

END OF TEXT

19

PROGRAMMED TEXT

3ABR42331-PT-401C

* Technical Training \

Aircraft Environmental Systems Mechanic

PRESSURE DEMAND OXYGEN EQUIPMENT

15 March 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE

DO NOT USE ON THE JOB

FOREWORD

This programmed text was prepared for use in the 3ABR42331 instructional system. The materials contained herein have been validated using 30 students enrolled in the 3ABR42331 course. Eighty percent of the students taking this text surpassed the criterion called for in the approved lesson objective. The average time required was 2.8 hours to complete the text.

OBJECTIVE

Relate five (5) of six (6) gaseous oxygen system components to their operation.

INSTRUCTIONS

This programmed text will review some of the parts taught in previous lessons on gaseous oxygen systems and cover in depth the operation of the regulators and mask that make the system a pressure demand system. In addition, the reason the pressure demand system a needed is explained.

The information in this text is presented in small steps called frames. After each frame you are asked to respond in some manner. Read the material carefully, then make your response as directed. The answers for the responses can be found on top of the next page. If you answered correctly, continue on to the next frame. If you are wrong or in doubt, read the technical material again and correct yourself before continuing.

Supersedes 3ABR42231-PT-313A, 22 March 1971.


OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/TTGU-P - 300: TTVSA - 1



2

The diluter demand regulator sends oxygen or oxygen mixe, with air to the user on demand or when he breathes. This is all just fine until we reach a height of about 40,000 feet. From 40,000 feet up, the human body needs oxygen under pressure to work the way it should. At sea level pressure, carbon dioxide and water are stable in the blood stream and oxygen saturation of the blood is 100%. At low atmospheric pressure (high altitude), carbon dioxide and water vaporize in the lungs and pressure builds up that keeps oxygen from entering the lungs. By adding pressure to the oxygen (pressure breathing), we get rid of this pressure in the lungs and force the carbon dioxide out and force oxygen in. Look at the chart below for a better idea of the equipment required.



Using the chart above to determine the approximate altitude for each of the questions written below. Place your answer in the blank provided.


- 1. What is the limit of a demand oxygen regulator?
- 2. What is the safe limit a person can reach without oxygen equipment?
- ____3. At what altitude is a pressure suit desirable?
- 4. How high can a pilot safely fly with a pressure breathing system?



2647
Answers to Frame 1: 1. 40,000 2. 10.000 3. 45,00 44,0

Frame 2

With pressure breathing, as shown in the chart in the past frame, we are safe up to a height of about 50,000 feet. Above this height, the carbon dioxide and water vapor pressure will rise to a point where any more of an incresse in oxygen pressure would damage the lungs. Also, above 50,000 feet, a pressure suit is needed in case cabin pressure is lost. Without any pressure, blood will boil at 60,000 feet, so you can see the need of this equipment. Now that you know why we need pressure breathing, let us talk about some of the replators that make up a pressure-demand system. Shown below is a complete oxygen system with the A-14 pressure demand regulator used. Note that the change found between this system and the straight demand system is in the regulator and mask used. The A-14 is a pressure demand regulator and the A-13A is a pressure demand mask.




Check the following statements that are true.

- 1. The A-14 is a pressure demand oxygen regulator.
- 2. The A-12A regulator can be used above 50,000 fect.
- 3. Above 50,000 feet, a pressure suit is essential.

Frame 3

Take a look at the difference between the A-14 (top) and the A-12A (lower) regulators. If you place your finger over the top section of the A-14 you will see that we have an A-12A regulator again, except for the EMERGENCY VALVE (13) on the A-12A. One of the settings on the A-14 dial will serve as an emergency setting. Keep in mind when we talk about the A-14 regulator that except for the pressure breathing section located on top, this regulator will work the same way as the A-12A. Match all the parts listed below with the A-14 regulator.



*A-14 **A-12A

Emergency Valve

*11.

*12.

**13.


No Response Required

Pressure Breathing Gear Train

Pressure Breatking Control Knob



The A-14 regulator is a pressure-breathing, diluter-demand regulator. The diluter lever works the diluter control cam (6). In the 100% oxygen position, the diluter control cam will press down on the metal strip hooked to the common lever and close the air valve (4). The regulator is now delivering 100% oxygen. With the diluter lever in the NORMAL OXYGEN position, the air is controlled by the aneroid (8) up to 32,000 feet at which time it, the air valve (4), will be closed off (same as the A-12A). Match the part name with the number in the arrowed circles for a better understanding.



A-14 PRESSURE-BREATHING DILUTER-DEMAND REGULATOR

Pressure Reducing VAlve 7. Diaphragm 1. 8. Aneroid Demand Valve 2. . .essure Breathing Lever 9. Oxygen Metering Valve 3. 10. Demand Diaphragm Air Valve 4. Pressure Breathing Gear Train 11. Check Valve 5. Pressure Breathing Control Knob 12. Diluter Control Cam 6.

Place the number of the part in the blank space next to the statement that best describes its operation/use.

- Worked by the diluter lever.
- b. The diluter control cam presses on a metal strip attached to the common lever and closes this valve.
- c. Controls the air up to 32,000 feet with the dilute: lever




Frame 5

The pressure breathing control knob or selector dial on the A-14 has six (6) positions that the user can choose from as he goes from sea level to above 45,000 feet. As shown in the regulator sketch below, the dial is hooked to a gear train which in turn will crank down the spring lever and force the domand diaphragm to open the demand valve. The first column in the chart shown lists the six different settings. In NORMAL, no pressure is placed on the demand diaphragm and the A-14 will work the same as the A-12A. The second column lists the altitude at which each setting should be used, and the third column lists the pressure that is sent to the mask. (Note: On the dial setting, "M" = thousands). In case of emergency, the setting "ABOVE 45M" is used.

8

DIAL SETTING		DELIVERED PRESSURE		
HORMAL	30,000	NO PRESSURE SAME AS A-12A		
SWETY	30,000	0.04791		
41M	- 39,000 41,000	0.1 <i>5</i> P Q 1		
49M	41,000 43,000	0.21791		
45M &-	43,000 45,000	0.2998		
ABOVE 45M		0.43791		



PRESSURE SETTINGS AND PRESSURE DELIVERED.

Refer to the chart above to complete each of the following statements.


- 1. The emergency setting on the A-14 regulator delivers PSI to the mask.
 - 2. The safety setting will be used at altitudes between and .
 - 3. At the 43M setting PSI is delivered to the mask.
- 4. At 39,000 feet the dial setting should be changed from SAFETY


2701


Answers to Frame 5: 1. 0.43 2, 30,000 ft, 39,000 ft 3. 0.21 4. 41M


Frame 6

The first schematic below shows operation at sea level The dial would be set at "NORMAL." A.ytime that the regulator is not being used it must be set ou "NORMAL" or else spring tension on the demand diaphragm will drain the system. Stud all of the schematics and read the information that tells just what is taking place.











No Response Pequired









Place the letter of the sketch in the blank space $\ensuremath{\text{next}}$ to the situation it matches.

- ____l. You will only breathe air because the air valve is open and the oxygen valve is closed.
- 2. The regulator will provide you with 100% oxygen because the air valve is closed and the oxygen value is open.

2703 Answers to Frame 7: 1. <u>A</u> 2. <u>B</u>

Frame 8






Place the letter of the sketch in the blank space next to the situation it matches.

- 1. As you breathe out you push the diaphragm against the spring tension. This in turn closes the demand valve and stops the flow of oxygen to the mask.
- 2. When you inhale the spring pushes against the diaphragm. The diaphragm opens the demand valve and oxygen is forced into the mask.

Frame 9

As has been said, the "normal" setting on the A-14 is used up to 30,000 feet and when the system is not being used the regulator must be left in this position. From 30,000 feet to 39,000 feet, the user should select the SAFETY setting on the dial. As explained below, this is added insurance against hypoxia which can creep up on you. The SAFETY setting provides only .04 psi to the mask.



Use of the Safety Satting on Type ..-14 Oxygen Regulators.

	1	The SAFETY setting 39,000 feet.	on	the	Λ-14	is	used	between	36,000	an d
--	---	---------------------------------	----	-----	------	----	------	---------	--------	-------------

2. The SAFETY is used in case of an emergency.

Check the following statements that are true.

- 3. Hypoxia can creep up on you at high altitudes.
- 4. When left in NORMAL, the regulator will not drain the system.




2705

Answers to Frame 9: $\sqrt{1}$. 2. $\sqrt{3}$. $\sqrt{4}$.

Frame 10

Keep in mind that without the pressure breathing mechanism, the A-14 will work the same as the A-12A regulator. The oxygen is reduced in the first stage chamber to 40 to 60 psi by the pressure reducing valve (1) a the diaphragm (7). The demand valve (2) is still controlled by the demand diaphragm just the same as in the A-12A. The oxygen pressure in the second stage chamber can be controlled in two ways. At low altitude it will be the same as the cabin pressure on top of the demand diaphragm and during pressure breathing it will be controlled by the spring tension of the pressure breathing lever (9). Remember, the air for dilution is still controlled by the diluter lever which works the diluter cam (6) and by the aneroid (8).




Type A-14 Pressure Demand Oxygen Regulator.

Place the number(s) of the component in the blank next to the statement that best describes its operation/use.

- Controlled by the demand diaphragm.
- b. Spring tension of this lever will control the oxygen pressure in the second stage chamber during pressure breathing.
- . This part and the diluter lever control the air for dilution.



Frame 11



Place the letter(s) of the part in the blank space next to the statement that describes its operation/use. Some statements require more than one answer.


1.	Reduces oxygen pressure in the first stage chamber to 40 to 60 PSI.
2.	In the 100% oxygen position the diluter control cam presses down on a metal strip attached to a common lever to close this valve.
3.	When you inhale, this spring puts a force on the demand diaphragm and opens the demand valve.
4.	The diluter lever works this item.
5.	This item will control the air flow to the mask up to 32,000 feet with the diluter lever in the normal position.
6.	Exhaling will force this diaphragm against the spring tension on the pressure breathing lever and close the demand valve.
7.	To breathe 100% oxygen these valves must be open



2707
Answers to Frame 11: G, K 1. J 2 D 3. C 4. L 5
I 6. F, H 7.

Frame 12

Before we go to the next regulator that has a pressure gage and a flow indicator built in, we should say here that with the A-14, the A-3 flow indicator, and the K-1 pressure gage are the same ones as used with the A-12A. If you recall, in the past lesson we said that the K-1 pressure gage is bourdon tube operated and shows cylinder pressure. The A-3 flow indicator (blinker) lets the user know that oxygen is flowing through the regulator by a blinking action.



A-3 Flow Indicator.

Check the following statements that are true.

1. The K-1 pressure gage and A-3 flow indicator are used with the A-12A and A-14 ingulators.

14

- 2. All onygen regulators require a separate pressure gage.
- 3. The K-1 pressure gage is boundon tube operated.

Answers to Frame 12: $\sqrt{1}$. 2. $\sqrt{3}$.

Frame 13

As was said in the past, there are many models of that same oxygen regulator. The D-2A regulator, shown below, is also a pressure demand regulator with many changes over the A-14. The change that is most easily seen from looking at the face of the D-2A is that the pressure gage and the flow indicator have been added to it. Now note that no pressure control dial is seen so this shows that the D-2a will sutomatically deliver the right pressure as altitude changes. This is done with an aneroid. The D-2A regulator also has an ON-OFF supply switch (lower center) that shuts off the oxygen supply to the regulator when it is not being used. The D-2A is placed on a panel in the aircraft and the A-12A and A-14 are hooked in the oxygen lines.



Type D-2A Oxygen Regulator.

Complete the following statements.

 The D-2A oxygen reg 	ulator has	a built-in	pressure g	gage and
·				
2. (Inside of the D-2A)	regulator :	is an	that	will auto
matically deliver the right pr	ressure as	the altitud	e changes.	ı
3. The D-2A is mounted			·	in the
aircraft while the	and	are co	nnected ir	ito the
oxygen line.	3			


2709

Answers to Frame 13: 1. flow indicator 2. aneroid

3. on a panel, A-12A, A-14

Frame 14

The MD-I pressure demand regulator, shown below, is very much like the D-2A but has a lot of improvements. The compact design needs about half of the panel space to mount in and presents the user with a much more uniform and readable system of controls. This regulator is used more at the present time than any other regulator because it can be adapted to more systems in use. For high altitude flights this is the best regulator available at the present time. In the illustration, look at the three toggle switches that are used to control this regulator. The EMERGENCY toggle (left) has three positions: emergency (up), normal (center), and test mask (down). The DILUTER toggle (center) has two positions: 100% and normal. The SUPPLY toggle is simply on or off. The FLOW indicator is the "flag" type which is worked by a diaphragm. The pressure gage shows system pressure or pressure before it is reduced for breathing.



Type MD-1 Automatic Diluter Demand Pressure Breathing Oxygen Regulator.

Check the following statements that are true.


1.	The MD-1 has three toggle switches for control.	
2.	The MD-1 is used more than other regulators at present.	
3.	The MD-1 is twice as large as the D-2A regulator.	
4.	The emergency toggle has three positions.	
5.	The flow indicator operates from a diaphragm.	



Answers to Frame 14: $\sqrt{1}$. $\sqrt{2}$. $\sqrt{3}$. $\sqrt{4}$. $\sqrt{5}$.

Frame 15

Let's take a look at the major parts inside the MD-1 before we talk about how it operates. Mentally match each numbered item in the schematic below with its name from the list below.



- 1. Pressure Gage
- 2. Supply Toggle
- 3. Press. Reducing Meclanism
- 4. 1st Stage Chamber
- 5. 1st Stage Relief Valve
- 5. Diluter Toggle
- 7. Diluter Ameroid
- 8. Demand Valve
- 9. Injector Mechanism
- 10. Flow Indicator
- 11. Emergency Toggle
- 12. 2nd Stage Relief Valve
- 15. Demand Diaphragm

13.

14.

16. Cour er-Weight Lever


2nd Stage Chamber

Demand Valve Lever

17. Press. Breathing
Ameroid

No Response Required

Some of the parts of the MD-1 have, in the past, been pointed out to you. The pressure gage (1) shows system (or supply) pressure. The supply toggle switch (2) just lets oxygen in the regulator when it is placed in "ON." The pressure reducing mechanism (3) is the first stage of reducing. This is a spring loaded bellows and valve which sets the incoming pressure between 37 and 45 psi. As the bellows moves up and down, the valve moves back and forth (see arrows). The reducing mechanism is in the first stage chamber (4). The first relief valve (5) will open at 55 psi if the reducing mechanism fails. The diluter toggle switch (6) lets cabin air in to mix with the oxygen when it is in the "normal oxygen" position and the air inlet valve is in the "100% oxygen" position.



Match the circled number of the component in the schematic to the statement below that describes that component operation/use.


- e. Opens a valve that allows oxygen from a converter into the regulator.
- b. When put into the normal position it lets cabin air mix with the oxygen and dilute it.
- c. A high incoming oxygen pressure will affect a spring-loaded bellows in this mechanism which in turn will set the incoming pressure between 37 to 45 psi.
- d. A spring loaded valve that will open at 55 ps if the pressure reducing valve failed.
- e. Shows the oxygen pressure in the system (supply pressure).

2712

Answers to Frame 16: 2 a. 6 b. 3 c. 5 d. 1 e.

Frame 17

The diluter aneroid (7) lets air in according to the <u>cabin</u> altitude when the diluter toggle switch is in the "normal oxygen" position. The aneroid will expand and completely shut off the air at 33,000 feet <u>cabin</u> altitude. The demand valve (8) lets the oxygen into the injector assembly (9) which acts as a venturi (creates a low pressure area). This low pressure area draws air in to mix with the oxygen. If a large demand is placed on the regulator, the injector (9) will slide forward (to the left) and let oxygen by ass through the p. ssageway on each side. The flow indicator (10) is a "flag" which is diaphragm-operated and shows in the viewing window as the user breathes.




Place the number of the component from the above schematic in the blank alongside the statement that best describes its operation/use. Some numbers can be used more than once.

a.	Cabin atmospheric pressure will cause this unit to expand.
b.	Creates a low pressure area that draws air in to mix with the oxygen.
c.	The amount of oxygen that flows into the injector is controlled by this unit.
d.	Meters air according to the cabin altitude completely shutting off the air flow when the cabin altitude reaches 33,000 feet.
e.	Operated by a diaphragm to show the flow of oxygen each time the user inhales.
f.	Slides forward when a high demand is placed on the regulator to lat oxygen bypass through passageways in each side of it.

27/3
Answers to Frame 17: 7 a. 9 b. 8 c. 7 d. 10 e

Frame 18

The emergency toggle switch (11) gives pressure breathing at any altitude when it is put in "EMER." In the n"normal" position, pressure breathing is taken care of by the pressure breathing aneroid (17). The "test mask" position provides pressure for testing the mask for leaks while on the face. The second stage relief valve (12) relieves pressure above 1.5 inches of water pressure in the second stage chamber (13). The demand valve lever (14) is hooked, at one end, to the demand diaphragm. It will push the demand valve found on the other end of the lever up and down. The counterweight lever (16) provides a linkage to the emergency toggle switch. It stops the fluctuation of pressure in the second stage chamber. The pressure breathing aneroid (17), which was mentioned earlier, automatically increases the pressure load on the demand diaphragm as the aircraft altitude increases. This, in turn, increases the pressure sent to the mask.




Place the number of the part from the above sketch in the blank space alongside the statement that best describes its operation/use. Some numbers can be used more than once.

- a. In the normal position aircraft altitude will cause this unit to expand and increase the pressure load on the demand diaphragm which, in turn, will increase the pressure sent to the mask.
- Provides a linkage from the demand diaphragm to the emergency toggle switch.
- c. When moved by the demand diaphragm, moves the demand valve up or down to increase or decrease the pressure sent to the mask.
- d. When placed in the emergency position it will provide pressure breathing at any altitude

ERIC.

Frame 19

In the sketch shown you can see how the MD-1 works below 30,000 feet when the user inhales or calls for oxygen. Follow the flow of oxygen and air through the regulator as we talk about how it works. With the supply toggle switch "ON," oxygen goes to the first stage chamber where the pressure is dropped to 37 to 45 psi. Oxygen now goes down to the small chamber below the pressure breathing aneroid. To aneroid has not expanded and the diaphragm under the aneroid has this port closed. When the user inhales, a vacuum is formed in the second stage chamber (shown by the circles) that will raise the demand diaphragm and the demand lever which, in turn, opens the demand valve. Oxygen will now flow through the top of the demand valve and through the injector, which will cause a low pressure area and draw in air from around the diluter aneroid. Oxygen also goes up to the flow indicator diaphragm and pushes the flag up to the window. The air and oxygen now mix in front of the injector and flow to the mask.



Select the statements that describe the operation of the MD-1 oxygen r julator. (Circle the number(s) of your choice.)


- 1. As you inhale the demand diaphragm will rise and open the demand valve and let oxygen from the corverter flow through the injector.
- 2. The oxygen that flows through the injector will create a low pressure area that will draw in air from around the diluter aneroid and mix it with the oxygen.
- 3. For items 1 and 2 above to happen the supply toggle is in the "ON" position, diluter toggle is in "normal oxygen," the emergency toggle is in "NOR," and the aircraft must be below 30,000 feet



27/5Answers to Frame 19: (1) (2) (3)

Frame 20

Let's take a look at what goes on in the regulator when the user exhales or breathes out. Muscular effort on the part of the user is needed to overcome the pressure in the regulator. This is especially true if the pressure breathing aneroid is in operation. When the user breathes out hard enough, the demand diaphragm drops down and lets the demand valve go closed. This back pressure also closes the air check valve below the diluter aneroid. Pressure on the top side of the flow indicator diaphragm pulls the flag out of the window. Oxygen pressure will quickly build up in the first stage chamber and close the reducing valve. When the user inhales again, this pressure is reversed as was explained in the previous frame.




Select the true statements from the following. (Circle the number(s) of your choice.)

- 1. When the user exhales, the flow indicator flag is not visible.
- 2. Muscular effort is required when exhaling into the regulators
- 3. When exhaling, the demand diaphragm drops and closes the demand valve.
- 4. The diluter toggle must be in 100% oxygen o get air in the regulator.
- 5. The first-stage chamber reduces pressure to between 37 and 45 psi.

Frame 21

Now, let's talk on how the MD-1 regulator works when pressure breathing. As we have said, pressure to the mask is changed automatically by the pressure breathing and oid as cabin pressure goes up. A safety pressure of 0.1 to 0.2 inches of water is sent to the mask at altitudes of 30,000 to 39,500 feet to do away with the chance of a negative pressure at the mask. Near 40,000 feet, the pressure breathing aueroid has expanded to give automatic pressure breathing to the user. This pressure is from 2 to 15 inches of water pressure depending on cabin altitude. You can see in the sketch shown that oxygen from the pressure breathing aneroid has raised the demand diaphragm which now holds the demand valve open. The cycle shown is when the user is breathing in. To exhale, the user has to overcome the pressure on the demand diaphragm. See, too, that the diluter aneroid has closed the air inlet and the flow indicator flag can be seen in the window.



Select the statements that describe the operation of the MD-1 regulator during pressure breathing. (Circle the number(s) of your choice.)

- 1. At altitudes of 30,000 to 39,500 feet a safety pressure of 0.1 to 0.2 inches of water is sent to the mask to do away with the chance of a negative pressure at that point.
- 2. Around 40,000 feet the pressure breathing ameroid has expanded and raised the demand diaphragm which, in turn, holds the demand valve open.
- 3. To exhale you have to overcome the pressure applied to the demand diaphragm.


27/7
Answers to Frame 21:

1. 2. 3.

* Frame 22

INSTRUCTIONS


Identify the components of the MD-1 oxygen regulator by matching the letters in the arrowed circles with the name of the item below.



1. 2. 3. 3. 4. 5. 6. 7	Pressure Reducing Mechanism 1st Stage Chamber 1st Stage Relief Valve Diluter Toggle	10. 	Flow Indicator Emergency Toggle 2nd Stage Relief Valve 2nd Stage Chamber Demand Valve Lever Demand Diaphragm Counter-Weight Lever Pressure Breathing Ameroid
6.	Diluter Toggle	16.	
7.	Diluter Aneroid	17.	Pressure Breathing Ameroid
8.	Demand Valve		,
9.	Injector Mechanism		•

27/8

Frame 23



Select the statements that describe the operation of the MD-1 regulator below 30,000 feet. (Circle the number(s) of your choice.)

- 1. Both the pressure breathing ameroid and diluter ameroid are compressed.
- 2. The pressure breathing aneroid expands while the diluter aneroid is compressed.
- 3. With the supply toggle in "ON," oxygen goes to the first stage chamber where it is reduced to 37 to 45 psi.
- 4. When you inhale a vacuum is formed in the second stage chamber that raises the demand diaphragm and opens the demand valve.
- 5. Oxygen will flow through the injector which creates a low pressure area that draws air in through the diluter anercid valve.
- 6. Both the oxygen from the injector and the air from the diluter anexoid mix and flow to the mask.
- 7. As you inhale a pressure is placed on the demand diaphragm forcing the demand diaphragm to close the demand valve.
- As you inhale a pressure is placed on the top of the flow indicator diaphragm which pulls the flag out of the window.



Frame 23 (Cont'd)

Select the statements that describe the operation of the MD-1 regulator during pressure breathing. (Circle the number(s) of your choice.)


- 9. The diluter aneroid will expand as the aircraft rises in altitude closing the diluter valve.
- 10. The driuter aneroid will send a safety pressure of 0.1 to 0.2 inches of water to the mask at altitudes of 30,000 to 39,000 feet.
- 11. Near 40,000 feet, the pressure breathing aneroid has expanded and provides oxygen pressure to the mask equivalent to 2 to 15 inches of water pressure.
- 12. The pressure breathing aneroid supplies oxygen pressure to raise the demand diaphragm and close the demand valve.
 - 13. During pressure breathing a person cannot exhale.
- 14. When oxygen pressure is supplied to the mask it also is placed on the bottom of the flow indicator diaphragm raising the flag in the window.

Answers to Frame 23;

(1) 2. (3) (4) (5) (6) 7. 8 (9) 10. (11) 12. 13. (14)

Frame 24

The oxygen regulators that are used in high pressure gaseous oxygen systems (1,800 to 1,850 psi) where a pressure reducer is not installed between the cylinders and the regulator are the MD-2 and MB-2 pressure demand regulators. If a pressure reducer is installed, regulators such as the MD-1 and D-2A can be used. The principles of operation of the MD-2 and MB-2 are the same as the MD-1. However, these regulators are constructed internally to withstand high pressure. The MD-2 shown (note the high pressure gage) looks the same as the MD-1 but the two regulators cannot be interchanged.




MD-2, Oxygen Regulator

Check the following statements that are true.

<u>·1</u> .	The MD-2 and MB-2 are high-pressure regulators.
2.	The D-2A regulator is designed to withstand high pressure.
3.	The MD-2 is a pressure demand regulator.
4.	If a pressure reducer is installed between the high press recylinders and the regulator, it's possible to use the D-2A.

Frame 25

The pressure demand, mask, type A-13 and type A-13A, are used with the pressure demand oxygen system. Pressure demand masks are not like demand masks in that they will hold pressures higher than ambient pressure. A flap or seal made of rubber (4) forms a ring on the inside of the mask to keep the oxygen in the mask. Check valves (2) keep the oxygen inlets closed while the user is exhaling. The exhalation valve (3) opens only at a pressure just a little more than that on the inside of the tubing leading to the mask. The housing of the exhalation valve forms a tube which goes down into the inlet tube (5). Through this tube, the oxygen coming in sends its delivery pressure to act upon the lower side of the compensating diaphragm (6). This pressure keeps the exhalation valve/(3) closed until a little greater pressure caused by exhaling is brought to bear upon the upper surface of the main diaphragm (7). The valve then opens and the exhaled air leaves the mask through the port (8). The mask-to-regulator hose in the pressure demand system is the same as in the demand system.



Type A-13 Pressure Demand Mask.


Place the number from the sketch shown above in the blank alongside the statement that best describes the mask's operation/use.

- a. Will open when the user inhales and closes when the user exhales.
- b. Will stay closed until a little greater pressure caused by exhaling is placed on the upper surface of the main diaphragm at which time it will open.
- c. Exhaled air will leave through this port.

Frame 26

The portable pressure demand unit is shown below. It consists of the A-21 regulator and the A-6 cylinder. The pressure demand unit is installed in the larger aircraft with an operating range above 35,000 feet. The A-21 is a straight demand regulator (no air) and contains a bellows-operated pressure reducer. Pressure breathing is caused by turning the control knob which puts a load off the breathing diaphragm through a system of springs and levers (very much like the A-14). The control knob has four (4) settings: "NORMAL" (demand only, no pressure), "30M" (pressure breathing at 30,000 feet), "42M" (pressure breathing at 42,000 feet), and "EMERGENCY" (continuous flow of oxygen to the user).

type A-21 PRESSURE-BREATHING REGULATOR



Check the following statements that are true.

~	•							,
1.	The	A-21	is	а	pressure	demand	portable	regulator.

2. The A-6 cylinder is used with the A-21 regulator.

3. Pressure breathing is controlled by an anergid in the A-21.

Answers to Frame 26: $\sqrt{1}$. $\sqrt{2}$. 3.

Pressure Demand

Portable Unit

PROGRAMMED TEXT

3ABR42331-PT-401D

Technical Training

Aircraft Environmental Systems Machanic

CONTINUOUS FLOW OXYGEN EQUIPMENT

16 September 1977



3350 TECHNICAL TRAINING WING 3370 Technical Training Group Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE
DO NOT USE ON THE JOB

FOREWORD

This programmed text was prepared for use in the 3ABR42331 Instructional System. The material contained herein has been validated using students enrolled in the 3ABR42331 course. Ninety percent of the students taking this text achieved or surpassed the criteria called for in the lesson objective. The average student required 1 hour and 15 minutes to complete this text.

CBJECTIVE

Relate five of six gaseous oxygen system components to its operation.

INSTRUCTIONS


This text presents material in small steps called "frames." After each frame you will find a number of statements and you are asked to select the <u>true</u> statement or statements from this list. Read the material carefully before making a selection. The answers to the statements can be found on the top of the next frame. If you select the correct answers, centinue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before continuing.

Supersedes 3ABR42231-PT-313B, 2 December 1970.

OPR#* 3370 TTG DISTRIBUTION: K

3370 TTGTC - 600; TTVSR - 1

Continuous flow or constant flow oxygen equipment is not used in any of the combat type aircraft, but it is used in some of the training aircraft, and in all cargo aircraft that take part in air evacuation and the transporting of troops and cargo. The crew which is in the front part of the aircraft uses the demand type oxygen regulator, while the cargo part in the rear of the aircraft uses the constant flow system. The main reason for this is that the constant flow system does not meet the needs of the crew. The supply for the constant flow system is the same as it is for the demand system, either the gaseous or the liquid may be used. 'Since there are many constant flow systems that are now in use, this text will be limited to the one that is found on transport or cargo aircraft and is called "THE TROOP OXYGEN SYSTEM."




Check the following statements that are true.

- 1. Constant flow systems are not used in combat aircraft.
- 2. Constant flow systems use only a gaseous oxygen supply.
 - . 3. There are many different constant flow systems.

Answers to frame 1: $\sqrt{1}$. 2. $\sqrt{3}$. $\sqrt{4}$.

Frame 2

The troop or gen system will supply oxygen for up to 154 troops. It will work at a supply pressure of 300 psi. The pressure regulator is used to regulate the distribution pressure from 29 psi to 69 psi, depending on how high the aircraft is flying. If the aircraft is at a low altitude, a strong flow of oxygen will be needed due to the high atmospheric pressure that's around the lungs. The troop system is made up of a pallat that is removable and an oxygen regulator panel. Look at the schematic that is on this page. This will show the items in the system that are going to be covered in this text.




Troop Oxygen System Schemetic

MINIMINI

No Response Required

Part of the troop system is the liquid oxygen pallet which is shown on page 5. This pallet will hold two 75-liter converters, two heat exchangers, and the electrical connections and lines that are used to join it to the fixed part of the system. These pallets are completely removable when they are empty, and are repaired by the shop.




Check the	e following statements that are true.	ŧ.
1.	The liquid oxygen pallet is removable.	
2.	The pallet contains two 75-liver converters.	
3.	The liquid oxygen pallet is repaired by the crew o	hief.
4.	Heat exchangers are not used on the liquid oxygen	pallets
5.	The liquid oxygen pallet is part of the troop syst	em.

Answers to Frame 3: $\sqrt{1}$. $\sqrt{2}$. 3. 4. $\sqrt{3}$

Frame 4


The troop regulator panel is in the cargo compartment and is made up of the following items: Two (24 constant flow regulators, four (4) heat exchangers, three (3) dual check valves, and a pressure switch. There is a self contained troop oxygen panel which we will talk about at a later time. The supply lines that are on the panel are joined to each of the regulators through the dual check valves. Because of the different spring loads in the check valves, either or both converters will be able to supply oxygen to either or both regulators. The heat exchangers are used to warm up the gaseous oxygen to a temperature that will be safe for breathing.



/////////////////////////
No Response Required

6


The constant flow regulator that is now being used in the troop system is the Scott 100-man regulator. Two (2) of these regulators are used in this system. They are hooked in parallel so that if one of them fails to work, the supply to the ther regulator will not be cut off. The Scott regulator has a built-in flow control valve that will automatically open at a cabin altitude of 12,000 to 14,000 feet to let gaseous oxygen flow to the troop outlets. This flow of oxygen will go on until the cabin altitude drops to 11,000 feet. Look at the sketch shown. A manual on-off switch (top right) is used so that the regulators are able to be turned on at any altitude down to sea level. A pressure operated on-off indicator (center right) is on each regulator to tell you whether or not that regulator is on. The test port is used to check the operation of the indicator.



CHOCK THE	TOTIONING STOCHMENTS PROF STOC. 1
1,	Scott constant flow regulators have an automatic flow control valve.
2.	Only one (1) regulator is used in the system.
3.	The Scott regulator can be manually turned on at any altitude.
4.	The regulator will automatically open at 12,000 to 14,000 feet cabin altitude.
5,	When the cabin altitude drops to 11,000 feet oxygen will stop flowing.

Frame 6

The troop oxygen panel (shown below) is joined to the oxygen regulator panel. This panel holds two (2) 75-liter oxygen quantity indicators (A), one for each of the liquid oxygen converters that are found on the pallet. From this part on we are going to refer to liquid oxygen as LOX. There is a "PUSH-TO-TEST" button (B) that is found below each indicator. This button is used to check the operation of that indicator. In each of the quantity indicators there is a microswitch. This switch is used to turn on the LOX quantity low light (C) when the system quantity drops to 7.5 liters. This light tells the crew that they are low on oxygen. There is also a pressure switch found in the system. This switch turns the "Oxygen On" light (D) on when the system is filled with gaseous oxygen. When the oxygen regulators are open and a supply of oxygen is placed in the system, pressure builds up on the emergency horn anercid which; in turn, sets off the emergency horn that is in the cargo part of the aircraft. This warning horn is also turned on whenever the quantity of the LOX drops below 7.5 liters. There is also a "Horn Shut-Off" button (E) that is located on the oxygen panel. This button is used to manually shut off the horn. The "Oxygen Lights and Horn" test switch (F) is used to check the operation of the horn and oxygen lights. The "Bright and Dim" toggle switch (G) on the oxygen panel is used to manually dim or brighten the oxygen lights.




- _____1. The troop oxygen panel is used to monitor the supply system.
- 2. When the supply drops below 7.5 liters, the LOX QTY LOW light comes on.
- _____3. The troop oxygen panel is connected to the oxygen regulator panel.
- 4. A warning horn wounds when the converters are empty.



Answers to Frame 6: \(\frac{1}{2}. \quad \frac{3}{3}. \)

Frame 7

Joined with the troop oxygen system there is a therapeutic oxygen eystem. This system is to be used for patients that must have epecial care. It is made up of seven (7) oxygen regulators. These regulators are found in two therapeutic boxes, which are on the right side of the cargo compartment. See the sketch below. These regulators are adjusted by hand to get the right amount of flow. There is a phut-off valve on the oxygen regulator panel. This valve is used to shut off the system when it is not in use. There are three (3) recharger hoses that are used to fill the portable bottles in case more than seven (7) people need therapeutic care.



Check the following statements that are true.

1. The therapeutic oxygen system contains seven (7) hand-adjustable regulators.

2. The therapeutic system has seven recharger outlets.


3. This system contains a shut-off valve on the oxygen regulator panel.

4. The seven (7) oxygen regulators are installed 1 two therapeutic oxygen boxes.

\$7

Frame 8

The distribution lines are found on each side and on the center top of the cargo compartment. These lines have self-sealing oxygen mask outlets. These outlets have valves which will determine the amount of oxygen that will flow to the mask.




Check the	following statements that are true.
1.	The oxygen mask outlets are installed in the distribution lines.
2.	The oxygen mask outlets are self-sealing.
3.	The oxygen mask outlets are not installed in the cargo compartment.

4. The metering valves determine the quantity of oxygen at the rask.

Answers to Frame 8: $\sqrt{1}$. $\sqrt{2}$. 3. $\sqrt{4}$

Frame 9

The troop oxygen masks are made of flexible plastic. They are cone-shaped units and have a headstrap. The oxygen is supplied to the mask by a plastic hose which is joined to the oxygen mask outlet. (See the sketch below.) Care should be used to be oure that all of the marks that are plugged in are in use. Since this is a constant flow system, any mask that is plugged in and is not being used will drain the supply of oxygen and could cause a fire hazard by filling the compartment with pure oxygen.



Check the	following statements that are true.
1.	The troop oxygen masks are cone-shaped.
	Oxygen is aupplied to the mask by way of aluminum tubing.
3.	The masks are made of plastic.

4. All masks which are plugged in should be in use.



ALEVETA	to	Frame	9:	√ 1.	2.	√ 3.	√ 4

Relate the following six oxygen system components to the statement that best describes their operation in the system. Place its letter in the blank provided.

- a. Heat Exchanger
- b. On-Off Indicator
- c. Microswitch
- d. Oxygen Regulators
- e. Converter
- f. Flow Control Valve

12,000 to 14,000 feet.

1.	Mounted on each oxygen regulator panel and are used to war up the gaseous oxygen by absorbing heat from the atmospher air.	m 1c
2.	Built into the Scott oxygen regulator and will let gaseous oxygen flow to the troop outlets at a cabin altitude of	

- 3. Mounted inside the quantity indicators on the troop oxygen panel and will turn on the LOX quantity low light when the system quantity drops to 7.5 liters.
- hand to get the right amount of oxygen flow to patients who require-special care.
- 5. Uses the principle of a vacuum bottle to store the liquid oxygen used in the troop system.
- 6. Found on the oxygen regulator and is pressure operated to tell you whether or not the regulator is on.

Answers to Frame 10: 1. <u>a</u> 2. <u>f</u> 3. <u>c</u> 4. <u>d</u> 5. <u>e</u> 6. <u>b</u>

IF YOU HAVE MISSED JUST ONE ITEM GO BACK AND REVIEW THIS COMPLETE PROGRAMMED TEXT.



▼ PROGRAMMED TEXT 3ABR42331-PT-402

Technical Training

Aircraft Environmental System Mechanic

CHARACTERISTICS AND SAFE HANDLING OF LIQUID OXYGEN

8 September 1977



3350 TECHNICAL TRAINING WING 3370 Technical Training Group Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE HSF

DO NOT USE ON ISF JOB



FOREWORD

This programmed text was prepared for use in the 3ABR42331 Aircraft Environmental Systems Mechanics Course. The materials contained herein were validated using students from the subject course. At least 90% of the students taking this text achieved or surpassed the criteria established in the lesson objectives. The average time for completion of this text was 55 minutes.

OBJECTIVES

After completing this programmed text, you will be able to:

1. Select without error, safety precautions relative to the explosive, fire, and temperature hazards involved in the storage, handling, and use of liquid oxygen.

INSTRUCTIONS-

This programmed text presents material in small steps called "frames." After each frame you will find a number of statements and you are asked to select the statement(s) that are true. Read the material in each frame before making a selection. The answers to each frame can be found at the top of the next page. If you select the correct answers, continue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before continuing.


Supersedes 3ABR42331-PT-402, 18 3eptember 1972.

OPR: 3370 TTG DISTRIBUTION: X

3370 TTGTC - 400; TTVSR - ❤



While the low pressure and high pressure gaseous systems are still being used on Air Force aircraft, these systems are gradually hein changed to the LOX system. Since inflight refueling was introduced, an aircraft can fly for long periods of time. The pilot and crew need large amounts of oxygen. The low pressure gaseous cylinders are light but take up a lot of space. The high pressure cylinders take up less space but are heavier. The best choice was to use the LOX system, which saves space and weight. The average weight and space reduction for all aircraft is '4% (see illustration).




- 1. Liquid oxygen saves both space and weight.
 - 2. Because of inflight refueling no oxygen is needed.
- High-pressure cylinders will save space but increase weight..
- 4. Average space and weight reduction using liquid oxygen is 74%.

Answers to Frame 1: $\sqrt{1}$. $\sqrt{2}$. $\sqrt{3}$. $\sqrt{4}$.

Frame 2

Shown below is an example of space and weight reduction on a fighter aircraft. One five liter LOX contactor will replace and give as much oxygen as six high pressure oxygen cylinder.




No Response Required

Answers to Frame 3: $\sqrt{1}$. $\sqrt{2}$. $\sqrt{3}$. $\sqrt{4}$.


Frame 4 -

As we said earlier, LOX is made by the compression and expansion of air. The temperature of the air when it liquifies is between -297°F and -361°F. When the temperature of the LOX is dropped below -361°F, it becomes a solid, and when the temperature is raised above -297°F the LOX will start to "boil off" and change into a gas (see illustration). The boiling point of LOX is -297°F. The most important thing about LOX is its expansion capability when it changes from a liquid to a gas., One liter (a little more than a quart) of LOX will expand to 860 liters of 70°F gaseous oxygen. You can see the advantages here for aircraft use. The illustration below shows the difference between the boiling and freezing point of water and oxygen.



Check the	following statement(s) that are true.
1.	The boiling point of liquid oxygen is -297°F.
·2.	One liter is slightly more than one quart.
<u></u> 3.	Liquid oxygen will not expand very much.
.4.	At -361°F liquid oxygen will become a solid.
5.	The expansion ratio of liquid oxygen is 860 to 1.
6.	At a temperature above -297°F the liquid becomes a gas.
7.	The most important thing about liquid oxygen is its expansion capability.

From the previous lesson you know that oxygen is a gas that can be changed to a liquid. The first LOX was obtained by Sir James Dewar (a Scottish scientist) in 1886 and was recently adopted for use in aircraft. LOX is made by taking all the carbon dioxide, water, and other impurities from the air. The pure air is then compressed and the heat given off by the compression is taken out through several stages. The highly compressed cold air is then brought through a coil that is submerged in a cooling agent for more cooling. The air is then passed through an expansion valve that will drop the pressure from 3000 psi to 75 psi and the air will turn into a liquid (see illustration below).



- 1. Before being liquified the carbon dioxide, water, and other impurities must be removed from the air.
 - 2. Oxygen in its normal state is a gas.
- 3. Liquid oxygen is obtained by the compression and expansion of air.
- 4. Liquid oxygen has been used in aircraft since 1886.
- 5. Highly compressed hot air is brought through a coil that is submerged in a cooling agent.




274/

Answers to Frame 4: 1. Frame 5 We said gaseous exygen was colorless, odorless and tasteless. Oxygen in a liquid state has a pale blue color when exposed to the atmosphere. In other words if you drained some out of the storage tank into a bucket it would be a pale blue color. When LOX is exposed to the atmosphere it will evaporate very fast, and if it is spilled on the ground or floor it will form into small "balls" like water on a waxed surface. Be sure not to step on these balls of liquid. If any oil or grease is mixed with the liquid the shock may cause an explosion. Check the following statements that are true. Liquid oxygen is pale blue in color when exposed to the atmosphere. At atmospheric temperature liquid oxygen emporates very 2. rapidly. When spilled, liquid oxygen boils off slowly. 3. Liquid oxygen f into small balls like water on a waxed surface.

If you ster on spilled liquid oxygen an explosion may occur.

Oxygen can be kept in a liquid state at atmospheric pressure by keeping its temperature at or below -297°F. There are special containers that have been made to store the LOX (see illustration below). In these containers the oxygen will be able to stay in a liquid state without applying any pressure. By increasing the pressure on the LOX it can be kept at higher temperatures until its critical temperature is reached. The critical temperature of LOX is -182°F and no matter how much more pressure is placed on it, oxygen will not stay in a liquid state above this temperature. The storage containers have vents to the atmosphere because when there is no pressure applied to the LOX, a certain amount of the liquid is going to boil off. To try to hold in the expanding gas is not too practical.



Check the following statements that are true.

1. By applying pressure to liquid oxygen, it can be kept at a higher temporature.

2. Pressure will not have any effect on the oxygen boil off.

3. When liquid oxygen is stored without being under pressure, the containers must be vented.

4. The critical temperature of liquid oxygen is -182°F.


5. Using special containers, oxygen can be kept in a liquid state without applying pressure.

2743

Answers to Frame 6: $\sqrt{1}$. 2. $\sqrt{3}$. $\sqrt{4}$. $\sqrt{5}$.

Frame 7

There are two LOX containers you will be most concerned with. They are the ones used to store LOX on an aircraft and the cart that is used to service the aircraft with LOX. The sketch that is shown below is a typical container that is used on the aircraft. The container by itself is called a LOX converter (sometimes it is referred to as a Dewar Flask), and with the valves and other parts put on it, it is called a converter assembly. The converter is made like a thermos bottle, you could say its a tank within a tank. The liquid is stored in the inner tank and a vacuum between the two walls will prevent a rapid boil off until the liquid has had a chance to cool the metal down to its own temperature. There are various size LOX converters that are ave lable, and they are all measured in liters.




- _____l. The ontainer used on an aircraft to store liquid oxygen is called a converter.
- 2. The converter does not require any insulation from outside heat.
- _____3. A converter is double walled and vacuum insulated.
- 4. Converter capacity is measured in liters.



Answers to Frame 7: $\sqrt{1}$. 2. $\sqrt{3}$. $\sqrt{4}$.

Frame 8

As we have said before, the LOX converter is a double-walled vacuum insulated container. The capacity of a converter is measured in liters. The size and number of converters that are required on an aircraft is determined by the number of personnel who will need oxygen, and the type of mission that the aircraft is on. LOX converters are made in such a way that they will allow a "head space" for the gas to form once the converter is full of LOX (see the sketch shown). A converger is full when the LOX flows overboard through the vent line. Once the converter is full the gas on top is used to force the LOX out of the bottom where it turns into a gas and flows to the regulators for use.



1. Converters are designed to be filled completely.

2. The size and number of converters used on a particular aircraft is determined by the number of personnel who require oxygen and the aircraft mission.

3. A converter is full when liquid oxygen flows overboard.

4. The gas on top of the converter is used to force the liquid out the bottom.

5. A head space for gas remains on the top of the converter when it is full.


10

-126

Answers to Frame 8: $1. \sqrt{2}. \sqrt{3}. \sqrt{4}. \sqrt{5}.$

Frame 9

Other than the aircraft LOX converter, you will be concerned with the MA-1 LOX storage cart or trailer (see the picture below). This cart, which has four wheels and a 50-callon LOX storage tank mounted to it, is used to service the aircraft LOX converter. This cart is only one of the units used to service the aircraft with LOX.




- 1. The MA-1 storage cart is used to service the aircraft converter.
- 2. The MA-1 cart has a capacity of 50 gallons.
- _____3. The capacity of the MA-1 servicing cart is measured in liters.

Answers to Frame 9: $\sqrt{1}$. $\sqrt{2}$. 3

Frame 10

The safety precautions you learned and used on gaseous oxygen will also apply to LOX. However, the expansion ratio, which is 860 to 1, and the temperature of the LOX (-297°F) is such that more precautions must be used. Anything that LOX comes in contact with will freeze immediately, this includes your skin. Look at the airman in this sketch that is servicing a LOX converter with the MA-1 servicing cart. He is in for big trouble, because lines and fittings are very cold when LOX is flowing through them. It is very important that you don't touch the servicing hose or the fittings with your bare hands. Protective clothing should be worn at all times while handling LOX.



bore hands.

Check	the	following	statement(s)	that	are	true.
-------	-----	-----------	--------------	------	-----	-------

- 1. Anything that liquid oxygen touches becomes frozen.
- 2. Liquid oxygen will not harm your skin.
- 3. Protective gloves should be worn when handling tubing that has liquid oxygen flowing through it.
- 4. Because liquid oxygen is extremely cold more safety precautions are required than with gaseous oxygen.

Answers to Frame 10: $\sqrt{1}$. $2 \cdot \sqrt{3}$. $\sqrt{4}$

Frame 11

The airms, in this picture is wearing the right protective clothing. The protective clothing that you will need are a plastic face shield, neoprene (rubber) apron, and a pair of nonabsorbant gloves. These items should be worn anytimy you use LOX or there is a chance that you might have some LOX spilled on you.



1.	Gloves,	apron,	and	face	shield	should	bе	worn	when	transferring
	liquid	oxygen.				~				

- 2. Oxygen converters normally should be empty when removed.
- 3. No special clothing is required when handling liquid oxygen.

Because of the characteristics of LOX, it should not be confined. A small amount of LOX will boil off all the time and form a gas. If the gas is confined, a pressure will build up and cause an explosio If you should spill some LOX on your skin, a severe burn or frostbi. will occur. If this happens wash the skin with water and see a doctor as soon as possible. The oxygen area should be kept clean at all times and smoking is not allowed in this area at any time. Note the airmen in this sketch are breaking all of these safety rules.




- 1. Liquid oxygen should not be confined in a container.
- 2. No smoking is allowed in an oxygen area.
- 3. If liquid oxygen spills on your skin, flush with water and see a doctor immediately.
- 4. The oxygen area should be kept clean at all times.

Answers to Frame 12: $\sqrt{1}$. $\sqrt{2}$. $\sqrt{3}$. $\sqrt{4}$.

Frame 13

If LOX is spilled on your clothing you should take it off as soon as possible. About 30 minutes should be allowed for the oxygen to . evaporate from the material. A serious fire hazard will exist as long as your clothing is saturated with oxygen. All petroleum base products should be kept away from omygen. An explosion may occur if LOX and items such as oil or grease are mixed and subjected to pressure. It is wise to keep petroleum products at least 50 feet away from oxygen. If LOX is spilled on your skin, it should be washed off with water immediately. This will reduce the chance of frostbite and a possible fire hazard.



If liquid paymen is spilled on clothing, brush off immediately, remove clothing, and dry for approximately 30 minutes.



Keep all petroleum products (oil, grease, fuel, etc) away from oxygen equipment.

Make sure that body, clothing, and protective equipment are ciean and free of petroleum products (hair oil is a petroleum product) before performing maintenance on oxygen system.

Check	the	following	statement(s)	that	are	true.
-------	-----	-----------	--------------	------	-----	-------

1.	011	and	grease	should	be	kept	at	least	50	ieet	aw ay	irom	oxygen.


- 2. It takes about 30 minutes for oxygen to evaporate from your clothing.
- 3. Oxygen and petroleum products mixed can cause an explosion.
- 4. Liquid oxygen is removed from the skin with water.
- 5. Frostbite can occur if liquid oxygen is spilled on your skin.

2750

Answers to Frame 13: $\sqrt{1}$. $\sqrt{2}$. $\sqrt{3}$, $\sqrt{4}$.

Frame 14

It is not the desire or intent that these precautions should scare you, but the handling of LOX can be dangerous. We think of an automobile as a useful and pleasurable necessity, but we also know it can be very dangerous when handled improperly. The same is true of LOX. NOW WHAT YOU ARE DOING AND DO IT RIGHT.



END OF TEXT

Technical Training

Aircraft Environmental Systems Mechanic

AIRCRAFT LIQUID OXYGEN SYSTEM BASIC SYSTEM WITH SINGLE FUNCTION VALVES

16 November 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE

DO NOT USE ON THE JOB

FOREWORD

This programmed text was prepared for use in the 3AER42331 instructional system. The material contained herein has been validated using 38 42010 students enrolled in the 3AER42331 course. Ninety percent of the students taking this text surpassed the criterion called for in the approved lesson objective. The average student required 43 minutes to complete the text.

OBJECTIVE

Relate four of five basic liquid oxygen system components to their purpose.

INSTRUCTIONS

As you read and study each frame in this programmed text, locate in the classroom the particular component or system you are reading about. Each individual part and a complete system on a trainer will be available for you to see and inspect. Also, after each frame you will find a number of statements and you are asked to select the <u>true</u> statement or statements from this list. Read the material carefully before making a selection. If you select the correct answers, continue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before continuing. The answers to the statements can be found on the top of the next page.

Supersedes 3ABR42331-PT-314A, 19 February 1970.


OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG)TTGU-P - 500; TTVSA - 1

2 . 134

ERIC Full Text Provided by ERIC


Shown below is a basic liquid oxygen system. It consists of a converter assembly (B) which includes everything inside the dashed lines, a filler valve (H), a buildup and vent valve (F), contents gage (E), oxygen regulator (G), and the tubing and fittings required to connect these components together. This basic system has single function valves (valves that have only one purpose). In other systems we have dual function or combination valves that serve more than one purpose. All of these components will be discussed one at a time in this text and will be available in the classroom for you to see and inspect. Review the schematic shown and identify all the components.



Aircraft Liquid Oxygen System (Single Function Valves).

No Response Required

The liquid oxygen converter assembly is the heart of the liquid oxygen system. This is a multi-function unit that is designed to receive and store the liquid, pressurize the liquid, convert the liquid to a gas (or allows it to be converted), and supply the gas at a constant pressure to the oxygen regulators. Once the liquid container is filled and the system is placed in operation, the conversion from liquid to gas is automatic as long as the gas is being used and as long as the liquid lasts.




Five Liter Converter Assembly.

- 1. The converter assembly stores, pressurizes and converts the liquid to gas.
- 2. The converter assembly is the heart of the liquid oxygen system.
- 3. The converter assembly operates automatically once its filled and the system is placed in operation.

3. ✓

Frame 3


The largest part of the converter assembly is the liquid container. This is a double walled, vacuum insulated unit similar to the common "Thermos" bottle. It is also known as a "Dewar" flask after its inventor. As shown below, the liquid is stored in the inner shell and a vacuum separates it from the outer shell. The outer shell has a rupture disc that will blow out to prevent an explosion if the inner shell develops a leak. The rupture disc will blow at 30 psi. Liquid containers vary in size from " to 75 liters caps-ity.



1.	The	container	1 -	double.	walled	and	vacuum	insulated.
		•						

- 2. The rup, we disc will blow at 30 psi
- 3. Containers range in size from 5 to 75 liters capacity.
- 4. Liquid oxygen is stored in the vacuum area of the container.
- 5. The largest part of the converter assembly is the liquid container.

The plessure closing valve acts as the pressure regulator for the liquid oxygen system. It will either be proset at 70 psi or 300 psi depending upon the type of system the aircraft requires. The main purpose of the high pressure (300 psi) is to allow trew members to fill walkaround bottles from the aircraft system. This means that directaft like the B-52 and KC-135 would have a high-pressure system.




Pressure Closing Valve

1	The pressure closing valve acts as a pressure regulator.
2.	Fighter aircraft would require a high-pressure liquid oxygen
	system.
3.	The pressure closing valve is set at 70 or 300 psi.
4.	The main reason for having a high-pressure liquid oxygen is to
	fill walk-around bottles.
5.	Th 1 low-pressure liquid oxygen system operates at 70 psi.



Because the pressure closing valve is going to act as the pressure regulator for the systim, its primary purpose is to maintain a constant head pressure on top of the liquid in the storage container. The head pressure (gas) is used to push the liquid out the bottom of the container and into the evaporator coil where it is converted to a gas. The bellows in the pressure closing valve (see illustration) will sense the head pressure and open the valve if pressure drops below the valve setting (70 or 300 psi). When the valve opens, gaseous oxygen is transferred from the evaporation side of the system to the build-up side no maintain head pressure. The pressure closing valve is part of the converter assembly.



- 1. The pressure closing valve maintains a constant head pressure.
 - 2. The pressure closing valve is part of the converter assembly.
- 3. The pressure closing valve acts as the system pressure regulator.
- 4. The head pressure (gas) pushes the liquid out of the container.

 5. The pressure closing valve transfers liquid oxygen in the system.


Answers to Frame 5. 1. / 2. / 3. / 4. / 5.

Frame 6

In our basic oxygen system we have two (2) relief valves. One valve is in the <u>build-up side</u> of the system and relieves excessive head pressure from t's container. This valve is set to open at 90 psi in the 70 psi system and 345 psi in the 300 psi system.

The second relief valve is in the evaporation side of the system (or distribution side) and protects it from excessive pressure. This valve is set to open at 110 psi in a 70 psi system and 395 psi in the 300 psi system.

Both of the relief valves are screwed into the pressure closing valve, one on each side. The relief v 'ves are also part of the converter assembly.




1.	The	relief	valve	in	the	build-up	side	relieves	excessive	head
	pre	saure.								
	 -									

- 2. The 110 psi relief valve is in the build-up side.
- 3. The relief valves are screwed into the pressure closing valve.
- 4. The evaporation side contains the 110 psi relief valve.
- 5. The 345 and 395 psi relief valves are found in the 300 psi system.

Frame 7

The liquid check valve is especially designed to operate in a liquid oxygen system. From its position in the system it will accomplish two things:

- It separates the <u>liquid phase</u> of operation from the <u>gaseous phase</u>.
 It prevents a <u>reverse flow</u> of gaseous oxygen (from the gaseous phase)
- back through the liquid container. During normal operation of the system, the liquid check valve allows liquid to be drawn from the bottom of the container into the evaporation coils in the direction of the arrow. As pressure in the build-up and evaporation sides change because of use or liquid boil-off, the check valve will open and close at 5 psi below the container head pressure. This creates a 5 psi differential between the gaseous phase and liquid phase. When we discuss overall system operation, the function of the valve will become more clear.



1.	The check valve operation.	separates	the liquid	and gaseous	phase of	system
	- •					,


- 2. The liquid check valve is especially designed for liquid oxygen systems.
- 3. The check valve opens or closes at 5 psi below container head pressure.
- 4. When the check valve closes, it prevents reverse flow.



Answers to Frame 7. 1. ✓ 2. ✓ 3. ✓ 4. ✓

Frame 8

The evaporating coil is made of aluminum alloy and mounted surrounding the liquid oxygen container. This coil presents a large surface area which allows the liquid oxygen to evaporate and turn into a gas. Keep in mind, though, that all converters do not have such a coil. When converters are used in large aircraft where the tubing runs are comparatively long, the evaporator coil is not necessary. The long tubing runs provide the necessary heat-exchanging tubing surface area for evaporation of the liquid oxygen. Note the converter assembly shown on the right below does not have an evaporating coil. In the complete oxygen system, the regulators are connected to the other end of the evaporating coil.



Check the following statements that are true.

1. The liquid changes to a gas in the evaporating coil.


2. The evaporation coil can be part of the converter assembly.

3. The oxygen regulator is part of the converter assembly.

4. The evaporation tubing allows the gaseous oxygen to heat up.

5. In large aircraft, an evaporator coil is not always necessary.

The filler valve (shown below) is provided for the purpose of filling the system with liquid oxygen. The filler valve is basically a spring loaded check valve assembly with a protective (dust) cap. This valve is also designed for a quick-disconnect coupling with the recharging hose nozzle. When the dust cap is removed from the supply inlet, the supply source (recharging hose) is connected by pushing the nozzle on the valve and making a half-turn. The nozzle on the servicing hose pushes in the stud on the filler valve and unseats the spring loaded check valve and liquid flows in. When the servicing hose is removed, the spring reseats the valve. If an aircraft has more than one converter, each converter will have its own filler valve.




_	_	_			_		_	_	
1.	The	dust	cap	prevents	the	filler	valve	from	leaking.

- 2. One filler valve is needed for each converter.
- 3. The filler valve is basically a spring loaded check valve.
- 4. The filler valve is designed for a quick-disconnect with the servicing hose nozzle.
- 5. When filling the system, the servicing hoze nozzle reseats the check valve.

Answers to Frame 9. 1. ____ 2. __ ✓ 3. __ ✓ 4. __ ✓ 5. __ ✓


Frame 10

The build-up and vent valve (shown below) is a manually operated, two-way rc ary valve. When the handle is turned to the "VENT" position, the top of the converter is vented to the atmosphere. In this position, the gas port (from the top of the converter) is now open to the vent port and the build-up port is closed. When the handle is rotated to the "BUILD-UP" position, the gas port is open to the build-up port and the overboard vent port is closed. As with the filler valve, the name of this valve states its purpose; it allows the converter head pressure to "build-up" or be "vented" overboard.




- 1. The build-up and vent valve is a manually operated valve.
- 2. In "vent," the system will not contain any pressure.
- 3. In "build-up," converter head pressure is trapped and system pressure will rise.

On the aircraft, the filler valve and build-up and vent valve are located side by side as shown below. When the build-up and vent valve is in "BUILD-UP," the control handle covers the filler valve dust cap and it cannot be removed. This insures that the servicing hose will not be connected with pressure in the system. When servicing the converter, the valve must be in "VENT" as shown on the right. On the other hand, the valve sust be in "BUILD-UP" for the pilot to receive oxygen. To insure the valve is in build-up before the aircraft takes-off, the access door (filler well door) is designed so it cannot be closed when the valve handle is in "VENT."



LIQUID OXYGEN IS DANGEROUS. OBSERVE ALL SAFETY PRECAUTIONS WHILE FILLING SYSTEM.




1.	In o	rder	to	connect	the	servicing	hose,	the	valve	must	be	in
	·"VEN	T."		•			·					

- When the aircraft is flying, the valve must be in "VENT."
- When the valve is in build-up, the filler valve dust cap cannot be removed.
- With the valve in the "vant" position, the access door cannot

to Frame 11. 1.

Frame 12

The tubing (plumbing) used in the liquid oxygen system is aluminum alloy. Also, all of this aluminum tubing will be No. 5 (5/16) except in the following places: 1. The line from the filler valve (H) to the liquid container (A) is No. 6 (3/8). This is the filler line (see below). 2. The line from the build-up and vent valve (F) to the overboard drain is No. 8 (1/2). This is the vent drain line. 3. The size and length of the evaporating coil tubing (J) depends upon the size and type of converter assembly (B) that is being used.




- A. CONTAINER
- S. CONVERTER ASSEMBLY
- C. PRESSURE-CLOSING VALVE
- D. 110-PSI OR 395-PSI RELIEF VALVE
- E. CONTENTS GAGE
- F BUILDUP AND YENT VALVE

- G. OXYGEN REGULATOR
- H. FILLER VALVE
- L CHECK VALVE
- J. EVAPORATING COIL
- K. 90-PSI OR 345-PSI RELIEF VALVE

Check the following statements that are true.

- The filler valve is connected to the container with No. 6 tubing.
- Aluminum tubing is used in the liquid oxygen system. 2.
 - The vent drain line is No. 8 tubing. 3.
 - Most of the liquid oxygen tubing is No. 5.
- The evaporating coil is always No. 5 tubing.

Shown below is a typical converter assembly installation. This assembly has the same single function valves we have been discussing. Keep in mind the build-up and vent valve and filler valve are not shown because in this system they are not part of the converter assembly.



Review the illustration above and recall previously taught materi 'to write in the components described in each statement.


τo	write in the components described in each statement.
1.	This valve acts as the system pressure regulator.
2.	This valve separates the liquid and gaseous phase of operation.
3.	The liquid changes to a gas in this tubing.
4.	This relief valve protects the build-up side of the system psi.
5.	This unit is vacuum insulated and holis the liquid.
6.	The servicing trailer hose is connected to this valve.
7.	This valve allows system pressure to build-up or be vented overboard.
8.	This relief valve protects the evaporation side of the system psi.
9.	In the illustration, the pressure closing valve would be set at psi.

- Answers to Frame 13. 1. Pressure closing valve. 5. Liquid container.
 - 2. Liquid check valve.
 - 3. Evaporation coil.
 - 4. 90 psi.

- 6. Filler valve.
- 7. Build-up & vent valve.
- 8. 110 psi
- 9. 70 psi

Refer to the illustration on the next page as you read the material in this frame. In the illustration, we show the flow of liquid and gaseous oxygen with bubbles and slashes in the lines while the system is being filled. Remember the build-up and vent valve has to be in "vent" to remove the filler (valve dust cap. Note that with the build-up and vent valve in "vent," the top of the liquid container is vented overboard. Note also the pressure closing valve is "open" and the system contains no pressure. When the system is in "vent," the pressure closing valve is isolated from the top of the container. The pressure loss causes the bellows in the pressure closing valve to expand and open the valve. When the recharging trailer hose is connected to the filler valve, the operator allows 20 to 30 psi head pressure to build-up on top of the liquid in the recharging trailer. This pressure forces liquid into the converter container from the bottom. The container is full when a steady flow of liquid comes out the overboard vent.

Check the following statements that are true. When the system is in "vent," the top of the container is vented overboard. The pressure closing valve will open when pressure drops around the bellows. The converter container is full when liquid comes out the 3. overboard vent. The system still contains 70 psi when placed in "vent." Pressure in the recharging trailer forces liquid into the 5. converter containsr. When placed in "vent," any pressure in the system is vented 6. overboard.



No Response Required.


17

Refer to the illustration on the next page when you read the material in this frame. When the liquid container is full, the build-up and vent valve is mo ed back to the "build-up" position as shown in the illustration. With the system closed, pressure will now start to rise. If you recall, we said previously that the liquid check valve opens to let liquid into the evaporating coil and closes to prevent reverse flow. Also remember the pressure closing valve is open until its bellows senses a 70 psi head pressure (in the low pressure system) on top of the liquid in the container. Note in the illustration that the pressure closing valve is again connected to the top of the container through the build-up and vent valve. Now, when the liquid changes to a gas in the evaporating coil, it goes up through the open pressure closing valve and builds up head pressure on top of the liquid. When 70 psi is reached, the pressure closing valve closes. When this happens, the liquid left in the evaporating coil is still changing to a gas and building pressure in this side of the system. This pressure will soon close the liquid check valve (5 psi differential is required) and the system will stabilize. As gaseous oxygen is used through the regulator, a pressure drop allows the liquid check valve to open and more liquid enters the evaporating coil. As the liquid level decreases in the container, the head pressure decreases also. This will cause the pressure closing valve to open again and allow the evaporation side to build up head pressure. There is little or no lag in maintaining the required head pressure; and for all practical purposes, oxygen is delivered to the regulator at a constant pressure of 70 or 300 psi depending upon the pressure closing valve setting.

Check the following statements that are true.

1.	The bellows in the pressure closing valve senses the container head pressure.
2.	In a 70 psi system, the pressure c^{-1} osing valve remains open until 70 psi is reached.
3.	The excessive pressure builds up in the evaporator coils, the 90 psi R. V. will open.
4.	The liquid check valve prevents reverse flow between the gaseous and liquid phase of the system.
5.	When pressure in the evaporation side is lower than the head pressure on the container, the liquid check valve will open.

13



No Response Required




Frame 18

Refer to the illustration on the next page when you read this material. In this illustration we have a separate build-up coil in our basic oxygen system. This is a short coil of rubing that changes the liquid to a gas for the sole purpose of maintaining a head pressure on top of the liquid in the container. Note that this coil of tubing runs directly from the bottom of the container to the bottom of the pressure closing valve. When a separate buildup coil is used, the evaporator toil no longer has to supply gaseous oxygen for a head pressure and more oxygen is available of the oxygen regulator for breathing. This additional circuit in no way affects the operation of the pressure closing valve. The bellows in top of the pressure closing valve still senses the head pressure through the build-up and vent valve. If the head pressure drops below 70 psi (or 300 in the high-pressure system), the pressure closing valve bellows and expands and unsemts the valve. The buildup coil will not rebuild the head pressure. The build-up coil is usually around the liquid container and becomes part of the converter assembly.

Check the following statements th : are true

<u></u> .	The build-up coil provides gaseous oxygen for maintaining a head pressure.
2.	The build-up coil provides gaseous oxygen for the oxygen regulator.
3.	The build-up coil is part of the converter assembly.
4.	When a build-up coil is used, the evaporator coils supply gaseous oxygen fo 'reathing purposes only.
5.	The pressure closg valve operates the same way when a build-up coil is used.






No Response Required



Frame 20

INSTRUCTIONS

Identify the units in the oxygen system by matching the letters with the unit's name below.



1.	liquid	container.

- 2. ____ converter assembly.
- 3. ____ pressure closing valve.
- 4. ____ 110 or 395 psi relief valve.
- 5. ____ contents gage.
- 6. ____ build-up and vent valve.

- 7. ____ oxygen regulator.
- 8. ____ oxygen filler valve.
- 9. ____ liquid check valve.
- 10. ____ evaporator coils.
- 11. ____ 90 or 3. _i relief valve.



Answers to Frame 20

1.	C
2.	H
3.	G

5. <u>E</u>
6. <u>J</u>

9. <u>1</u> 10. <u>F</u> 11. <u>D</u>

Frame 21

This completes our discussion on the basic liquid oxygen system. If you have any questions about the operation or components in this system, let your instructor know.



Remember Your Liquid Oxygen Safety.



3ABR42331-PT-402B

Technical Training

Aircraft Environmental Systems Mechanic

AIRCRAFT LIQUID OXYGEN SYSTEM ADVANCED DESIGN WITH DUAL FUNCTION VALVES

20 November 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

Designed for ATC Course Use.

Do Not Use on the Job.



FOREWORD

This programmed text was prepared for use in the 3ABR42331 instructional system. The material contained herein has been validated using 3C students enrolled in the 3ABR42331 course. Ninety percent of the students taking this text surpassed the cri.erion called for in the approved lesson objective. The average student required (58) minutes to complete the text.

OBJECTIVES

After completing this programmed text, you will be able to:

1. Relate four (4) of five (5) advance liquid oxygen system components with their purpose.

INSTRUCTIONS

As you read and study each frame in this programmed text, locate the individual component or system being discussed in the classroom or lab. A better understanding of the system will result if you look at and inspect these units as you read about them. Check with your instructor if these components are not available.

If you are asked to select the true statement or statements from this list. Read the material carefully before making a selection. If you select the correct answer(s) continue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before continuing. Check with your instructor if you have any problems.

Supersedes 3ABR42231-PT-314B, 18 February 1970.

OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/T~GU-P - 600; TTVSA - 1




2





In this text we will discuss a typical liquid oxygen system that has dual function valves. Shown below is a converter assembly used in the F-4 fighter aircraft. There are several converters that can be used in the F-4 and two of these will be discussed. Since you are already familiar with the components in the basic oxygen system, we will be concerned only with the units that are different in this system and the system operation. We will be concerned mainly with the fill, build-up, and vent valve (1), and the pressure opening-pressure closing valve which is not visible in the illustration below. This converter assembly is equipped with quick disconnects to allow for quick installation and removal. Review the components shown and locate the actual converter assembly in the classroom.

- Fill, Build-up, and Vent Valve.
- 2. Converter Vent Quick Disconnect.
- 3. Liquid Container.
- Carrying Handle.
- 5. Converter Supply Quick Disconnect.
- 6. Container Relief Valve.
- 7. Probe Lead Connectors.



1F-4C Liquid Oxygen .. Converter Assembly

No Response Required.






Answers to Frame 1: No Response Required

Frame 2

The combination fill, build-up, and vent valve is shown below. Here we have the filler valve as part of the build-up and vent valve instead of two separate valves. As shown in the schematic on the left, the <u>normal</u> position of this valve is in <u>build-up</u>. In this position, the gas port (from the top of the container) is open to the build-up port. The build-up port is connected to the pressure opening-pressure closing valve. The "fill out" port on the valve is connected to the bottom of the container. The ball check valve in this port prevents a reverse flow of liquid out through the valve. A protective dust cap attached to a chain is used on the filler port of this valve the same as on the separate filler valve.



Shown in Build-up.


Filler, Build-up, and Vent Valve

- 1. The normal position of the fill, build-up, and vent valve is "build-up."
- 2. The ball check valve in the "fill out" port prevents a reverse flow of liquid oxygen out of the valve.
- 3. The gas port is connected to the bottom of the container.
- 4. A dust cap is used on the filler port of the combination fill, buili-up, and vent valve.

Answers to Frame 2: 1. T 2. T 3. 4. T

Frame 3

When the filler nozzle from the liquid oxygen servicing trailer is connected to the fill, build-up, and vent valve, it wil? be in the position shown below. A pin in the filler nozzle pushes the valve shaft forward and closes the build-up port. At the same time, the gas port is opened to the overboard vent and system pressure is discharged overboard. When the liquid flows in under pressure, it unseats the ball check valve in the "fill out" port and goes into the container. When the filler nozzle is removed, the ball check valve reseats, the valve shaft moves out and automatically returns the system to "build-up."




Shown in Fill & Vent. Combination Fill, Build-up, and Vent Valve. Select the following statement(s) that is/are true. 1. When the filler nozzle is connected, system pressure is venered overboard. 2. The normal position of the fill, build-up, and vent valve is "vent." When the filler nozzle is removed, the valve returns to "build-up." 3. 4. When servicing the system, the incoming liquid unseats the ball check valve in the "fill out" port. When the filler nozzle is connected, the valve automatically moves f m build-up to vent.

Answers to Frame 3. 1. <u>T</u> 2. <u>3. T</u> 4. T 5. T

Frame 4

You already know the pressure closing (PC) valve regulates system pressure by controlling the container "head pressure." In this particular F-4 system we have a combination pressure opening pressure closing valve. The primary purpose of the pressure opening (PO) valve is to conserve gaseous oxygen that is normally vented overboard by the relief valve. The pressure opening valve is used only in low pressure (70 psi) liquid systems. As shown below, both of these valves are bellows operated pressure regulating valves contained in one housing. The pressure closing (PC) portion of this valve is normally open and closes at 72 psi. The pressure opening (PO) portion of this valve is normally closed and opens at 82 psi. When the pressure opening valve opens at 82 psi, gaseous oxygen is drawn directly from the top of the container for breathing. This valve is part of the converter assembly.



Select the following statement(s) that is/are true.

systems.


1.	The pressure opening-pressure closing valves are bellows operated
2.	The pressure closing valve regulates system phassure at 72 psi.
	The pressure opening valve opens at 82 psi.
4.	The pressure opening valve is normally open.
<u></u> 5.	When the pressure opening valve opens, gaseous oxygen is taken
-	from the top of the container
6.	The pressure opening-pressure closing valve is part of the
	converter assembly.
7.	The purpose of the pressure opening valve is to conserve gaseous
	oxygea.
Q	A nressure opening value is used only on low pressure liquid #



Answers to Frame 4: 1. \underline{T} 2. \underline{T} 3. \underline{T} 4. \underline{T} 5. \underline{T} 6. \underline{T} 7. \underline{T} 8. \underline{T}

Frame 5

The liquid check valve separates the liquid and gaseous phase of operation and prevents a reverse flow. This valve allows liquid to be drawn into the main supply line during normal operating conditions. When operating pressures are excessive, and the pressure opening valve is open, the spring in this check valve creates a 5 psi differential between the gaseous and liquid phase as gaseous oxygen is being drawn off the top of the container. This will close the check valve when the pressure opening valve is open. When we discuss overall system operation, the function of this valve will become clear.




1.	· The	liquid	check	valve	prevents	reverse	flow.
----	-------	--------	-------	-------	----------	---------	-------

- 2. This valve separates the liquid and gaseous phase of operation.
- 3. During normal operating conditions, liquid flows through the check valve into the main supply line.
- 4. When the pressure opening valve is open, the liquid check valve is closed.

Answers to Frame 5: 1. T 2. T 3. T 4. T

Frame 6

Let's take a look at a schematic of the complete converter-assembly. Locate the fill, build-up, and vent valve, pressure opening-pressure closing valve, and liquid check valve that we discussed individually. The other units such as the liquid container, build-up coil, and relief valve, are already familiar to you. The capacitance probe inside the container is part of the quantity indicating system which will be covered later. In the schematic, the system is shown empty and the valves in their normal position. Note the converter assembly has only one relief valve which is set at 110 psi. This is the container relief valve.



F-4C Liquid Oxygen Converter Assembly (Dual Function Valves).

- 1. The normal position of the fill, build-up, and vent valve is "build-up."

 2. The pressure opening valve is normally closed and the pressure closing valve is open as shown.

 3. The container relief valve is set at 110 psi.

 4. The supply line and vent line are connected to the converter assembly with quick disconnects.


 5. The spring in the liquid check valve is holding it open.
- 6. The luild-up coil is connected to the inlet port of the pressure closing valve.

Answers to Frame 6: 1. $\frac{T}{T}$ 2. $\frac{T}{T}$ 3. $\frac{T}{T}$ 4. $\frac{T}{T}$ 5.

Frame 7

So far we have discussed the converter assembly and its components. Now let's look at the components of the oxygen system that are fixed to aircraft. The supply line relief valve is sot at 130 pai and relieves excessive pressure in the supply line and warm-up coil (or warm-up plate). When the converter assembly is removed at the quick disconnects, oxygen is trapped in the supply line and warm-up coil and pressures may become excessive if the temperature changes. The supply line relief valve takes care of this. Also, if the container relief valve fails, the supply line relief valve will take over.

The purpose of the <u>warm-up coil</u> or plate is to raise the temperature of the gaseous oxygen to where it is suitable for breathing. The coil is usually in the cockpit or electronics compartment. Heat in the area surrounding the coil is transferred to the gaseous oxygen as it passes through the coil on its way to the regulators.




- 1. The supply line relief valve is fixed to the aircraft and set at 130 psi.
- 2. As gaseous oxygen passes through the warm-up coil, its temperature rises.
- 3. If the container relief valve fails, the supply relief valve takes over.

7733
Answers to Frame 7: 1. T 2. T 3. T

Frame 8

Now let's take a look at the complete liquid oxygen system we have been discussing in parts. Remember that the supply line relief valve and warm-up coil remain in the aircraft when the converter assembly is removed at the vent line and supply line quick disconnects. The container relief valve stays with the converter assembly.



- 1. The container relief valve is part of the converter assembly.
 - 2. The supply line relief valve is part of the converter assembly.
- 3. One end of the build-up coil goes to the pressure closing valve.
- 4. The supply line relief valve has a higher setting than the container relief valve.
- 5. The rormal position of the fill, build-up, and vent valve is "build-up."



Answers to Frame 8: 1. <u>T</u> 2. <u>3. T</u> 4. T 5. T

Frame 9 (Review Frame)

Circle the letter that is in front of what you believe to be the correct response. Check your answers on the top of the next page.


- What prevents a reverse, flow of liquid oxygen out of the fill, build-up and vent valves when the filler nozzle is removed?
 - a. Supply line relief valve.
 - b. The fill check valve.
 - c. Container relief valve.
 - d. The liquid check valve.
- 2. When system pressure becomes excessive, which valve will open and allow gaseous oxygen to be drawn off the top of the container?
 - a. Fill, build-up and vent valve.
 - b. Pressure closing valve.
 - c. Container relief valve.
 - d. Pressure opening valve.
- 3. On the F-4C converter assembly, the pressure opening valve forms a combination with the
 - a. filler valve.
 - b. liquid check valve.
 - c. pressure closing valve.
 - d. build-up valve.
- 4. The F-4C converter assembly contains only the CONTAINER relief valve.
 - a. True
 - b. False
- 5. The pressure opening-pressure closing valve is ONLY used
 - a. on low pressure (70 psi) liquid oxygen systems.
 - b. when a build-up coil is used.
 - c. on high pressure (300 psi) liquid oxygen systems.
 - d. when no head pressure is required.
- 6. On the F-4C aircraft, the warm-up coil or plate is part of the converter assembly.
 - a. True
 - b. False



2785
Answers to Frame 9: 1. b 2. d 3 c 4. a 5. a 6. b

Frame 10

Now that you are familiar with the dual function valves used in this type of system, let's discuss the operation of this system. In order to fully understand what is taking place within the system, it is necessary to look at the system in four (4) different phases of operation. The first phase is FILLING and this is shown below. When the nozzle from the servicing trailer is connected to the fill, build-up and vent valve, the plunger in the valve is pushed in as shown. This closes the build-up line and provides an open line to the overboard vent. Any pressure in the system is now vented overboard. When the liquid oxygen enters the valve, it unseats the fill check valve and goes into the container through the bottom. When the container is full, ?! id flows out the top of the container, back through the valve and out the overboard vent. At this time, the nozzle from the servicing trailer is removed and this automatically places the system in the build-up phase.




1.	The	f111	check	valve	1s	unseated	when	filling	the	system.
		* * * * *	CHCCK	AGTAC	*0	diibeated	MITEIL	rrrring	LHE	system.

- _____2. The liquid check valve is closed when filling.
- _____3. When filling, the pressure closing valve is open (normal position).
- 4. When filling, liquid oxygen enters the warm up coil.
- _____5. System pressure is vented overboard when the filling nozzle is connected.



Once the transfer hose nozzle is removed, pressure begins to build up in the system. This pressure build-up continues until system pressure reaches 72 psi. The schematic below illustrates this pressure build-up phase. Note that liquid is boiling off in the build-up coil and returning to the top of the container through the pressure closing valve (which is open) and the fill, build-up and vent valve. The container is building up "head" pressure. During this phase, breathing oxygen is obtained from liquid oxygen drawn through the liquid check valve (shown open). This liquid will vaporize as it passes through the supply line and warm up coil on its way to the oxygen regulator.




- 1. When system pressure is below 72 psi the pressure closing valve is closed.
- 2. When the transfer hose nozzle is removed, the system returns to build-up.
- 3. During the build-up phase, the build-up coil is supplying gaseous oxygen which is returned to the top of the container.
- 4. During this phase, liquid oxygen is drawn through the liquid check valve and vaporized in the supply line and warm up coil.
- 5. During this phase, the container relief valve is open.



Answers to Frame 11: 1. ___ 2. _T 3. _T 4. _T 5.

Frame 12

In this phase of operation, breathing oxygen is obtained from gaseous oxygen drawn through the liquid check valve. In this condition the pressure closing valve is closed (closed at 72 psi) and the pressure opening valve is still closed (opens at 82 psi). With the pressure closing valve closed, pressure build-up in the system is stopped because the return path to the top of the container is blocked. The liquid trapped in the build-up coil now evaporates (shown evaporated) and causes a back flow of liquid to the container. This action is what enables gaseous oxygen to be drawn through the liquid check valve (see schematic). As the pressure is lowered by the caygen being used, the pressure closing valve will open and pressure will again build up.




1.	When system pressure	is between	72 and 82 psi,	the pressure closing
	and pressure opening	valves are	closed.	

- When the pressure closing valve closes, pressure build-up is halted.
- 3. The pressure closing valve is set to close at 52 psi.
- 4. When the pressure closing valve closes, liquid oxygen trapped in the build-up coil will evaporate and cause a back flow.
- 5. In this phase, gaseous oxygen for breathing is drawn through the liquid check valve.

Answers to Frame 12: 1. T 2. T 3. 4. T 5. T

Frane 13

In cases where the use of gaseous oxygen is below normal at the regulator (low demand), and repeated cycling of the system causes excessive pressure build-up, the pressure opening valve will open. The pressure opening valve will open at 82 psi as shown below. When this valve opens, gaseous oxygen for breathing is drawn from the top of the container through this valve and out to the warm up coil. The pressure opening valve remains open as long as normal evaporation in the container is adequate to maintain system pressure above 82 psi. With this valve open, a back pressure will close the liquid check valve as shown. This phase of operation continues until system pressure drops below 82 psi again. When the oxygen system is not being used at all, normal evaporation in the container will cause pressure to build up until it reaches the setting of the container relief valve (110 psi). This will vent excess pressure overboard.




1.	The pressure opening valve opens at 82 psi
2.	A low demand on the system causes pressure to build up.
3.	When the pressure opening valve is open, breathing oxygen is drawn from the top of the container.
4,	In this phase, the liquid check valve is open.
5.	If no oxygen is being used, pressure will rise to the relief valve setting.

2799
Answers to Frame 13: 1. T 2. T 3. T 4. 5. T

Frame 14

Let's take a look at another type of converter assembly found on the F-4C aircraft. As shown in the schematic, this assembly has a single unit pressure closing valve only. The fill, build-up, and vent valve used in this system has another component built in; this is the container relief valve. So now we have a combination fill, build-up, vent, and relief valve. Note also that this converter assembly does not have a liquid check valve. In operation, liquid oxygen will gravity feed into the build-up coil and change to a gas. This gas goes through the pressure closing valve and up to the top of the container. This pressure build-up continues until the pressure closing valve "closes" at 72 psi. As the "head pressure" on the top of the liquid increases, more liquid is forced out the bottom of the container and evaporates in the supply line and warm up coil on the aircraft. This converter assembly can be placed in the aircraft and connected at the same quick disconnects as the previous converter assembly we have discussed.



F-4C Liquid Oxygen System Schematic (Without Pressure Opening Valve)

Select the following statement(s) that is/are true.

1. In this type of converter assembly the container relief valve is part of the fill, build-up, and vent valve.

16

- 2. This unit does not have a liquid check valve.
- 3. Only a pressure closing valve is used in this converter assembly.

Answers to Frame 14: 1. T 2. T 3. T

Frame 15

Instructions: The facing page has a schematic of the liquid oxygen system we have been discussing. Use this page to do the following:

- Part 1. Identify the components in the system by placing the letters from the arrowed circles by the correct name of that component in the given list. Check your answers on the next page.
- Part 2. Draw the necessary valves open or closed (with a black pencil) to indicate the position they would take if the system pressure was above 82 psi. Now use a red pencil and trace in the liquid flow and a blue pencil to show gaseous oxygen flow. Check your tracing against the schematic for this phase of operation in the text.



1.____Vent Quick Disconnect.

2. Fill, Build-Up, and Vent Valve.

3.___fill Check Valve.

4. Liquid Container.


5.___Build-Up Coil.

6. Liquid Check Valve.

7 Pressure Opening-Pressure Closing Valve.

8. ___Container Relief Valve.

9.___Supply Quick Disconnect.



uswers to Frame 15: (Part 1) 1. \underline{E} 2. \underline{G} 3. \underline{D} 4. \underline{J} 5. \underline{C} 6. \underline{A} 7. \underline{H} 8. \underline{F} 9. \underline{I} 10. \underline{B} 11. \underline{K}

Technical Training

Aircraft Environmental Systems Mechanic

LIQUID OXYGEN QUANTITY INDICATING SYSTEMS

20 November 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Alr Force Base, Illinois

Designed for ATC Course Use.

Do Not Use on the Job.

FUREWORD

This programmed text was designed for use in-Course 3ABR42331. The material herein has been validated with 30 students from the subject course. All students achieved the objectives as stated. Average time for completion of the text was 35 minutes.

OBJECTIVES

After completion of this programmed text you will be able to:

1. Relate four (4) of five (5) liquid oxygen quantity indicating components with their purpose.

INSTRUCTIONS

Throughout this programmed text you will be required to respond to the information given. After making your response, check the correct answer at the top of the following page. If your response was incorrect review the frame to determine your error before proceeding to the next frame.

Supersedes 3ABR42731-PT-314C, 16 December 1970.


OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/TTGU-P - 600; TTVSA - 1.



All liquid oxygen systems have some types of quantity indicating system to let the pilot, or whoever is using the oxygen, know how much he has remaining in the liquid container. There are three (3) types of indicating systems used with liquid oxygen convertors: 1. The direct reading, differential-pressure contents gage (shown on right below).

2. The electrical-differential pressure contents gaging system. 3. The capacitance contents gaging system (shown on left). Regardless of the types of indicating system used, all the gages are read in liters of liquid oxygen. The total number of liters which the gage indicates (5-25-75, etc.) depends upon the size of the liquid container on the convertor assembly being used. The three indicating systems mentioned above will be discussed in this text.






LIQUID OXYGEN CONTENTS GAGE

Mark the following statements with a T for True or an F for False.

- __1. Quantity gages indicate in liters of liquid oxygen.
- 2. The three types of indicating systems used are the direct reading, electrical-differential pressure, and capacitance type system.
- 3. If the convertor assembly has a 5 liter container, the quantity indicator would read a total of 5 liters.
- 4. All liquid oxygen systems have a quantity indicating system of some type.

The first quantity indicating system we will discuse is the direct reading type shown below. It is referred to as "direct reading" because it is connected to the container with tubing and no electrical connections are required. As shown in the illustration, we have one line coming off the bottom of the container going to the liquid connection on the back of the unit. The line coming off the top of the container goes to the gas connection on the back of the unit. Note also the gas line to the build-up and vent valve is tapped off this line. This quantity gage is located in the cockpit usually next to the oxygen regulator.




Direct Reading, Differential-Pressure Contents Gage Installation.

Mark the following statements with a T for True or an F for False.

1.	The direct reading quantity gage is connected directly to the
	liquid container with tubing.

- 2. This gage has two connections; gas and liquid.
- 3. The direct reading contents gage operates by electricity.
- 4. The quantity gage is located in the cockpit.

The direct reading contents gage has two chambers separated by a diaphragm. Notice below that gas pressure from the top of the container is applied to one side of the diaphragm. On the opposite side of the diaphragm, we have the pressure on top of the liquid PLUS the weight of the liquid applied. The weight of the liquid then sets up the differential pressure. This differential pressure positions the diaphragm and through mechanical linkage, positions the indicator pointer. Note the connection on the back of the gage is labeled "liquid." However, oxygen in a liquid state does not reach the gage. Liquid leaves the container but changes to a gas as it travels through the tubing. The direct reading, differential pressure quantity indicating system is the most simple of the systems we will discuss. However, it's not often used because of the disadvantage of the long tubing runs from the container to the indicator.



Direct Reading Contents Gage Schematic.

Mark the following statements with a T for True or an F for False.


1.	The weight of the liquid determines the amount of differential
	pressure.
2.	Oxygen in a liquid state is applied to one side of the diaphragm.
3.	This type of system is not often used because of the long tubing runs.
4.	The pointer on the gage is positioned through mechanical linkage.
5.	The direct reading contents gage has two chambers separated by a

diaphragm.

Answers to Frame 3: 1. T 2. F 3. T 4. T 5. T

Frame 4

The next system we will discuss is the electrical differential pressure contents gaging system. This system is composed of two basic units, the transducer assembly and the quantity indicator. The transducer used in this system is shown below. Generally speaking, a transducer is any device that changes one type of gnal to another. In our case, we want to convert the pressure differential (as discussed in the direct reading system) to an electrical signal. The transducer shown will do this job. When the transducer converts the pressure signal to an electrical signal, it sends it to the indicator which provides a readcast in liters on its dial. The transducer is located on or near the convertor assembly and connects to the container with tubing at the GAS and LIQUID ports.



Transducer Assembly Schematic.


Mark the foll wing statements with a T for True or an F for False.

- 1. A transducer changes one type of signal to another.
- 2. In this system, the transducer changes the differential pressure signal to an electrical signal.
- 3. The indicator reads out the electrical signal in livers of oxygen.
- 4. The transducer is local d on the pilot's instrument panel.
- 5. The two major units in the electrical-pressure differential contents gaging system are the transducer and indicator.

Answers to Frame 4: 1. T 2. T 3. T 4. F 5. T

Frame 5

Let's take a look at a simplified schematic of the transducer and determine how the mechanical portion of this unit operates. The transducer (B) operates on the differential pressure created in the liquid container (A). Here we have gas pressure from the top of the lontainer acting on one side of the diaphragm (E), and gas pressure PLUS the weight of the liquid acting on the other (bottom) side of the diaphragm. The movement of the diaphragm (E) positions the contact arm (D) on the resistance strip (C). Note the contact arm (or wiper arm) is connected to the movable shaft which in turn is connected to the diaphragm. As the liquid level changes in the container, the differential pressure will change and lediaphragm varies the contact arm accordingly. The indicator, which is electrically connected to the resista le strip, will pick up this varying signal and move its indicating pointer.




- A. Liquid Container.
- B. Transducer Assy.
- C. Resistance Strip. E. Diaphragm.
- D. Contact Arm.
- F. Tubing.

Mark the following statements with a T for True or an F for False.

- 1. As the liquid level changes, the differential pressure will change.
- 2. The indicator is connected electrical y to the resistance strip.
- 3. The contact arm varies the resistance sent to the indicator.
- 4. The weight of the liquid determines the differential pressure.
- 5. The contact arm can move up or down the resistance strip.

Let's discuss the electrical circuit of the indicator and transducer as shown below. This type of liquid indicating system is sometimes referred to as a "Selsyn' system in technical publications. Selsyn is a trade name used by a particular manufacturer that makes this type of "three wire" liquid gaging circuit and simply means the system has self-synchronous instruments and they are DC operated. In operation, the wiper contact arm (A) in the transducer is positioned on the curved resistance strip (E) by movement of the transducer diaphragm. The current flow in each of the three coils (B-C-D) is determined by the position of the wiper contact arm and the applied voltage. The position of the rotor. (G) depends upon the proportion of current flowing in each coil. Note that with the wiper contact arm positioned as it is, a strong magnetic field exists around coil (B) in comparison to the other two coils. Therefore, the permanent magnet rotor (G) is pulled around to align itself with coil (B). The indicator pointer now gives a read-out in liters of liquid oxygen.




- A. Wiper Contact Arm.
- B. Differential Coil.
- C. Differential Coil.
- D. Differential Coil.

- E. Resistance Strip.
- F. Coil Connecti Wire.
- G. Permanent ,net Rotor.
- is the following statements with a T for True or an F for False.
- 1. When the wiper cc .ct arm moves, the current is varied in the differential coils.
- 2. DC voltage moves the wiper contact arm in the transducer.
- _____3. The rotor (G) is positioned by the properties of current flowin, in each coil.
- 4. Selsyn is a trade name for this type of three wire liquid pagine system.
- 5. This system contains self-synchronous, OC operated instruction

Frame 7

In order to obtain an accurate indication of the number of liters in the container at each end of the scale (full-empty), it's usually necessary that the transducer and indicator be a "matched set." That is, the transducer should be calibrated while connected to the indicator with which it is to be installed in the aircraft. The adjustments for the FULL and EMPTY arrows are accomplished by turning the adjustment screw on the transducer assembly as indicated below. When this screw is turned in one direction, resistance will be varied at R - or the EMPTY end of the resistance strip. When turned in the opposite direction, resistance is varied at R+ or the FUL end of the resistance strip. In other words, if you know the liquid container is completely empty, the resistance can be varied to make the indicator read empty.




INDICATOR

TRANSDUCER

1.	The indicator and transducer should be calibrated together for accuracy.
2.	When the adjustment screws are turned, resistance is varied at R- or R+.
3.	If the liquid container is full, the indicator should read emp-y.
4.	All adjustments are made on the transducer assembly.
5.	These units an be calibrated in the shop or on the aircraft.
6.	The transducer is connected to the liquid container with tubing.

Frame 8

The last quantity indicating system we will discuss is the capacitance type contents gaging system. This system is probably used more than both the other two systems we have discussed. This indicating system does not require tubing or diaphragms which add weight and cause maintenance problems. Simply stated, the capacitance probe side the liquid container (see below) acts as a variable capacitor as the liquid level changes. This varying signal is picked up by the capacitance gage (shown) which contains the indicating circuit.



Capacitance Type Contents Gaging System.

Mark the following statements with a T for True or an F for False.

- 1. The capacitance probe acts as a variable capacitor.
- 2. The probe is installed inside the liquid container.
- 7. This indicating system does not contain tubing or diaphragms.
- 4. As the liquid level change, the capacitance signal changes.
- 5. The indicating circuit is inside the capacitance probe.


153

2802

Answers to Frame 8: 1. T 2. T 3. T 4. T 5. F

™rame 9

If you recall from previous instruction, a capacitor consists of two conducting plates with an insulating material separating them. This insulating material is called the <u>dielectric</u>. Materials such as glass, air, mica, wax paper, and oil are commonly used as dielectrics. In this particular case, we are using liquid oxygen as the dielectric between the two plates of the probe as shown below. The amount of capacitance stored in the plates depends upon the plate area, distance between the plates, and the type of dielectric used. As the liquid level changes, we have a variable dielectric between plates of the probe. This generates a varying capacitance signal which is passe on to the indicating circuit




A. Container B. Plates C. Probe CAPACITANCE PROBE

- 1. The capacitance probe consists of two conducting plates.
- 2. The liquid oxygen is used as a dielectric.
- 3. The capacitance probe is installed in the container.
- 4. The insulating material used for all capacitors is oil.
- 5. As the liquid level changes, a varying capacitance signal is generated.

Frame 10

The capacitance indicating circuit is shown below. Keep in mind these components are miniaturized and contained inside the indicator or capacitance gage. The indicating circuit is primarily a capacitance bridge circuit in which the probe (L) in the container makes up one leg. In operation, the capacitance bridge measures probe (L) capacitance by comparing it to a known reference capacitor (B). When the bridge becomes unbalanced due to a liquid level change in the container, the induction motor (E) receives power and corrects the indicator pointer (C) by mechanical linkage (dotted lines). At the same time, the motor (E) corrects the balancing potentiometer (D). It will also close the low-level switch (G) and send power to the low-level light (F) if the pointer moves to the empty end of the scale. Identify all the components listed below the schematic.




Α. Full Adj. Potentiometer Low-level Switch G. B. Reference Capacitor H. Push-to-test Switch C. Indicator Pointer I. Empty Adj. Potentiometer Balancing Potentiometer D. J. Coaxial Cable E. Induction Motor Shielded Electrical Lead K. Low-level Light L. Capacitance Probe

CAPACITANCE INDICATING CIRCUIT

- 1. The capacitance indicating circuit is primarily a bridge circuit.
- _____2. The bridge ci cuit compares probe capacitance with a reference capacitor.
- 3. The indicator poin or is moved by mechanical linkage.
- 4. The prob. makes up one leg of the capacitance bridge.

Frame 11

Two of the items we did not discuss in the schematic in Frame 10 are the two adjustments that can be made on the indicator. The full adjustment potentiometer ("A" in the schematic) and the empty adjustment potentiometer ("I" in the schematic). These two potentiometers are connected at opposite ends of the transformer secondary winding shown in the schematic. They provide a means of adjusting the bridge voltages to balance over the empty-tofull capacitance range of the system. The adjustment screws are accessible at the back of the indicator as shown on the right below. The low-level warning light on the face of the indicator warns against complete exhaustion of the oxygen supply. The particular indicator shown below has a power failure "flag" in the lower center of the dial. The oxygen quantity push-totest switch shown below (located on the indicator panel) is used to check system operation. When the switch is pushed, the bridge is unbalanced and the motor drives the indicator pointer to "empty." When the switch is released, bridge balance is restored and the pointer returns to its original position. This response by the indicator proves that the system is operating normally.





LIQUID OXYGEN CAPACITANCE INDICATOR


- 1. Adjustments to the quantity indicating system are made on the indicator.
- 2. Adjustments to the system are made on the capacitance probe.
- 3. The push-to-test switch is used to check system operation.
- 4. The low-level warning light warns against complete exhaustion of the oxygen supply.

2805

Answers to Frame 11: 1. T 2. F 3. T 4. T

Frame 12

In the capacitance indicating circuit in Frame 10 we have two wires connecting the capacitance probe to the indicator. On the "low" side of the probe we are using a coaxial cable for this connection. This type of cable is illustrated on the right below. Coaxial cable is used on this side of the probe to prevent picking up stray signals which would upset the bridge circuit in the indicator. The wire connecting the "high" side of the probe to the indicator is a shielded electrical lead as shown on the left below. This is the 400 cycle power supply to the probe. This wire does not transmit a signal, so coaxial cable is not required. The wiring diagram symbol for these two wires are shown above each illustration.



Shielded Electrical Lead

Coaxial Cable

- Coaxial cable will transmit a true signal.
- Coaxial cable is used on the "low" side of the capacitance probe.
- The wiring diagram symbol is the same for both cables shown.
- 4. The shielded electrical lead is used on the "high" side of the capacitance probe.
- 5. The shielded lead is used to carry power to the capacitance probe.

Answers to Frame 12: 1. <u>T</u> 2. <u>T</u> 3. <u>F</u> 4. <u>T</u> 5. <u>T</u>

Frame 13

As we mentioned previously, the capacitance indicating system is more accurate and reliable than the direct reading or transducer operated indicating systems. The most frequent trouble with the capacitance indicating system is water (moisture) in the container. Moisture can cause a short between the probe plates or cause an erroneous read-out on the indicator. This is because water (moisture) has a different dielectric effect than liquid oxygen on the capacitance probe.

Mark the following statements with a T for True or an F for False.

- 1. The capacitance indicating system is more reliable than the other two systems we discussed.
- 2. Water (moisture) has a different dielectric effect than liquid oxygen on the capacitance probe.
- 3. Moisture on the probe plates can cause an erroneous read-out on the indicator.

REMEMBER YOUR OXYGEN SAFETY

Answers to Frame 13: 1. T 2. T 3. T

15

APROGRAMMED TEXT 3ABR42331-PT-402D

Technical Training

Aircraft Environmental Systems Mechanic

الكول

OXYGEN SYSTEMS SERVICING AND EQUIPMENT

1 August 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE

DO NOT USE ON THE JOL



FOREWORD

This programmed text was prepared for use in the 3ABR42331 instructional system.

ODJECTIVES

After completing this programmed text, you will be able to:

1. Relate four (4) of five (5) oxygen system servicing equipment components with their purpose.

INSTRUCTIONS

This programmed text presents material in small steps called "frames." After each frame you will find a number of statements and you are asked to select the statement/s that are true or mark true and false. Read the material in each frame before making a selection. The answers to each frame can be found at the top of the next page. If you select the correct answers, continue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before continuing.

Note: Upon completion of this programmed text you will use the equipment covered in this text while doing your oxygen lab projects workbook.

Supersedes 3ABR42231-PT-315, 16 July 1971.

OPP: 3370 TCHTG DISTRIBUTION: X

3370TCHTG/TTGU-P - 600; TTVSA - 1

Frame 1

The TTU-28/E master oxygen test gage is used when performing pressure leak tests on a liquid oxygen system. The unit consists of a 0-400 psi test gage, a gaseous oxygen filler valve, and a liquid oxygen filler valve adapter. When attached to the filler valve of a liquid oxygen system, it opens the system so that you can fill the system with gaseous oxygen. The gaseous oxygen filler valve is of the quick disconnect type and the servicing hose is released from it by moving the handle clockwise.




Figure 1. Master Oxygen Test Gage TTU-28/E.

- 1. The TTU-28/E is attached to the filler valve of a liquid oxygen system.
- _____2. The servicing hose is released from the gaseous oxygen filler valve by pulling it out.



Answers to frame 1: 1. T 2. F

Frame 2

The ultrasonic leak detector is also known as an ultrasonic translator. It is a completely transistorized, battery operated instrument that detects sounds within the ultrasonic frequency range and converts them into sounds audible to the human ear. Audible sounds within the normal hearing range are not picked up by this instrument. Other than normal background hiss, the only sounds hat are heard from the loudspeaker are ultrasonic sounds that have been converted to audible sounds. The unit is portable and has a shoulder carrying strap. The major components are two probes, a lead assembly for attaching probes to the detector, a rubber adapter that reduces the area of coverage of the probe, and a headset. The headset provides a means of listening when plugged in by cutting out the loudspeaker. On the front panel of the unit are three plug-in jacks, a volume control, an OFF-ON toggle switch, and a meter. The meter indicates the level of sound output in decibles.




Figure 2. Ultrasonic Leak Detector.

Check the following statement/s that are true.

1.	The ultrasonic leak detector is a completely transistorized unit.
2.	It requires an external power source of 28 volts DC.
3.	Audible sounds within the normal hearing range are picked up by the unit.
4.	Sounds of ultrasonic frequency are converted to human hearing range

The loudspeaker can still be heard with the headset plugged in.

. 3.

Frame 3

The MH-2 oxygen regulator tester accurately checks the regulator demand diaphragm, the air inlet check valve, and the mask-to-regulator hose for leaks. The pressure being applied and the degree of leakage occurring can also be correctly determined with this tester. Another use of this tester is to determine the amount of oxygen flow from the regulator in the EMERGENCY and TEST MASK positions. The tester has a pressure gage, flowmeter gage, rubber squeeze bulb, rubber bladder, and two adapters. The pressure gage indicates the pressure in inches of water applied to the regulator. The flowmeter indicates any regulator leakage in liters per minute. One connector is made of metal, and is used when attaching the tester to the mask-to-regulator hose. The rubber stop adapter is used when connecting into the outlet port of the regulator.




Figure 3.

- 1. The MH-2 tester is used to check the air inlet check valve, mask-to-regulator hose, and demand diaphragm for leaks.
- 2. The pressure gage indicates in inches of water.
- _____3. The flowmeter indicates in psi.
- 4. The tester is connected to the mask- o-regulator hose by using the rubber stop adapter.

Answers to frame 3: 1. 7 2. T 3. F 4. F

Frame 4

There are different types of liquid oxygen servicing trailers in use throughout the Air Force. The example shown below is a Type TMU-27/M.



Figure 4. Type TMU-27/M Servicing Trailer.

Although the trailers may look completely different, they must adhere to certain basics. All carts consist of an inner and outer tank, and have an insulating material between the tanks? Also, the area between the tanks is evacuated of air, like a thermos bottle. All units have a capacity gage and a pressure gage. Safety features include tank and hose relief valves. These valves are of the automatic-manual or completely automatic type. The tank relief valve prevents an excessive cuildup of pressure when the tank is pressurized. Excessive pressure may be caused by the operator failing to close the build-up valve at the desired pressure. The automatic-manual valve can be hand operated to relieve the pressure. The hose relief valve prevents rupture of the servicing hose. When the trailer servicing walve is closed, and the hose disconnected from a converter filler valve, trapped liquid in the hose turns to gas with an increase in pressure. Again, if the valve is the automatic-manual type, the operator can relieve the hose pressure. If the unit develops a leak in the inner tank, a means of pressure relief is provided to prevent rupture of the outer tank.

Check the following statement/s that are true.

	Certain basics must be alhered to in the construction of trailers	•
2.	All have an inner and outer tank. (
. 2	Adm do assembly the same hadrons the tente	-

4. A means of pressure relief is provided if the inner tank leaks.

Answers to frame 4: 1.

2.

3.

4. <u>~</u>

Frame 5

The control section for operation of all mobile units is at the rear end of the unit. The control section shown below is from the Type TMJ-27/M liquid oxygen servicing unit.




Figure 5. TMU-27/M Liquid Oxygen Servicing Trailer Control Section

All trailers have three basic valves. The first is a vent valve. It is normally open and is closed only when the tank is to be pressurized to force the liquid out of the tank. The second is a buildup valve. It is normally closed and is opened when you desire to build up pressure in the tank. The third valve is referred to as a fill-drain valve on some tanks and a transfer valve on others. It is used to transfer liquid from the tank, through the transfer hose, and into the converter to be filled. If the valve is referred to as a fill-drain valve the tank is also filled through this valve. This is come by removing the servicing hose and attaching a larger hose that is connected to a storage tank of 500 gallons or more. If it is referred to as a transfer valve the tank has a separate fill point and an additional valve is installed.

The transfer hose is constructed of an inner and outer hose which have insulation between them. Hoses are steel wire wrapped, have an aluminum scuff guard, and a standardized servicing nozzle.

lark the	following statements with a T for True or an F for False.	*
1.	Three basic valves are required on all units.	•
2.	The vent valve is normally closed.	
3.	The buildup and fill-drain or transfer valves are normally	closed.
4.	All transfer hoses are steel wire wrapped.	;
5.	The servicing nozzles are standardized.	

2814 .

Answers to frame 5: 1. T 2. F 3. T 4. T 5. T

Frame 6

The type TTU-162/E liquid oxygen converter tester, shown below, is used the shop for bench checking liquid oxygen converters. The vacuum space, wild-up time, operation of the pressure closing valve, design flow, and the system relief valve opening pressure and reseating leakage can all be checked to determine operational suitability. Although Air Force type TTU-162/E converter testers may look different, they all have the same basic components.




Figure 6. Type TTU-162/E Converter Tester.

No response required.

shown below is a typical TTU-162/E control panel. On the panel are three valves; the supply, buildup, and vent valves. At the right of the panel are the supply pressure and buildup pressure gages which indicate from 0 to 600 psi. Three flowmeters are provided. The evaporation loss flowmeter is used when checking the converter vacuum. The leakage flowmeter checks the system relief valve for proper reseating after opening. The large flowmeter with the temperature indicator above it is in use when checking a converter assembly for design flow. When the supply valve is oren, gaseous oxygen flows through this unit and passes the temperature indicator as it flows overboard. Three connectors are provided for attaching the tester to the converter under test and the necessary evaporator coils. These connections may be standard or of the quick disconnect type. An exhaust vent, which is an outlet for liquid to spill from when filling the converter, is used as a test port when checking converter vacuum.





Figure 7. Liquid Oxygen Converter System Tester Type TTU-162/E.

- 1. The three valves are titled supply, buildup, and vent.
- 2. To check the converter vacuum space the evaporation loss flow-meter is used.
- 3. Liquid oxygen flows through the supply flowmeter.
- 4. Liquid oxygen flows from the exhaust vent when a converter is filled.

Answers to frame 7: 1. _T 2. _T 3. _F 4. _T

Frame 8

The gaseous oxygen servicing cart, shown below, is the Air Force Type 02 unit which can handle two gaseous oxygen storage cylinders. It consists of a two wheeled hand cart, pressure regulator, oxygen purifier, and a servicing hose. At the end of the hose is a hand wheel type charging valve. The valve has a standard adapter that will connect to a gaseous oxygen filler valve. Two oxygen storage cylinders, which contain approximately 2200 psi when full, are connected by a common manifold to the pressure regulator.







Figure 8.

No response required.

The first step in operation of the unit is to determine which cylinder , has enough pressure for your immediate needs. The cylinder with the Towest usuable pressure is always used first. This is known as cascading. This is done by opening a storage cylinder valve. Oxygen enters the manifold at cylinder pressure up to the inlet side of the pressure regulator. The storage cylinder pressure is indicated on the cylinder pressure gage at this time. A pressure reading is taken and the valve is closed. The pressure reducer handle is turned in until about 10 psi is indicated on the reduced pressure gage. At this time the operator must open the charging valve until both pressure gages drop to zero to bleed the manifold and servicing hose. The operator must never point the charging valve at himself, other persons, walls or equipment because of the hazards impolved in the use of compressed gases or air. The charging valve is reclosed and the pressure reducer handle backed out. The second cylinder is opened and a reading is taken of its pressure. The cylinder with the lowest usuable pressure is used first. The same procedure must be used whether using the 02 cart or larger units that have six or twelve mounted storage cylinders. No more than one cylinder should be open at any time because the gaseous oxygen will flow from the cylinder of higher pressure into the one of lower pressure until the pressures equalize.



- 1. The first cylinder to be used must have the lowest usable pressure.
- _____2. Only one cylinder must be opened at a time.
- /3. Pressures will not equalize if more than one cylinder is open.

Answers to frame 9: 1.

Frame 10

To reduce cylinder pressure, the pressure reducer handle is turned out slowly (counterclockwise). The pressure is indicated on the reduced pressure gage. Gaseous oxygen flows into the servicing hose at this reduced pressure. When the charging valve is opened, oxygen will flow into the unit being serviced. The flow continues until the reduced pressure set by the regulator, is reached. At this point, the regulator automatically stops the flow. If the unit being serviced is open to an overboard vent, oxygen will flow continuously at the reduced pressure.

GAUGE




Figure 10.

Check the following statement/s that are true.

- The pressure reducer handle is backed out to reduce pressure. 1.
- When the preset reduced pressure is reached the flow stops 2. automatically.

Answers to frame 10: 1. $\sqrt{\cdot}$.2

Frame 11

Capacitance Type Liquid Quantity Systems Test Set Model TF-20-1 is a compact portable instrument which is used for testing and collibrating aircraft liquid oxygen converter probes, indicators and complete gauging systems. Tests can be performed with the gauging system installed in the aircraft, or with system components removed from the aircraft for bench tests in the laboratory, shop or field.




Figure 11. Capacitance Type Liquid Quantity Systems Tester Model TF-Z0-1.

No response required.

Frame 12

The test set includes a waterproof case, adapter cables, and special adapter harness assemblies for different aircraft. Circuitry is provided for measuring capacitance, d-c electrical resistance, and for simulating the capacitance of compensated and uncompensated type tank probes. This caster operates from a power source of 115 volts at 400 cps. The front panel contains a capacitance indicator, megohameter, adapter cable connection points, and all operating controls. You will use the TF-20-1 Tester when doing Project No. 11 of your Lab workbook.




Figure 12.

			i .										
Mark	the	following	statements	with	a	T	for	True	or	an	F	for	False.

		• •	•		*
1.	Outh oue	type aircraft	can be	checked with	the TF-20-1.

202

^{2.} The test set operates on 115 volts 400 cps.

^{. 3.} All controls for operation are on the front panel.

Environmental Pneudraulic Branch Chanute AFB Illinois 61868 3ABR42331-H0-402 30 June 1978

FOREIGN OBJECT DAMAGE PREVENTION AND COMPOSITE TOOL KITS (CTK)

Dollars out of your pocket!! Sounds drastic, doesn't it? Everyday throughout the military, thousands of dollars are wasted through foreign object damage (FOD). These initials - FOD - are probably new to you, but during your stay in the Air Force they will become familiar to you.

Foreign Object Damage is caused by a variety of things, mostly man-made. A mechanic installs a new engine bleed valve. During his installation he drops a 4" bolt (sounds pretty small, right?). In his haste to complete the job he fails to check the area for FOD items. This small 4" bolt is eaten by the engine. Engines, you will find, have a big appetite, they will est anything that can pass their inlet: bolts, nuts, safety wire, tools, rocks, even ear defenders and hats. The bolt, while being digested by the engine, nicks two compressors and three turbine blades. This damage does not become known until the pilot advances the throttles on takeoff. The turbine blades crack, causing the engine to be out of balance. The engine disintegrates, rupturing the fuel cells. Scratch one aircraft, eight people (four even members and a family of four) as the aircraft crashes on a highway two miles from the end of the runway. Although this is ficititious, incidents such as this have happened and will ontinue, unless we all practice good FOD prevention.

In dollars alone, we spend millions that need not be spent from damage caused by foreign objects. In 1976, SAC alone spent over a million dollars due to FOD. - This includes damaged engines, tires, equipment and personal injuries.

We all complain about spending our money, especially when we have nothing to show for it. FOD is a major drain on your pocket. Being in the Air Force you tend to lose twice. How? First, your tax dollars must be used to remedy FOD, they must pay to replace or repair items damaged by FOD. Secondly, since the Defense budget is fixed (you get a set amount to operate on for one year), the more you spend which you do not need to, the less you have to operate on a daily basis. As an example of this: if a B-52 tire is damaged by FOD, \$280.00 is spent out of the Air Force budget. This is \$280.00 less you'll have to spend on new equipment to make your job a little easier. It is really a needless expense, so practice good FOD prevention, it makes good sense!

While doing your projects, you will be required to practice FOD prevention. This means you will use care not to allow nuts, bolts, safety wire, etc. to be left in your work area when you complete your assigned job. Use the magnet provided to remove all traces of FOD.

OPR: 3370 TCHTG DISTRIBUTION: X 3370 TCHTG - 600; TTVSA - 1

> DESIGNED FOR ATC COURSE USE DO NOT USE ON THE JOB



Clean up your project area. If your instructor finds FOD items during his inspection of your project, you will be required to reaccomplish the project. This is treated the same as a technical error and a failure will the entered in your progress record. Get used to it now, since it will become a part of your everyday life during your Air Force career.

While you are doing your projects, you will also use a Consolidated Tool Kit (referred to as a CTK). The CTK program is one of many integral parts of the FOD program. This kit is a quick means of identifying lost or misplaced tools. They are made in many forms, such as bags, shadow boards, metal and wooden boxes. Some are even designed to fit into briefcases.

A CTK is one of these containers mentioned and is usually filled with strips of styrofoam or some type of spongy material. A silhouette of that tool is cut out and usually painted a specific color. The tools required to do the job are then placed in the container. This is done so that any shortage can instantly be identified.

If any shortage does occur, you can easily and the tool since you have not left the job. You must backtrack until you find the tool. This will prevent FOD and perhaps save thousands of dollars in FOD damage.

WORKBOOK

3ABR42331-WB-403

Technical Training

Aircraft Environmental Systems Mechanic

OXYGEN SYSTEMS LABORATORY PROJECTS

20 November 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE
DO NOT USE ON THE JOB



CONTENTS

PROJECT	TITLE	PAGE
. 1	Inspects Oxygen System	4
2	Purging Liquid Oxygen System (Cold Purge)	6
3	Liquid Oyxgen System Pressure Leak Test	9
4	Locating Oxygen System Leaks	10
5	Porforming a Regulator Demand Valve Leak Test.	12
6	Operational Check of an Oxyger Regulator	13
7.	Using the Oxygen Regulator Leakage Tester MH-2	14
8	Purging the Liquid Oxygen System (Hot Purge)	17
9	Liquid Oxygen Servicing Trailer	, 19
10	Using the TTU-162/E Liquid Oxygen Converter System	21
11	TF-20-1 Capacitance Type Liquid Quantity System Trainer	25
12 ~	Repair and/or Replacement of a Liquid Oxygen Converter, Pressure Closing Valve or Relief Valve	28

Supersedes 3ABR42231-WB-402, 15 September 1975.

OPR: 3370 ACHTG

DISTRIBUTION: X

3370TCHTG/TTGU-P - 600; TTVSA - 1



2825

Environmental Pneudraulic Branch Chanute AFB, Illinois 3ABR42331-WB-403

OXYGEN SYSTEMS OXYGEN LABORATORY PROJECTS

OBJECTIVES

The objectives for each project is given in the heading of the individual projects. Read the objectives to determine the task that is to be done and the equipment you will L.d.

EQUIPMENT

	Basis of Iss
Oxygen System Trainer Number 3251	1/student
Go-No-Go Gage	1/student
Test\ Gage, TTU÷28/E	1/student
Leak Tester, MH-2	1/student
Sonic Leak Detector	1/student
Liquid Oxygen System Tester, TF-20-1	1/student
Tester Type TTU-162/E	1/student
Hot Purge Kit, Heating Assembly	1/student
Oxygen System Trainer Number 1762	1/student
Tester Type MH-1	1/student
LOX Trailer, TMU-27/M	1/student
LOX Trailer, A-1	1/student
Pressure Demand Regulator, D2-A	1/student
Demand Regulator	1/student
TO 15X-1-1	1/student

INFOR ATION

If you cannot find the equipment that is used with a project, call an instructor. Any test equipment used will be put back in the same manner that it was found.

One of the most important things the instructor will check you on is safety while you work in the oxygen laboratory. Do not take any chances with liquid oxygen (LOX) or with the electrical equipment. WORK SAFELY.

Read all instructions carefully. If in doubt, ask your instructor for help. Your instructor will move you to the work area for each project. You will use the list of equipment as directed by the various laboratory projects. Each project has a list of specific procedures.

SPECIAL SAFETY PRECAUTIONS

There will be no danger with any of the projects, if you follow instructions. In instructor will be available at all times to help you.

You will work with liquid oxygen (LOX). You must locate and observe all safety points that must be followed when handling LOX. To help you we have made a list of the safety points.



- 1. Hazards of handling liquid and gaseous oxygen.
- a. Liquid oxygen in contact with the skin will cause frostbite and burns.
- b. When liquid oxygen is mixed with fuels it will cause a dangerous explosive hazard.
 - c. Frozen fuel/liquid oxygen mixtures are "shock sensitive."
- d. When gaseous oxygen is absorbed in clothing it will stay for some time.
 - 2. First aid plocedures.
- a. If liquid oxygen gets in the eyes, immediately flood the eyes with water. (See the instructor for the water location.)
- b. If liquid oxygen gets on the bare skin, thaw the area by flooding with water.
- c. Get medical treatment immediately if liquid oxygen gets on the skin or in the eyes.
 - 3. Safety precautions.
 - a. Remove all your jewelry now.
- b. There will be $\underline{\text{NO SMOKING}}$ in the oxygen laboratory at any time.
- c. Personnel must wear the proper face shield, apron, and gloves when handling liquid oxygen. This equipment is provided in the laboratory for your use.
- d. You must and sections in TO 15X-1-1 that give points on oxygen safety and oxygen servicing equipment. Ask your instructor for the page numbers and a lagraphs you are to read.

PROJECT NUMBER 1: INSPECTS OXYGEN SYSTEM

OBJECTIVES


After completing this project, you will be able to:

- 1. Follow inspection work card instructions (AFTO Form 26) to inspect the condition of an oxygen system.
- 2. Use a GO-NO-GO gage and trainers to check the condition of the mask-to-regulator hose connectors.

Standard of Performance:

Your ability to reach the objectives of this project will be evaluated by an instructor, using a criterion reference checklist.

1. Check all the items on the inspection work card. When you reach step 9, obtain the GO-NO-GO gage from locker #1.



2. Use the GO-NO-GO gage to check the inside diameter of the female connector on the mask-to-regulator hose on trainers in the lab. Have the instructor check your work. Identify worn connectors to the instructor.




Figure 2. Using the GO-NQ-GO Gage.

5



Note: As shown in figures 1 and 2, "A" of the gage is the "GO" (small diameter) part and "B" is the "NO-GO" (large diameter) part.

- 3. But the gage in the female connector of the mask-to-regulator hose, as shown in figure 2. Push the gage straight in, but do not force it. A slight rocking or twisting motion may be used.
- 4. The "GO" part of the gage (A) is small and should slip through the smallest internal diameter of the connector. The "NO-GO" part (B) should not go through the small part of the connector. If it does, the connector has too much weak and must be replaced.

PROJECT NUMBER 2: PURGING LIQUID OXYGEN SYSTEM (COLD PURGE)

OBJECTIVES

Ar er completing this project, you will be able to:

- 1. Use the master oxygen test gage TTU-28/E to purge (clean) a liquid oxygen system.
- 2. Transfer gaseous oxygen from a gaseous oxygen storage cylinder, through a liquid oxygen system trainer to a liquid oxygen system.
- 3. Use the liquid oxygen system trainer to purge a liquid oxygen system.
 - 4. Check the pressure of a gaseous oxygen storage cylinder.

Standard of Performance:

Your ability to reach the objectives of this project will be evaluated by an instructor.

PROCEDURES

- 1. Prepare the trainer.
- a. Check the liquid quantity gage. The system must be empty. If the system is not empty, the liquid oxygen converter will have to be drained. When you work on an aircraft, check the technical order for the proper procedures.
- b. Place the oxygen regulator supply switch to ON and the emergency switch to EMERGENCY. This is for the D-2A regulator.

Note: To purge a system on the flight line, first vent the mask-to-regulator hose or hoses to the outside of the aircraft. This can be done through an open canopy, hatch, or entrance way. This will stop the buildup of an oxygen rich atmosphere. An oxygen rich atmosphere is very dangerous.

c. Place the buildup and vent valve to the vent position. Take the hardle from the clip and the dust cap from the oxygen filler valve.




Figure 3. Master Oxygen Test Gage TTU-28/E.

d. Connect the TTU-28/E master test gage to the trainer. Screw the liquid oxygen filler valve adapter of the gage (figure 3) on the threaded part of the liquid oxygen filler valve.

Note: On some aircraft, the buildup and yent valve handle would have to be removed to place the system in the buildup position, with the master gage connected. However, on the trainer it is not necessary.

- 2. Prepare the Gaseous Oxygen Servicing Unit (see figure 4).
- c. Check to be sure that the pressure reducer handle is backed out (turn counterclockwise (CCW) and is free to turn (figure 4)).
- b. Slowly open the oxygen cylinder valve and watch the oxygen high pressure gage (figure 4). If you have an oxygen cylinder with a pressure of less than 400 psi, as your instructor for more instructions before continuing.

Note: Do not drain cylinders below 50 psi. A charge of 50 psi, or more in the cylinders will stop the accumulation of moisture in the cylinders.

- c. Slowly turn (clockwise (CW) the pressure reducer handle (figure 4)) until the reduced pressure gage reads 50 psi.
- d. Open (CCW) the charging valve handle (figure 4) on the supply hose. Purge the hose for ten (10) seconds. Close (CW) he charging valve. BE SURE TO POINT THE NOZZLE AWAY FROM YOURSELF, OTHERS, AND WALLS.

Note: Purging removes any contaminants (dirt or moisture) that may be inside the hose.






Figure 4. Gaseous Oxygen Servicing Unit.

- e. Connect the charging valve to the gaseous oxygen filler valve (figure 3) on the master test gage. The gaseous oxygen filler valve is a quick disconnect unit. The adapter on the charging valve will lock automatically.
 - 3. Purging the system.
 - a. Place the oxygen regulator supply switch ON.
 - b. Open the charging valve on the supply hose.
- c. Readjust the pressure reducer handle to keep a flow of oxygen to the TTU-28/E test gage at 50 psi.
 - d. Allow oxygen to flow through the system for 5 minutes.

Note: In the field use the purge time and steps that are in the technical order for the aircraft on which you are working.

- e. Close the charging valve on the supply hose.
- f. Place the oxygen regulator supply switch OFF.
- g. Place the regulator emergency switch to the NORMAL position.
- h. Back out the pressure reducer handle on the servicing unit.

Note: The system is now purged. In the field the aircraft should be serviced with LOX within two hours after it has been purged.

i. This ends the project on cold purging. Leave the trainer and servicing unit as is and start on the next project.

PROJECT NUMBER 3: LIQUID OXYGEN SYSTEM PRESSURE LEAK TEST

OBJECTIVES

After completing this project, you will be able to:

- 1. Use the master oxygen test gage TTU-28/E to make a pressure leakage test.
- 2. Transfer gaseous oxygen from a gaseous oxygen storage cylinder to a liquid oxygen system trainer.
- 3. Make a pressure leakage test on a liquid oxygen system trainer.
 - 4. Check the pressure of an oxygen storage cylinder.

Standard of Performance:

Your ability to reach the objectives of this project will be evaluated by an instructor, using a criterion reference checklist.

PROCEDURES

- 1. Se sure that the TTU-28/E test gage and servicing hose are still connected to the trainer.
 - 2. Place the buildup and vent valve handle to the BUILDUP position.
 - 3. Turn the oxygen regulator supply switch to the OFF position.
 - 4. Open the charging valve on the supply hose.
- 5. Slowly turn IN the pressure reducing handle on the servicing unit. Charge the system to 300 psi. Use the TTU-28/E test gage to check the pressure.
- 6.) Close the charging valve on the gaseous oxygen supply hose. Disconnect the charging valve from the test gage.



2332

- 7. The pressure shown on the TTU-28/E test gage is ____ psi.
- 8. Close the oxygen cylinder valve and back OUT the pressure reducing handle. Open the charging valve and bleed the pressure from the manifold and charging hose. Be sure to point the nozzle away from yourself, others and walls.
- 9. Let the system stand for 15 minutes. (30 minutes is normal time for an aircraft system.)
- 10. The pressure in the system now is _____ psi. Subtract this reading from the first reading. The difference is _____ psi.

MAXIMUM ALLOWABLE PRESSURE LOSS FOR THE 15 MINUTE TEST

6.0 psi drop
3.5 psi drop
2.5 psi drop
2.0 psi drop
1.5 psi drop
none is allowed

- il. If leakage is more than the listed value, the leaks will have to be found, and identified to your instructor.
- 12. This ends this project. Leave the trainer as is and start the next project.

PROJECT NUMBER 4: LOCATING OXYGEN SYSTEM LEAKS

OBJECTIVES

After you have done this project, you will be able to:

- 1. Use an ultrasonic leak detector, to check for oxygen system leaks.
- 2. Use the LEAK TEC solution to check for oxygen system leaks.
- 3. Explain the operation of the ultrasonic leak detector.
- 4. Explain the use of the LEAK TEC solution to check for oxygen system leaks.

Standard of Performance:

Your ability to reach the objectives of this project will be evaluated by an instructor, using a criterion reference checklist.

PROCEDURES

1. Use of the Ultrasonic Leak Detector.

Note: Refer to figure 5 as you get the detector ready for use.

2133

- a. Take the probe assembly from the top of the carrying case and the lead assembly from inside the cover of the case.
 - b. Plug the lead into the probe assembly.
 - c. Plug the other end of the lead into the jack marked PROBE.
 - d. Place the switch to the ON position.
 - e. Turn the volume control to the right to get more volume.
- f. Blow into the PROBE to check for sound output. Readjust the volume control if necessary.
- g. Slowly move the probe over the tubing and all fittings to check for leaks. A leak will cause the unit to make a sound. As the probe is moved close to a leak the sound will get louder.
 - h. / Have an instructor check your work.
 - i. Turn the tester switch to the OFF position.
 - j. If no leaks are found, put the lead assembly back in the carrying case cover, put the probe on top of the case.
 - 2. Use of LEAK TEC (Soap) Solution.
 - a. Shake the bottle of LEAK TEC solution well to form small bubbles.
 - b. Put the solution on the fittings connecting the plumbing and components of the oxygen system trainer.
 - c. If there is a leak, the LEAK TEC solution will form more bubbles.
 - d. Be sure to wipe off any excess LEAK TEC solution from the trainer.
 - e. This ends this project on locating exygen system leaks. Leave the trainer and servicing unit as is and start on the next project.








Figure 5. Ultrasonic Translator Detector.

PROJECT NUMBER 5: PERFORMING A REGULATOR DEMAND VALVE LEAK TEST WITH THE MH-1 TESTER

OBJECTIVES

After completing this project you will be able to use the MH-1 demand valve leak tester, a soap solution and an oxygen trainer to make a regulator demand valv leak test.

Standard of Performance:

Your ability to reach the objective of this project will be evaluated by an instructor, using a criterion reference checklist.

1. Plug end "A" of the MI-1 tester (figure 6) into the female connector of the mask-to-regulator hose.




Figure 6. MH-1 Demand Valve Leak Tester.

- 2. Place the regulator emergency switch to the NORMAL position.
- 3. Place the supply switch to the OFF position.
- 4. Shake the bottle of soap solution well.
- 5. Squeeze some of the solution onto your finger.
- 6. Apply the solution across end "B" of the MH-1 tester (figure 6) to form a film of soap.
- 7. If a bubble forms from the "B" port and breaks on the pointed hook in less than 8 seconds, the demand valve leaks too much. If the bubble stays under the pointed hook for more than 8 seconds, the leakage is within tolerance. The regulator must be changed if it leaks too much.
 - 8. This ends the demand valve leak test. Start the next project.

PROJECT NUMBER 6: OPERATIONAL CHECK OF AN OXYGEN REGULATOR OBJECTIVE

After completing this project, you will be able to use an oxygen mask and an oxygen system trainer to make an operational check of an oxygen system.

Standard of Performance:

Your ability to reach the objective of this project will be evaluated by an instructor, using a criterion reference checklist.

PROCEDURES

- 1. Connect the oxygen mask to the mask to regulator hose.
- 2. Place the oxygen regulator supply switch to the ON position, the diluter switch to the NORMAL position and the emergency switch to the NORMAL position.



- 3. Breathe normally through the mask and watch the flow indicator on the oxygen regulator for operation. Now place the diluter switch to the 100% position and repeat this step.
- 4. Place the emergency switch to the EMERGENCY position. More oxygen should flow.
- 5. Put the emergency switch to the TEST MASK position. Much more oxygen should flow. Notice that by firmly holding the mask against your face, you will cause the flow blinker to go out.
- 6. This ends the operational check. Return the diluter switch to the NORMAL position, the supply switch to the OFF position and the emergency switch to the NORMAL position. Take the oxygen mask off the hose and put the mask back in the locker.
 - Secure the gaseous oxygen servicing unit.
 - a. Close the valve on the oxygen storage cylinder.
- b. Open the charging valve on the supply hose until both of the pressure gages on the servicing unit read zero (0).
 - c. Back out (CCW) the pressure reducing handle.
 - d. Close the charging valve.
 - e. Recheck the gages to be sure they both read zero (0).
 - f. If the gages are not at zero (0), repeat steps a through d.
 - 8. Secure the oxygen system trainer.
- a. SLOWLY move the buildup and vent valve handle 🗢 the VENT position.

Note: After the system has been drained, pressure will be trapped in the system and will show on the pressure gage. This is normal. DO NOT bleed off this pressure.

- b. Disconnect the TTU-28/E master test gage.
- c. Put the dust cap on the filler valve, and on the master test gage.
 - d. Place the handle in the clip.
 - e. Reposition the build-up and vent handle to "build-up."
 - 9. This ends the project, start on the next project.

PROJECT NUMBER 7: USING THE OXYGEN REGULATOR LEAKAGE TESTER MH-2 OBJECTIVE

After completing this project, you will be able to use the oxygen regulator leakage tester (type MI-2) and a trainer to check an oxygen regulator demand diaphragm and the mask-to-regulator hose for leaks.



14

Standard of Performance:

Your ability to reach the objective of this project will be evaluated by an instructor, using a criterion reference checklist.

Note: Before testing the regulator for leakage, the tester has to be checked for leaks. It a tester with a leak is used, the regulator leakage reading will be wrong. To check the tester, put your finger over the end of the adapter hose. Pump up 17 inches of water pressure with the pressure bulb. Check for leakage on the flowmeter. NO leakage is allowed. Drop pressure by removing your finger from the end of the adapter hose.

- 1. Mask-to-Regulator Hose and Oxygen Regulator Leakage Test.
- a. Check the oxygen regulator to be sure that each switch is positioned for the test.
 - (1) Supply "OFF"
 - (2) Diluter "NORMAL"
 - (3) Emergency "NORMAL"
- b. Attach the metal adapter to the hose of the tester and put the adapter into the open end of the mask-to-regulator hose.
- c. Close the bleed screw (some units do not have a bleed screw) that is between the bag and pressure bulb.
- d. Squeeze the pressure bulb several times until the tester pressure gage shows 17 inches of water pressure.
 - e. Hold this pressure by squeezing the bag.
 - f. Leakage should not be more than 1.0 liter per minute.
 - g. Place the diluter switch to the 100% position.
- h. Squeeze the pressure bulb several times until the pressure gage shows 17 inches of water pressure.
 - 1. Leakage should not be more than 0.5 liter per minute.

Note: If 17 inches of water pressure can not be reached in either the NORMAL or 100% positions, there is a leak. The leak could be in either the mask-to-regulator hose or the regulator demand diaphragm. To find which unit has the leak, do steps (1) through (5).

- (1) Tak the metal adapter from the mask-to-regulator hose.
 - (2) Take the mask-to-regulator hose from the regulator.
 - (3) Take the metal adapter f. om the tester hose.



- (4) Put the <u>rubber adapter</u> on the tester hose and plug the tester hose into the regulate, outlet port.
 - (5) Do steps c through i again.
- k. If there are no leaks, the oxygen regulator demand diaphragm is good. The leak is in the mask-to-regulator hose.

Note: After the leakage test is done the MM-2 tester could be connected to the units in one of two ways.

- (1) If there is no leak in the mask-to-regulator hose, the METAL ADAPTER should still be attached to the hose. Check to make sure the adapter is still attached.
- (2) If there was a leak in the mask-to-regulator hose, the RUBBER ADAPTER should be attached to the oxygen regulator outlet. Check to make sure it is installed.

The regulator pressure outlet test can be made with the MH-2 tester connected in either of the two positions.

2. Regulator Pressure Output Test.

Note: For this check, the D2-A oxygen regulator should show a minimum of 80 lsi.

- a. Crack the bleed screw on the tester to cause a slight leak. If there is no bleed screw, move the adapter on the hose to cause a slight leak.
 - b. Place the supply switch to the UN position.
 - c. Place the emergency switch to the EMFRGENCY position.
- d. The pressure gage on the tester should now show a pressure of at least 2.75 inches of water. This is the correct output pressure.
- e. Place the emergency switch to the TEST OR TEST MASK position and hold the switch in that position.
- f. The pressure gage should show a pressure of from 6 to 17 ' les of water for the test or test mask position to be good.
 - g. Place the supply switch to the OFF position.
 - h. Place the test or test mask switch to the NORMAL position.
- i. Take the tester from the oxygen system trainer and store all parts in the tester box.
 - j. This ends the MH-2 test project.



OBJECTIVES

After completing this project, you will be able to:

- 1. Use the hot purge kit to purge an oxygen system.
- 2. Transfer gaseous oxygen from a gaseous oxygen storage cylinder to the liquid oxygen system trainer.
- 3. Use the liquid oxygen system trainer to purge a liquid oxygen system.
 - 4. Check the pressure of an oxygen storage cylinder.

Sturdard of Performance:

Your ability to reach the objectives of this project will be evaluated by an instructor, using a criterion reference checklist.

PROCEDURES

Note: The hot purge kit can be used to purge any liquid oxygen system. The kit can be used to remove moisture from the capacitance probe used with some liquid oxygen converters. Moisture on a probe can cause a wrong signal to be sent to the quantity adicator.

- 1. Prepare the trainer.
 - a. The hot purge kit is in locker #2.
- b. Move the regulator supply switch to the ON position and the emergency switch to the EMERGENCY position.
- c. Vent the mask-to-regulator hose to the side of the trainer. This will drain the remaining system pressure that was left from project #6.
 - d. Place the buildup and vent valve to the BUILDUP position.
 - e. Take the dust cap from the filler valve.
- f. Take the dust cap from the filler nozzle end of the hot purge kit.
- g. Align the three studs (in the open end of the nozzle) with the three grooves on the filler valve on the trainer. (On some aircraft the buildup and vent valve handle will have to be removed for this test.)
- h. Push on the nozzle and twist it to the right to lock on the filler valve. Be sure the nozzle is fixed to the valve. Have an instructor check your work before proceeding.

- 2. Prepare the Gaseous Oxygen Servicing Unit.
- a. Check to see that the pressure reducer handle is backed out (CCW) and is free to turn.
- b. Slowly turn IN the pressure reducer handle until the reduced pressure gage reads 50 psi.
- c. Open the charging valve on the supply hose and purge the hose for 10 seconds, then close the valve.
- d. Plug the charging valve into the gaseous oxygen filler valve, on the side of the hot purge kit.
- e. Connect the electrical lead from the hot purge kit into a 110V AC, 60 Hz outlet.
 - 3. Purging the System.
- a. Open the charging valve on the gaseous oxygen supply hose.
- b. Check the reduced pressure gage to be sure that oxygen under 50 psi is flowing into the hot purge kit. If not, turn the pressure reducer handle to adjust the pressure to 50 psi. (Oxygen should flow out the distribution hose from the regulator.)
- c. Place the electrical switch, on the end of the hot purge kit, to the ON position. A red light should come ON. This shows that the kit is heating the gaseous oxygen that flows to the system. This light will cycle ON and OFF as the correct temperature is maintained.
- d. Oxygen should flow through the system for 5 minutes. Aircraft purging time is listed in the aircraft TOs.
 - 4. Disconnecting the Hot Purge Kit.
 - a. Place the electrical switch to the OFF position.
 - b. Close the charging valve on the oxygen supply hose.
 - c. Place the oxygen regulator supply switch to the OFF position.
 - d. Place the emergency switch to the NORMAL position.
 - e. Take the electrical lead from the wall outlet.

Caution: When disconnecting the charging valve from the hot purge kit, lift the kit only by the carrying handle and the insulated portion of the nozzie. This method will prevent burning your hands.

18

- f. Take the charging valve from the hot purge kit.
- g. Take the hot purge kit from the trainer filler valve and place it back in the carrying case.
 - h. Put the dust cap on the tester connection.
- i. Put the dust cap on the trainer filler valve and place the buildup and vent valve to the vent position.
 - 5. Secure the Gaseous Oxygen Servicing Unit.
 - a. Close the valve on the gaseous oxygen storage cylinder.
- b. Open the charging valve on the supply hose until both pressure gages read zero (0).
 - c. Close the charging valve.
 - d. Recheck the gages to be sure they both read zero (0).
 - e. If pressure still shows on the gages, do steps a through c.
- f. The system has been purged with the hot purge kit and should be serviced with liquid oxygen within 2 hours to prevent recontamination.
 - g. This ends this project.

Note: Check with your instructor before continuing.

PROJECT NUMBER 9: LIQUID OXYGEN SERVICING TRAILER

OBJECTIVES

After completing this project, you will be able to:

- 1. Connect a liquid oxygen converter to a liquid oxygen servicing cart (trailer).
 - 2. Transfer liquid oxygen from the trailer into the converter.
 - 3. Use safety precautions while handling liquid oxygen.

Standard of Performance:

Your ability to reach the objectives will be evaluated by an instructor.

PROCEDURES

Note: This project is to familiarize you with the operation of a liquid oxygen servicing trailer. In the field you will service converters with oxygen. You can then use the TTU-162/E converter tester (figure 7) to bench check a converter in the shop.




Figure 7. Converter and Test Equipment Hookup.

- 1. The converter (figure 7) you will be servicing is connected to a piece of test equipment and a coil of tubing. This is the TTU-162/E converter tester you will use in the next project.
- 2. The valves on the tester must be in the following positions before servicing the converter with LOX,

a. Supply valve CLOSED

b. Buildup valve CLOSED

c. Vent valve OPEN

3. Place a clean container under the piece of tubing attached to the tester exhaust vent. When the converter is full, liquid will come out of this vent.

Caution: Put on safety equipment .-- gloves, face shield, and apron.

- 4. The instructor will give you the information you need to operate the servicing trailer. Read through the servicing checklist to find all the valves and parts before you start to service the converter. Follow the TO checklist as you do the servicing operation. If you have any problems, immediately call for an instructor to help you. After the converter is filled, go back to this workbook for further instructions.
- 5. After the converter is full, leave the trainer and tester in the positions they are in. Wait at least 15 minutes for the system to stabilize, then do the next project.

OBJECTIVES

After completing this project, you will be able to:

- 1. Use the TTU-162/E converter tester to test a liquid oxygen converter.
 - 2. Operate a TTU-162/E converter tester.

Standard of Performance:

Your ability to reach the objectives will be evaluated by an instructor, using a criterion reference checklist.

- 1. TEST NUMBER 1 The vacuum space of the liquid oxygen converter under test needs to be checked for the loss of vacuum. A loss of vacuum will cause a high evaporation rate of the liquid.
 - a. Check to see that the vent valve is still OPEN.
- b. Take the metal tubing and hose from the exhaust vent of the tester and place them on the bench.
- c. Connect one end of the hose to the EVAPORATION LOSS FLOWMETER and the loose end of the hose to the EXHAUST VENT of the tester.
- d. Watch the ball in the flowmeter. If the ball rises from zero (0), the amount of leakage is as shown on the markings of the glass tube. The leakage is ______ liters per minute.
- e. Use the information in table 1 to choose the leakage that is allowed for the converter under test.

. MAXIMUM LOSS SHAJ.L NOT EXCEED					
Converter Size (Liters)	Allowable Leakage (Liters Per Minute)				
5	0.60				
8	V.69				
10	0.75				
, 20	0.92				
25	1.0				
75	2.1				

Table 1. Allowable Converter Leakage.



f. Compare the leakage listed in step d with the leakage allowed for the converter under test. The converter vacuum is
(good/bad)
g. Take the hose from the flowmeter and exhaust vent and place the hose on the bench. Do test number 2.
2. TEST NUMBER 2 - This test is made to find out how much time it takes the converter under test to buildup to operating pressure. Operation of the pressure closing valve will also be checked.
8. Close the vent valve on the tester.
b. Open the buildup valve.
c. Maximum buildup time to operating pressure (70 or 300 psi)
is 10 minutes. Record the start time
d. Watch the buildup and supply pressure gages. Both gages should rise at about the same rate.
e. At the end of 10 minutes look at the buildup gage. The pressure should be either 70 or 300 psi. Record the pressure.
psi.
Note: If the converter does not reach operating pressure in 10 minutes, the pressure setting is out of tolerance (above or below 70 to-300 spi), the pressure closing valve must be adjusted or replaced.
f. The pressure closing valve is (good/bad)
3. TEST NUMBER 3 - The converter under test will be checked for maximum and minimum pressures and flow rates. Liquid oxygen converters are made to give a set amount of gaseous oxygen per minute. The amount will change with the type of converter. During this test, the liquid oxygen that flows into the evaporator coils is changed to a gas that flows overboard through the supply flowmeter.
a. List the temperature that is shown on the temperature gage at the top of the supply flowmeter on the tester. The tempera-
ture is
b. For the converter under test, find the design flow rate in table 2.
c. Watch the float in the supply flowmeter.

2845	
アリソン	

					F-12	
CCNVERTER	SPECIFICATION	NO. OF RELIEF VALVES	OP'PRESS (PSI)	SIZE (L)	DESIGN FLOW (L/M)	
A-2	MIL-C-6650	2	300	8 ,	80 .	
A-3	MIL-C-7407	2 (INDIVIDUAL)	. 70	5	20	
MA-1	MIL-C-25021	2	300	20 .	120	
ME-3.	MIL-C-25674	2	300	25	150	
GCU-2/A	MIL-C-25777 🕏	1	70	10	72	
GCU-3/A	MIL-C-25781	1,	. 70	10	72	
GCU-10/A	MIL-C-25974	2 (INDIVIDUAL)	300	10	80	
GCU-11/A	MIL-C-25972	a 2	300	10	100	
GCU-12/A	MIL-C-25973	1	70	5	72	
GCU-14/A	MIL-C-26358	1	70	5	72	
GCU-17/A	MIL-C-27336	2	300	25	150	
*GCU-20/A	MIL-C-27652	. 2	300	75	400	

'Lable 2. Converter Data.

d. After the supply valve is opened, stabilize the top of the float at the design flow rate for the converter under test. This is done by opening and closing the supply valve and checking table 2.

e. Let oxygen flow for 15 minutes.

Caution: The evaporator coils and connecting plumbing will ice up during this test. Practice all safety precautions.

f. Watch the pressure gages. The pressure for the converter being tested is listed on the data plate for the converter. If pressure is not in the range set for the converter, the pressure closing valve is not working.

	g.	The	minimum	pressure	ís	 psi.	The	maximum	pressure
is	 psi.								

h. Check the temperature gage. The temperature should be about the same as in step a.

Note: During the 15 minute oxygen flow test, read TEST NUMBER 4.

4. TEST NUMBER 4 - This test is to check the system relief valve for proper opening and closing. During the flow test, liquid goes in the coils of the evaporator. A sudden stop in the flow of gaseous oxygen overboard, will cause the trapped liquid to turn to a gas. This will cause a high supply pressure. To protect the system the pressure relief value must open at a set pressure.

Caucion: During this test, stand clear of the converter relief valve vent.

- a. Suddenly close the supply valve.
- b Watch the supply pressure gage and list the pressure at which the relief valve opens. The relief valves opens at

ne 1	
 NO T	•

CONVERTER OPERATING PRESSURE	RELIEF VALVE SETTING
Low-Pressure System	100 - 120 ps1
High-Pressure System	380-430 psi .

Table 3. Converter-to-Relief Valve Relation.

- c. From Table 3 find the setting of the relief valved used with the converter under test.
- d. Compare the reading listed in step b with the relief valve setting listed in Table 3. The relief valve is (good/bad)
- e. Put the rubber test hose on the leakage flowmeter of the tester.
 - f. Place the other end of the mose on the converter vent port.
- g. If the ball in the flowmeter does rise from the zero mark, list the amount of leakage shown. The leakage is _____ LPM.

Number of Relief Valves Installed	Leakage Permitted
1	0.01 LPM
. 2	0.02 LPM

Table 4. Permitted Relief Valve Leakage.

- h. From Table 4 find the amount of permissible leakage.

 Compare this setting with the leakage listed in step g. The reseating

 of the relief valve is (good/bad)
- i. Take the hose from the flowmeter and converter vent and place the hose on the bench.
- j. Open the vent valve on the tester and vent the converter head pressure.
 - k. Open the supply valve and bleed off the supply pressure.
- 1. Close the supply valve. This leaves the tester in the vent position.

Note: At this time you would have a serviceable converter or one on which work would have to be done to make it serviceable.

PROJECT NUMBER 11: TF-20-1 CARACITANCE TYPE LIQUID QUANTITY SYSTEM TRAINER

OBJECTIVES

After completing this project, you will be able to:

- 1. Sat up the TF-20-1 tester for an empty converter capacitance check.
 - 2. Take readings from the capacitance indicator on the tester.
- 3. Find the condition of a liquid oxygen converter probe assembly.

 Standard of Performance:

Your ability to reach the objectives of this project will be evaluated by an instructor, using a criterion referenced checklist.

PROCEDURES

Note: All test leads that will be used are in the cover of the tester. The leads have numbers or letter-number combinations on them for identification. These leads are used with the tester. When you are given a numbered connection point, control switch or indicator in this project, look at the front panel diagram, inside the cover, for the location of the item.

- 1. Connect adapter <u>lead #100038 from point 5</u> to a suitable ground.
- 2. Connect power cable #100033 and adapter cable #100034 together.
- 3. Connect the combined cable from point 4 to the power source.
- 4. Place power switch #1 to the ON position. The red light near the switch should come ON. Allow at least 5 minutes warm-up time.



25

- 5. Connect the <u>lead</u> from <u>point 11</u> to the <u>HI-Z connector</u> of the converter under test.
- 6. Connect the <u>lead</u> from <u>point 12</u> to the <u>LO-Z connector</u> of the converter.
- 7. Set function selector switch #24 to TANK UNIT TEST-UNSH position.
 - . 8. Set CAP-RES CHECK switch #13 to CAP position.
- 9. Set the capacitance RANGE SELECTOR #6 to the <u>lowest range</u> that will give a stable reading (the indicator does not rotate continuously) on <u>capacitance indicator #7</u>. If the inner needle does cross above 100, place the range selector to the next higher multiplier.

Note: Study the capacitance meter dial (figure 8). With the capacitance range selector in the xl position, a reading of 43.25 MMF is obtained as shown in figure 8. The last decimal place is estimated by eye. In the x3 position this reading is 43.25 X 3 = 129.75 MMF. For the x10 and x50 positions the values are 432.50 MMF and 2162.50 MMF. Now apply what you have to read to interpret your reading on the converter you are checking.




Figure 8. Capacitance Meter Dial.

- 12. Complete the statements.
- a. The capacitance indicator reading is ____ MMF and the range selector is in the x___ position.

26

•	Ъ	The	MMF	reading	multiplied	by	the	range	selecto
position	is	1	mmf.	•		•		•	

c. Select the required reading from Table 5 for the size converter you are testing.

CONVERTER SIZE	REQUIRED READING
10 Liter	123.5 ± 1.0
25 Liter	303.5 ± 2.5
75 Liter	910.0 ± 7.5

Table 5. Converter Size-Capacitance Relation.

. d. The requi	ired reading is	MMF and the number in	
step b (is/is not)	in the tolerand	e of the required reading	} ્.
The converter capacitane	ce probe is (good/ba	d)	
e. Have an	Instructor check you	r readings.	



()

PROJECT 12: REPAIR AND/OR REPLACEMENT OF A LIQUID OXYGEN CONVERTER,
PRESSURE CLOSING VALVE OR RELIEF VALVE

OBJECTIVES

- _1. Repair and/or replace liquid oxygen converter part.
 - 2. Apply anti-sieze tape to fittings of liquid oxygen systems.
- 3. Select common handtools necessary for LOX converter maintenance.
- 4. Observe all safety precautions involved during LOX converter maintenance.

Standard of Parformance:

Your ability to reach the objectives will be evaluated by the instructor.

PROCEDURE

Note: In the field you will be required to remove and replace minor parts of LOX converters. This project will miliarize you with the handtools, equipment, procedures and afety precautions necessary to accomplish that task.

- 1. On a given converter, remove lines and tubing connected to the part, being careful not to twist any lines.
- 2. Remove common hardware securing the part to the converter assembly, and remove the part.
- 3. Place the part in a bench vise and remove all old fittings and tape, retape fittings. Have the instructor check your work at this time. INSTRUCTOR'S INITIALS

Install the fittings in the new valve exactly the way they came out of the old valve. (During taping, follow the instructions on the role of anti-sieze tape.)

- 4. Mount the new part on the converter assembly, reinstall common hardware and tighten.
- 5. Reinstall and/or connect tubing and lines disconnected during removal, and tighten tubing and lines.

Note: In the field, your converter would now be serviced with a few liters of liquid or gaseous oxygen, for the purpose of leak checking all the fittings. All lines found to be leaking would be tightened to stop the leak.



3ABR42331-PT-404

Technical Training

Aircraft Environmental Systems Mechanic

CYROTAINER CONSTRUCTION AND MAINTENANCE

9 November 1978



CHANUTE TECHNICAL TRAINING CENTER (TC)
33/0 Technical Training Group
Cnanute Air Force Base, Illinois

Designed for ATC Course Use.

Do Not Use on the Job.

FOREWORD

This programmed text was prepared for use in the 3ABR42331 instructional system. The materials contained herein have been validated using 30 students enrolled in the 3ABR42331 course. Eighty percent of the students taking this text surpassed the criterion called for in the approved lesson objectives. The average student required 4.8 hours to complete the text.

OBJECTIVES

- 1. Match 8 of 10 components of the cryctainer with the function/operation.
- 2. Identi'y without error, the safety precautions relative to cryotainers.

INSTRUCTIONS

This text is presented in small steps called "FRAMES." After each frame you will select correct statements, match names, and/or numbers to items. Compare your answer vith the correct one found at the beginning of the next frame. If your answer is correct, go to the next frame. If your answer is wrong, read the frame again and see how the correct response was derived.

READ CAREFULLY AND DO NOT HURRY!!!!

Note: Upon completion of this programmed text you will use the equipment covered in this text while doing your oxygen lab projects.

Supersedes 3ABR63130-PT-208, 31 March 1977.

OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/TTGU-P - 400; TTVSA - 1



2


Frame

The storage of exyogenic fluids for many years has caused a problem. No refrigeration system was able to keep this liquid at a temperature low enough to keep it in a liquid state. Now liquid oxygen and liquid nitrogen can be stored successfully. They are stored in the same manner. Since our first concern is the storage of liquid oxygen, this Programmed Text refers to liquid oxygen.

Liquid oxygen must be kept at an extremely cold temperature (below -297°F) to keep it in a liquid state. Any heat causes it to boil and gas off. You can see the gassing off process taking place in water. Water will boil and gas off to a water vapor, when its temperature is raised above the boiling point. The more heat added to any liquid, the more it boils and evaporates.

There is no low cost way of refrigerating liquid oxygen to keep it in a liquid state; therefore, the only practical way to store it is to try to keep heat from getting to it. This is done by use of a cryotainer.

It was said earlier in the text that LOX must be kept in insulated tanks to stop it.from boiling and thus changing from a liquid to a gas. To slow this boiling action down, one tank is placed inside another. The inner tank holds the liquid. The outer tank aids in insulating the inner tank. The space between the two tanks (annular space) is filled with an insulating material. A vacuum pump is attached to the line at the top of the tank. The vacuum valve is then opened and the ai. is pumped out. The valve is then safety wired shut to stop accidental opening. This valve will be color coded yellow and may be letter coded "A". These two items, the insulating material and vacuum in the annular space, provide the insulation for the inner tank. (See figure below)





Frame 1 (Cont'd)

Circle the correct answer.

- 1. The space between the two tanks is called
 - a. annular space.
 - b. pressure.
 - c. LOX.
 - d. rupture.
- 2. The vacuum valve must be letter coded "A". TRUE or FALSE
- 3. The vacuum valve must be color coded
 - a. blue.
 - b. red.
 - c. white.
 - d. yellow.
- 4. Insulating material provide the only insulation for the inner tank. TRUE or FALSE
- 5. Air in the annular space is a good insulator. TRUE or FALSE




Answers to Frame 1: 1. a 2. FALSE 3. d 4. FALSE

FALSE

Frame 2

There are 3 main control valves. All are the globe type with extended stems. The extended stem prevents the packing from freezing and reduces heat transfer from the hand-wheel to the valve body. The valve body is at the temperature of the liquid oxygen while the hand-wheel is cool to the operator.

There are two pipes that come from the inner tank. The top line from the inner tank is the vent pipe and has the vent valve attached. This valve is only closed when transferring (dispensing) liquid. At all other times, this valve will be open to let the liquid that is vaporizing, out of the tank. The valve is color coded red and may be letter coded "E". (See figure below). The line from the bottom inner tank is the fill and drain line with the fill and drain valve attached. The valve will be color coded blue and may be letter coded "C". This valve will only be opened when issuing or receiving LOX.



Circle the correct answer.

- 1. When you are <u>not</u> transferring liquid, the vent valve will be left in the
 - a. closed position.
 - b. middle position.
 - c. open position.
 - d. annular position.

Frame 2 (Cont'd)

2. The vent valve is color coded red.

TRUE or FALSE

- 3. The fill and drain valve is color coded
 - a. blue.
 - b. red.
 - c. white.
 - d. yellow.




Answers to Frame 2: 1. c 2. TRUE 3. a

Frame 3

Located on the pressure line that connects the yent pipe and the transfer pipe is a capacity gage. As the name states, this gage shows the amount of liquid oxygen within the inner tank. This gage is sensitive to pressure and it can be damaged by pressure surges. Therefore, the gage is offset from the pressure line and is protected by a capacity gage bypass valve located in the pressure line.

The valve located in the pressure line is a safety device that protects the capacity gage. This valve is normally open, allowing pressure to "bypass" (go around) the capacity gage. The bypass valve should be closed only when you need to obtain the amount of LOX in the tank. As soon as you have obtained the amount of LOX within the tank, the bypass valve should be opened again. This valve will be color coded black and may be letter coded "B". (See figure below)



Frame 3 (Cont'd)


Circle the correct answer.

- 1. What valve is installed in the system to protect the capacity gage?
 - a. Tank vent
 - b. Capacity gage bypass
 - c. Capacity gage
 - d. Fill and drain valve
- 2. The capacity gage bypass valve is normally in the
 - a. open position.
 - b. closed position.
 - c. up position.
 - / d. side position.
- 3. The capacity gage bypass valve is color coded red. TRUE or FALSE



Frame 4

Earlier in this text we said that pressure buildup within the LOX tank can (under the right conditions) present a hazard to personnel and equipment. For example, if the shell of the inner tank should rupture and leak liquid oxygen into the annular space between the inner and outer tanks, there could be a dangerous buildup of pressure between the two tank shells. To prevent the outer tank from being damaged or blown up from excessive pressures, a safety device is installed in the shell of the outer tank. This safety device is a rupture disc. The rupture disc is set to blow out at a pressure low enough to prevent damage to the outer tank shell. Since LOX tanks are made by several different companies and since each company has different pressure settings on the tanks' safety devices, we will not discuss the pressure settings of these safety devices in this text. (See figure below). A complete description of the rupture disc and its blowout pressure is in TO 37C2-8-1-101.



Circle the correct answer.


- 1. What is the name of the auto pressure buildup device on the outer tank?
 - a. Vacuum valve
 - b. Rupture disc
 - c. Tank vent
 - d. Caracity gage
- 2. All outer tank rupture discs are set at the same pressure.

TRUE or FALSE



Pre 3'5

Low tanks do not have pumps to aid in the rapid transfer of LOX. So some other way must be used to move the liquid. The other way is pressure. As you already know, if the tank vent is closed, pressure will start to build in the tank. But this is a slow process. To speed this process, a pressure buildup valve and coil are attached to the fill and drain line. When the pressure buildup valve is opened (see figure) LOX will flow through the pressure buildup coil (heat exchanger) where it is changed to a gas. From the heat exchanger, the gas follows the pipe which joins the tank vent pipe (remember the tank vent is closed). The gas will then flow back into the gaseous portion of the tank and will apply added pressure to the liquid which allows a more rapid transfer of LOX. This valve will remain closed except when building up pressure in the tank. The pressure buildup valve will be colored coded white and may be letter coded "D".



Circle the correct answer.


- 1. The pressure buildup coil changes gas to liquid? TRUE or FALSE
- 2. The pressure buildup valve will be open at all times except during transfer? TRUE or FALSE
- 3. The pressure buildup valve is color coded white. TRUE or FALSE



Frame 6

Just above the point that the pressure buildup coil joins the tank vent line is a direct reading gage (Pressure Gage). This, is used to tell how much pressure is built up within the vapor portion of the inner tank.

Located just above the pressure gage in the pressure build up line is a protective device, the <u>Tank Pressure Relief Valve</u>. This valve will relieve encersive pressure in the inner tank. (Depending on the type of tank the valve will operate either manually or automatically.) See figure below.



Frame 6 (Cont'd)

Circle the correct answer.


- I. What valve is installed to relieve excessive pressure in the inner tank?
 - a. Tank vent
 - b. Pressure build up
 - c. Rupture disc
 - d. Tank pressure relief
- 2. What is used to tell how much pressure has been built up in the inner tank?
 - a. Capacity gage
 - b. Pressure gage
 - c. Vacuum gage
 - d. Annular space



Frame 7

Another relief valve is located in the fill and drain line. This is the Hose Pressure Relief Valve. This relieves excessive pressure in the transfer hose and, depending on the type of tank, will be manually or automatically operated. There are two more safety devices, one located in the pressure buildup line and one in the fill and drain line. These are safety discs. If for example, the hose pressure relief valve or tank pressure relief valve were frozen in the closed position, to se discs (Hose Safety Disc and Tank Safety Disc) are designed to blow out if the pressure in the hose or tank continued to rise.

The last item is of the <u>Filter</u> located in the fill and drain line. The filter is the metal porous type. This unit, as the name implies, filters LOX.



Circle the correct answer.

1. The purpose of the hose pressure relief valve is to relieve normal pressure.

TRUE or FALSE


2. The safety disc will blow out automatically if the relief valves are frozen closed and pressure in the inner tank continues to rise. .

TRUE or FALSE.



Frame 8

Using the diagram, enter the number that correctly identifies the components that make up a liquid oxygen facility. If you are not sure of the answers go back and review the information.



a.	Vacuu	m valve

- b. Pressure buildup valve
- c. Tank safety disc
- d. _Annular space
- e. Hose pressure relief valve
- f. Rupture disc
- g. ____Rose safety disc

- h. Tank vent valve
- 1. ____Tank pressure relief valve
- j. ____Fill and drain valve
- k. Pressure gage
- 1. Capacity gage
- m. ____Capacity gage bypass valve
- n. ____Filter



Answers to Frame 8. a. 2 b. 8 c. 1' d. 1 e. 11 f. 7 g. 13 h. 3 i. 10 j. 4 k. 9 1. 5 m. 6 n. 14

Frame 9

Before any LOX transfer or receiving operations are done, the valves must be properly positioned. Valves should not be tightened-down more than hand tight (using gloved hand only). The use of additional levers, breaker bars, etc will squeeze out the teflon seat. This will cause premature failure of the valves.

The following chart will show the correct valve positions for transferring, receiving, and storing LOX.

Valves

IUNCTIONS

Color	4 Name	Filling	Pressure Buildup	Transfer	Liquid Storage
Black	Capacity Gage	Open	Open	Open	C- n
Blue	Fill and Drain	Gen	Closed	Open	Closed
White	Pressure Buildup	Cl os ed	Open	Closed	Closed
Red	Vent	Open	Closed	Closed	0 p en

If the LOX tank is empty and not used, the vent valve should be closed.

Match the lettered items to their corresponding numbered items. More than one lettered item may be used.

1.	Open for transfers	a.	Black colored
2.	Closed when filling	ъ.	Tightening valves
3.	Open when storing LOX	c.	Pressure buildup valve
4.	Using gloved hand	d.	Vent valve
*	Open for all operations	e.	Blue valve



Answers to Frame 9: 1. a 2. c 3. a6d 4. b 5. a

Frame 10

The most common method of filling LOX tanks is through the fill and drain system. Before starting a LOX transfer operation, determine the amount of liquid in each tank to be used in the operation, to insure the tank isn't empty. This is done by closing the Capacity Gage Bypass Valve on each LOX tank. After getting the reading, remember to open the Capacity Gage Bypass Valve. This valve must be opened to prevent damage to the Capacity Gage.

Caution: Always leave the Capacity Gage Bypass Valve open when not taking a reading. If the valve is closed Juring a filling operation, there is a possibility of damage to the gage as a result of surging pressure against the gage mechanism.

Circle the correct answer for each of the following questions.

- 1. Why is the Capacity Gage Bypass Valve closed on the LOX tank from which you will transfer?
 - To prevent damage to Capacity Gage.
 - b. To make sure the tank is not empty.
 - c. To use as ready reference for inventory purposes.
 - d. To prevent surging of pressure.
- 2. What is the most common method of filling a LOX tank?
 - Through the Capacity Gage Bypass line.
 - b. Through the valve cc r coded black.
 - c. Through the valve color coded white.
 - d. Through the fill and drain system.
- 3. When would there be a possibility of Capacity Gage damage during a filling operation?
 - a. Capacity Gage Bypass Valve left open.
 - b. Fill and drain system clogged.
 - .. Rupture in fill and drain system.
 - d. Capacity Gage Byrass Valve left closed.

Frame 11

Before liquid can be transferred, enough pressure must be built up in the LOX tank.

Caution: Check tank pressure and hose pressure relief valves for free operation before building up tank pressure.

To build up pressure in a tank for transferring LOX, the valves must be properly positioned. The following chart is the portion of the chart in Frame 18 that cove 3 the pressure buildup operation.

Valves

Function

Color	Name	Pressure Buildup	
Black	Capacity Gage	Open	
Blue	Fill and Drain	Closed	
White	Pressure Buildup	Open	
Red	Vent	Closed	

When doing a pressure buildup operation, first make sure the Capacity Gage Bypass Valve is open. Then check the fill and Drain Valve to make sure that it is closed hand tight. Now, close the red color coded Vent Valve. After the Vent Valve has been closed, SLOWLY open the Pressure Buildup Valve. While opening the Pressure Buildup Valve, watch the pressure increase on the pressure gage. Before the desired pressure is reached, close the Pressure Buildup Valve. The valve is closed before the desired pressure is reached because of the excess liquid in the pressure buildup coil. The expanding of this excess liquid will cause the pressure to be more than what is needed for transferring. For most transfers, 30 psi will be the desired pressure. Do not pressurize the LOX tank over 50 psi. Now, open the Vent Valve. You do not want to confine LOX.

Frame 11 (Cont'd)

Circle the correct answer for each of the following questions.

- 1. Which valve should be checked first for a transfer operation?
 - a. Fill and Drain Valve.
 - b. White color coded valve.
 - c. Capacity Gage Bypass Vilve.
 - d. Red color coded valve.
- Opening which valve actually allows the build up of a pressure in a LOX tank?
 - a. Capacity Gage Bypass Valve.
 - b. Vent Valve.
 - c. Fill and Drain Valve.
 - d. Pressure Buildup Valve.
- 3. Transferring of LOX can be started at what desired pressure?
 - a. 50 psi.
 - b. After the pressure buildup coil is empty.
 - c. 30 psi.
 - d. Before the pressure buildup valve is closed.
- 4. What would cause pressure in a LOX tank to exceed the desired transfer pressure?
 - a. Closing pressure buildup valve too early.
 - b. Liquid in pressure buildup coil.
 - Leaving vent valve open.
 - d. Not operating hose and tank pressure relief valves.

18



Answers to Frame 11: 1. c 2. d 3. c 4. b

Frame 12

So far you have made sure that the LOX tank from which you will transfer (source tank) has enough LOX for the transfer operation and you have built up enough pressure in the source tank for transferring LOX. Now, you will have to connect the transfer hose to both the LOX storage tank and the 50 gallon LOX cart that you will be filling. First of all, remove the dust cover from the fill and drain line on the storage tank. / Now, remove the dust cover from one end of the transfer hose. Connect the open end of the transfer hose to the storage tank fill and drain line. Remove the dist cover from the uncoupled end of the transfer hose. Place this open end of the transfer hose into a drip pan. Slightly open the Fill and Drain Valve on the source tank. Allow a small amount of liquid into the hose. When the liquid starts coming from the open end of the transfer hose, close the Fill and Drain Valve on the storage tank. The liquid in the transfer hose will evaporate. This evaporation action will clean (purge) the hose. Now you can remove the dust cover from the fill and drain line on the receiving tank. Then connect the transfer hose to the receiving tank.

Circle the correct answer for each of the following questions.

- 1. The transfer hose is connected to which tank first?
 - a. Receiving tank
 - b. Transport tank
 - c. 50 gallon tank
 - d. Source tank
- What is done with the open end of the transfer hose before it is purged?
 - a. Connected to receiving tank.
 - b. Placed in drip pan.
 - c. Remains closed when purging.
 - d. Placed on concrete pad.
- 3. Why is the transfer hose purged?
 - a. To coo! the hose.
 - b. To cool the hose coupling.
 - c. To clean the hose.
 - d. To check for obstructions

Answers to Frame 12: 1. d 2. b 3. c

Frame 13

If the LOX tank is empty at the time it is to be filled, you will first have to cool it down. To cool down a receiving tank, slowly open the Fill and Drain Valve on the source tank. Open it only enough to permit a partial flow of liquid. Maintain this reduced flow rate until the receiving tank will be cooled down. This process will require several minutes. A receiving tank will be considered to be cooled enough when the gas escaping from the vent slows down.

Once the receiving tank is cooled down enough, or if the tank is already cool, fully open the Fill and Drain Valve on the source tank. Leave the valve open until liquid LOX starts spurting from the vent on the receiving tank. This spurting of liquid LOX from the vent will indicate the receiving tank is full. At this point, close the Fill and Drain Valve on the source tank, and open the Vent Valve. Then close the Fill and Drain Valve on the receiving tank.

·Circle the correct answer for each of the following questions.

- 1. What flow rate is used when cooling down a LOX tank?
 - a. Reduced flow rate until gas coming from the ver. slows down.
 - b. Full flow rate until gas escapes from the vent.
 - c. Reduced rate until liquid escapes from the vent.
 - d. Full flow rate until liquid escapes from the vent.
- What is indicated by liquid LOX coming from the receiving tank's vent?
 - Tank is cooled down enough to increase flow.
 - b. Leak in tank piping.
 - c. Tank is full.
 - d. Leak at transfer hose coupling.

Frame 14

After the receiving tank is full, the transfer hose must be disconnected and stored. Also, a quantity reading will be taken. After the receiving tank is full, do not immediately disconnect the transfer hose. The LOX that is still in the transfer hose will cause pressure to be exerted on the hose. This pressure is relieved by pulling the control knob for the Hose Pressure Relief Valve. Hold this valve open until the pressure in the hose ceases to escape. Then disconnect the transfer hose from the receiving tank. Replace the dust covers on the hose and the fill and drain line on the receiving tank. Now, remove the hose from the source tank. Again, replace the dust covers on the other end of the transfer hose and the fill and drain line on the source tank. The transfer hose will be placed in the hose trough or other protective receptacle after the dust caps have been replaced.

Warning: Some liquid may remain in the hose even after the pressure has been released. Use caution at all times when disconnecting the transfer hose. Keep hose pointed away from personnel.

Circle the correct answer for each of the following questions.

- 1. Before the transfer hose is disconnected from the receiving tank, what must be done?
 - a. Open Vent Valve.
 - b. Pull Hose Pressure Relief Valve.
 - c. Close Vent Valve.
 - d. Push Hose Pressure Relief Vaive.
- 2. What causes pressure to remain in the transfer hose after the Fill and Drain Valves are closed?
 - a. Sudden stopping of the flow of LOX.
 - b. Liquid LOX remaining in the transfer hose.
 - c. Back flow of liquid LOX.
 - d. Liquid LOX escaping from the vent.

Answers to Frame 14: 1. b 2. b

Frame 15

The final step of a LOX transfer is to obtain a quantity reading. This may be done by determining the amount of LOX in either the source or receiving tank. However, the quantity reading will not be taken until the liquid has stebilized in the tank. The time required for the liquid to stabilize is usually 10 minutes. The reading is obtained by fully closing the Capacity Gage Valve. Do not forget to reopen the Capacity Gage Valve. The quantity of liquid transferred will be recorded on an AFTO Form 134.

Circle the correct answer for each of the following questions.

- 1. What must occur before a quantity reading is taken for a LOX transfer?
 - a. The receiving tank must be warmed up.
 - b. The liquid must be out of the transfer line.
 - c. The source tank must be warmed up.
 - d. The liquid must not be moving.
- 2. How long will the Capacity Gage Valve be left closed when getting a quantity reading?
 - a. 10 minutes.
 - b. Until the reading is taken.
 - c. Until the liquid has stabilized.
 - d. It is open at all times.

Frame 16

Review Exercise

true	For thor fal.	e first set of questions, indicate whether the statement is se.
1.	On LOX	tanks, the Capacity Gage is color coded black.
		True
		False
2.	The Veropen to	nt Valve and the Pressure Buildup Valve are the only valves o buildup pressure for a transfer operation.
		True
•		False
3.	The val	lve that is color coded blue on LOX tanks is the Fill and Drain
-		True
,		False
4.	The ,Tai	nk Pressure Relief Valve is used to relieve pressure after a ansfer is completed.
,		True
		False,
5.	The Ver	nt Valve on LOX tanks is color coded red.
•		True
		False
5.	Valves only.	on LOX tanks should be closed hand tight using a gloved hand
		True
		False
· ·	The blu	se color coded valve on LOX tanks is the Pressure Buildup Valve.
_		True
-		False

Frame 16 (Cont'd)

8.	After a LOX	transfer is finished, the pressure in the	transfer	hose
	is relieved	by pulling the Hose Pressure Relief Valve	open.	

True

False

For the rest of the questions, circle the correct answer for each of the questions.

- 9. How can you tell when the receiving tank is full during a transfer operation?
 - a. Gas escaping from the vent.
 - b. Transfer hose will frost over.
 - c. Gas escaping from the bypass line.
 - d. Liquid escaping from the vent.
- 10. Why is a small amount of liquefied LOX allowed into the transfer hose before it is connected to the receiving tank?
 - a. Make sure the source tank's Fill and Drain Valve opens freely.
 - b. Cool the attached coupling for a tighter fit.
 - c. Check for leaks in the transfer hose.
 - d. Purge the transfer hose.
- 11. What two valves are open when storing LOX?
 - a. Capacity Gage Valve and Fill and Drain Valve.
 - b. Capacity Gage Valve and Pressure Buildup Valve.
 - Capacity Gage Valve and Vent Valve.
 - Fill and Drain Valve and Vent Valve.
- 12. After a LOX transfer operation is finished, what is done after a 10 minute wait?
 - Reopen the Vent Valve.
 - b. Close the Vent Valve.
 - c. Close the Capacity Gage Valve.
 - d. Reopen the Pressure Buildup Valve.





- 13. What is the maximum pressure that should not be exceeded in a LOX tank?
 - a. 30 psi.
 - b. Until gas starts escaping from the Vent Valve.
 - c. 50 psi.
 - d. Until the fill and drain line is full.
- 14. Before an empty receiving tank is filled, what must be done to the tank?
 - a. Cooled down
 - b. Purged
 - c. 'Vacuum checked
 - d. Tank cleaned
- 15. Why should caution be used when disconnecting the transfer hose?
 - a. Prevent contamination from entering the transfer hose.
 - b. Prevent introduction of hydrocarbons.
 - c. Liquid may remain in the hose after pressure is released.
 - d. Liquid may leak from the bypass line.
- 16. Why should the Pressure Buildup Valve be closed before the desired transfer pressure is reached?
 - a. Prevent pressure from exceeding 50 psi.
 - b. Because of liquid in the pressure buildup coil.
 - c. So LOX will not be confined.
 - d. Prevent damage to the Capacity Gage Bypass valve.
- 17. The quantity of LOX transferred will be recorded on what form?
 - a. AF Form 134
 - b. AF Form 371
 - c. AFTO Form 134
 - d. AFTO Form 371
- 18. What two valves are checked for free operation before building up pressure in a LOX tank?
 - a. Capacity Gage Valve and Fill and Drain Valve.
 - b. Tank Pressure Relief Valve and Vent Valve.
 - c. Capacity Gage Valve and Vent Valve.
 - d. Hose Pressure Relief Valve and Tank Pressure Relief Valve.



Answers to Review Exercises, Frame 16

- 1. True
 - 2. 741se
 - 3. True
 - 4. True
 - 5. True
 - 6. True
 - 7. False
 - 8. True
 - 9. d
- 10. d
- 11. 0
- 12. c
- 13. c
- 14.
- 15.
- 16. t
- 17. c
- 18. d



A general inspection is to be performed on all LOX equipment. The following chart lists the items to be inspected, what the items are to be inspected for, and how often each item is to be inspected.

ITEM	INSPECTED FOR	FREQUENCY
Instruments	Cracked or broken gage faces.	Daily
	Damaged mountings and connections.	Daily
Hose ,	Excessive scuff guard wear.	Daily
•	Frayed wire in braid.	Daily
Fill and Drain Valve	Physical damage and worn or damaged parts.	Daily
Cabinet	Cleanliness and absence of foreign objects.	Daily
	Missing or damaged valve hardles.	Daily
Valves	Ease of operation.	Daily
	Leaks in bonnet or packing.	Daily .
Brake	Proper and easy operation.	Daily
Tank	General physical condition and loose or missing hardware.	Daily
Tires	Cracks, underinflation, deterioration, or other damage (30 psi pressure).	Monthly
Painted Surface	Corrosion, Rust, Damage, Peeling (Spot paint if deterioration constitutes less than 25 percent of the entire surface to be refinished; if 25 percent or more, refinish entire surface.).	Monthly ,



2678 Frame 17 (Cont'd)

In the following matching exercise, the lettered items are brief descriptions of what a specific item on the LOX equipment must be inspected for. Match the lettered items to their corresponding numbered items.

1.	Brake	4.	Daily cracks and deterioration
2,	Valves	b.	Monthly for corrosion and peeling
3.	Cabinet	•	pering
4.		c `•	Daily for loose or missing 'hardware
5.	Fill and Drain Valve	d.	Monthly for ease of operation
6.	Tires	e.	Daily for proper and easy operation
7.	Instruments		
8.	Tank	f.	Monthly for cracks, underinflation and deterioration
9.	Hose		461012018120
		g.	Daily for cleanliness and absence of foreign objects
		h.	Monthly for loose or missing parts
	-	i.	Daily for physical damage and worn or damaged parts

j.

1.

braid

Daily for ease of operation

Daily for damaged mountings

Daily for frayed wire in

and connections



Antwers to Frame 17: $\frac{e}{f}$ 6. $\frac{1}{1}$ 2. $\frac{g}{c}$ 3. $\frac{b}{k}$ 4. $\frac{1}{5}$ 5.

Frame 18

Réview Exercise

fal	Indicate whether $^{\prime}$ each of the following statements are true or se.
1.	Brakes on mobile LOX trailers will be inspected monthly for easy operation.
	True
	Faise
2.	The Fill and Drain Valve is inspected daily for physical damage and worn or damaged parts.
	True
	False
3.	The instruments on LOX equipment will be checked for damaged mountings and connections monthly.

If less than 30 percers of the painted surface of LOX equipment to be refinished has desert rated, the equipment will only be spot painted.

True False

4.

True

5. Each day the tank of LOX equipment is inspected for loose or missing parts.

____ True

·__ False

6. Instruments on LOX equipment will be inspected for cracked or broken gage faces daily.

True

____ False

7. Valves on LOX equipment are inspected daily for leaks in bonnet or packing.

_____ True
____ False

8. Excessive wear of the hose scuff guard is checked daily.

____ True
___ False

9. Tires on mobile LOX trailers are inspected daily to make sure they have 30 psi pressure.

____ True
___ False

10. LOX equipment cabinets are inspected daily for missing or damaged valve handles.

True

____ False




2881

Review Exercise Answers, Frame 18	3: 1.	False	2.	True	· 3.	False
•	4.	False	5.	True	6.	True
	7.	True	8.	True	9.	False
	10.	True				

Frame 19

We spoke of the construction of LOX storage tanks in the previous frames. In the next frames we are to talk about HEAT LOSS IN LOX STORAGE TANKS. Heat can be moved in three ways; conduction, convection, and radiation. The transfer of heat can be reduced or sleved down but it cannot be stopped. Heat transfer can be reduced to the point where it is practical to keep liquid oxygen. By reducing the amount of heat to the liquid oxygen in a LOX tank, the loss through vaporization is less. Note in the sketch below how the tank is built.



Cryotainer Construction to reduce heat transfer.

NO RESPONSE REQUIRED

Answers to Frame 19: NO RESPONSE REQUIRED

Frame 20

CONDUCTION

Heat is moved by conduction through some solid material such as metal, wood, or glass. Each type of material will move heat at a different degree or speed. To lower heat transfer by conduction, the aluminum inner tank is fastened to the aluminum outer tank by stainless steel supports, which are poor conductors of heat when compared with aluminum. Thus, the transfer of heat to the inner tank by conduction is slowed down. Look at the sketch in Frame 19, page 31.

Select the following statement(s) that is/are true.

- 1. Heat conduction is through a solid material.
- 2. Stainless steel is a good conductor of heat.



Answers to Frame 20: T 1. F 2.

Frame 21

CONVECTION

Heat moved with a fluid as a carrier or conveyer, is convection. All gas and liquids are fluids, thus, air which is a fluid is a good conveyor. One example is the heat given off by an old-fashioned heating stove or a camp heater. As the air near the stove gets heated, it expands and becomes lighter. This will cause the air to rise. Cool air from the floor then moves toward the stove and is heated. This continuous movement of air heats the whole room. Heat transfer by convection is reduced in an oxygon container by removing most of the air in the annular space with a vacuum pump. The annular space is the space between the inner and outer tanks as, you saw in the sketch in Frame 19.

Circle the letter in front of the correct answer.

- 1. Fluids are
 - a. water and oil.
 - b. water and air.
 - c. liquids and mercury.
 - d. liquids and gases
- Heat given off by a stove is called
 - a. conduction.
 - b. convection.
 - c. radiation.
 - d. conduction and convection.



Answers to Frame 21: 1. d 2. b

Frame 22


RADIATION

Heat that travels through space by waves or rays in place of air currents is known as heat transfer by radiation. The air is not heated as in the case of convection. A good example of this heat transfer is the radiant heat received from the sun. We know the earth receives most of its heat from the sun. An object on the earth absorbs the heat from the sun. The only known way to control radiant heat is to reflect the rays away from the object. Since the heat rays can travel through a vacuum, the annular space of the storage tanks is filled with a white powdery insulation. This reflects most of the heat rays away from the inner tank and the liquid oxygen, sketch in Frame 19.

Of the three types of heat transfer acting on the liquid oxygen tank, man can only change the transfer of heat by convection. The degree of vacuum in the annular space is what he controls.

Complete the following statements by writing in the correct word or words.

1.	Heat received from the sun is called
2.	Radiant heat may be controlled by reflecting the rays the object.
3.	Heat rays travel through a vacuum.



Atmospheric Pressure.

35

Answers to Frame 22: 1. radiation 2. away from 3. can

Frame 23

VACUUM

A perfect vacuum, related to liquid oxygen storage tanks, is the absence of all atmospheric air pressure. Air is all around the earth and extends out into space. The weight of all this air puts a pressure on the earth of 14.7 pounds per square inch at sea level. Look at the graph illustration (page 35) of what causes atmospheric pressure. This pressure (atmospheric) is in all cavities and tanks. The atmospheric pressure becomes less above sea level. For each 1000 feet above sea level, the pressure drops one-half pound per square inch (psi). Any pressure less than atmospheric pressure is a partial vacuum. Note the sketch on page 37 shows atmospheric pressure pushing a mercury column up the sealed (vacuum) end of the tube. The pressure of 14.7 psi (at sea level) will push the mercury to a height of 29.9 inches. Less pressure will raise the mercury in a less amount. The ratio is 1 pound of pre-sure for every 2 inches rise in a column of mercury. At an elevation of 6000 feet the atmospheric pressure of 11.7 psi will push the mercury column to 26.9 inches. See illustration on page 37.

Select the following statement(s) that is/are true.

1. Atmospheric pressure becomes higher above sea level.


2. Pressure less than atmospheric pressure is a partial vacuum.

3. A mercury barometer is used to measure a partial vacuum.



269

Barometer Used to Measure Atmospheric Pressure.



Operation of a Manometer.

ERIC

272

Answers to Frame 23: 1. 2. T 3. T

Frame 24

MEASUREMENT OF VACUUMS

One method used to show the degree of vacuum is based on the measurement of inches of mercury. A manometer can be used for this. The difference in the operation of a barometer is that a manometer will use atmospheric pressure as a known pressure and a partial vacuum as the unknown, illustration on page 38. Note in Example "A" that the mercury level will be equal in each side of the U tube (manometer) when both ends of the tube are open to atmospheric pressure. By connecting one side of the manometer tube to a vacuum space (the annular space of the tank) and then pump a vacuum in that space, the mercury level in the manometer will change, Example "B". Atmospheric pressure on the open end of the manometer tube will force the mercury up the tube connected to the partial vacuum. The mercury will rise in the direction proportional to the degree of vacuum that has been created by the pump. 'Examples B and C.

NC ESPONSE REQUIRED.

2890
Answers to Frame 24: NO RESPONSE REQUIRED

Frame 25

A vacuum of 28.9 inches of mercury is a high vacuum. But, in the annular space of a LOX tank, such a vacuum is still not high enough for storing liquid oxygen. The vacuum in the annular space should be as close as possible to a perfect vacuum (the absence of all pressure). manometer is a good instrument for measuring a vacuum to a tenth of an inch. But for measuring the vacuum in a LOX storage tank this is not good enough. To split vacuum readings in small increments less than tenths, the metric system is used. This unit of measurement is the micron. In C of the figure shown on page 38 the vacuum pump has pumped a low pressure or vacuum, equal to nearly 30 inches of mercury. As shown, the exact measurement is hard to determine. This is why a micron scale is used for measuring the vacuum in a LOX tank. One inch of mercury is equal to 25,400 microns; thus, the distance between 28.9 and 29.9 inches of mercury is equal to 25,400 microns. The micron scale shows the increments so the exact degree of vacuum can be seen. Instead of a manometer, the degree of vacuum in a LOX tank is determined by a vacuum gage with a micron scale.

Select the following statement(s) that is/are true.

- _____1. A manometer uses partial vacuum as a known pressure.
- _____2. Vacuum readings need to be divided into smaller readings than tenths.

289;


Answers to Frame 25: 1. T 2.

Frame 26

MICRON GAGES

The micron gage (vacuum gage) on LOX Storage Tank indicates the vacuum in the a nular space. Its scale is from 0 to 1000 microns. On the micron scale the less the reading, the greater the vacuum. As we said before, th greater the vacuum in the annular space the more difficult it is for heat to move by convection. So the greater the vacuum in the annular space of a LOX TANK the more efficient it is for storing LOX.

NO RESPONSE REQUIRED



- I. Pressure Relief Valve I
- 2. Purging Device
- 3. Button
- 4. Button or Switch
- 5. Knob
- 6. Pressure Relief Valve 6
- 7. Transfer Hose
- 8. Thermocouple Vacuum Gage
- 9. Vacuum Valve A
- 10. Capacity Gage
- 11. Pressure Gage
- 12. Vent Valve E

- 13. Pressure Build-Up Valve D
- 14. Fill-Drain Valve C
- 15. Capacity Gage Valve B
- 16 Transfer Hose
- 17 Vacuum Gage Assembly

Micron Gage.

When a 50 or 500 gallon tank is cooled down (has LOX in the inner tank) the vacuum in the annular space must be less than 250 microns. 2,000 or 5,000 gallon tanks must have a vacuum of 100 microns or less. Anytime the vacuum reading is more than that specified for storing LOX, the tank should be taken out of service. Check for leaks and recheck the vacuum holding capabilities. If there is not a vacuum in the annular space loss of LOX will result by evaporation. The micron gage (vacuum gage) is easy to use. It is a thermocouple tube and is on the panel of the tank control hood. To take a reading, place the toggle switch (4 on page 42) in the "on" position. While the switch is in the "on" position the needle of the gage 8 on page 42 should read zero. If the needle does not return to zero, adjust the black knob (5 on page 42 while pressing the contact button (switch 3 on page 42). Adjusting the potentiometer should make the gage needle return to zero. After the needle has been zeroed, release the contact button. The gage should now show the degree of vacuum.

Complete the following statements by filling in the blanks.

1.	After a 50 gallon tank has cooled down, the vacuum should be
	less than microns.
2.	Without a vacuum in the annular space, loss of LOX will result

						_
3.	The	micron	gage	is a	a	tube.

Answers to Frame 27: 1. 250 2. evaporation 3. thermocouple

Frame 28

REVIEW OF LOX STORAGE TANKS

Tanks for the storage and handling of LOX are made in many sizes. They range in size from small Dewar flasks (thermos bottles) for lab use to tanks with a capacity of many thousands of gallons for missile support. There are several different types of tanks used for storage and handling of LOX. A 50 gallon tank, mounted on a four-wheel trailer, is used to service aircraft. Other tanks have capacities of 500-, 2000-, and 5000 gallons. These are skid mounted and used for storage and transfer. All of these LOX Storage Tanks are constructed of two concentric cylinders, separated by the annular space. This space is filled with insulation, note page 45.

The temperature of liquid oxygen within tank is -297°F. Even so, there is a slight boiling at all times due to some heat transfer. This slight boiling governs the evaporation rate or liquid loss. The evaporation rate, by volume for every 24 hours with a full tank should not exceed:


Type MA-1 (50 gal) 3.0% Type C-1 (500 gal) 1.0%

No specified boiloff rates are given for the 2000 or 5000 gallon LOX storage tanks.

The tanks have piping, valves and gages used in operation. All of this equipment is accessible in the tank control hood as shown on page 45. A fill-drain line and a vent line connect the external piping to the inner tank, (items 17 and 19). The fill-drain lines contain porous filters which take out foreign particles from the final product. The vent line vents the inner tank to the atmosphere during normal storage. A pressure buildup coil (item 2) is connected between the vent and fill-drain lines. This coil acts as a heat exchanger and picks up heat to evaporate some liquid to pressurize the inner tank for liquid ransfer. A vacuum line is connected to the annular space near the top of the storage tank. This line is used to evacuate the air in the annular space (item 7) page 45.

Select the following statement(s) that is/are true:

1.	50-gallon tanks are used to service aircraft.
2.	All LOX storage tanks are made with two concentric cylinders.
3.	Temperature of liquid oxygen within a tank is -297°F.
4.	The fill-drain line is used to fill or drain the inner tank.
5,	The pressure buildup coil is connected between the vent and fill-drain lines.
6.	The vacuum line evacuates air in the annular space.



- 1. Pressure Relief Valve 1
- 2. Pressure Buildup Coil
- 3. Rupture Disc
- 4. Safety Disc
- 5. Safety Disc
- 6. Relief Valve b
- 7. Vacuum Line
- 8. Thermocouple Vacuum Gage
- 9. Vacuum Valve A
- 10. Capacity Gage

- 11. Pressure Gage
- 12. Vent Valve E
- 13. Pressure Buildup Valve D
- 14. Fill-Drain Valve C
- 15. Capacity Gage Valve B
- 16. Filter
- 17. Fill-Drain Line
- 18. Dampener Tank
- 19. Vent Line

Liquid Oxygen Cryotainer.

45



2876
Answers to Frame 28: 1. <u>T</u> 2. <u>T</u> 3. <u>T</u> 4. <u>T</u> 5. <u>T</u> 6. <u>T</u>

Frame 29

GAGES

Conveniently located on the LOX Storage Tank control hood are three gages: The inner tank pressure gage, a capacity gage, and the vacuum gage, page 45. The purpose of the vacuum gage (micron) indicates the vacuum in the annular space. The pressure gage indicates the pressure inside the inner tank when it is built up for the purpose of transferring liquid. It gives a reading in pounds per square inch. The capacity gage indicates the amount of liquid in a LOX Storage Tank.

NO RESPONSE REQUIRED



Frame 30

SAFETY

Carelessness in handling cryogenic fluids can result is bodily injury or damage to equipment. The extremely low temperatures can cause severe frostbite (burns) if allowed to contact human skin. High-purity oxygen greatly increases the potential for supporting combustion. Oxygen vapors mixed with such fuels as lesel fuel, tar, rags, or clothing can cause an explosion if ignited. There are many sources of ignition which can result in an explosion. A few of these sources are an open flame, lighted cigarettes, matches, static electricity, or scraping shoe nails against a concrete floor. Always wear tightly wow a cotton clothing whenever working with liquid oxygen. Do not wear woolen or nylon clothing because there is danger of static sparks caused by this material. Wear high-top shoes with sewn soles (no nails). Wear your trouser legs outside shoe tops to prevent spilling liquid into your shoes. Note in the sketch what we are talking about. In addition, wear a face shield, loose fitting heavy degreased gauntlet gloves, and a long rubberized or asbestos apron.

These protective devices are mandatory when handling liquid oxygen. Smoking or any other source of ignition must not be allowed within 50 feet of the area where liquid oxygen is handled or stored. Also do not smoke for at least 30 minutes after handling liquid oxygen. Clothing saturated with oxygen vapor could explode with a flash while lighting a digarette. Trovide adequate ventilation in areas where liquid oxygen is handled and stored. It is necessary to ground oxygen tanks during transfer and storage. Keep oil and grease, and any hydrocarbons away from an area where liquid oxygen is stored or transferred. Do not allow equipment to become contaminated. Cleanli ass of person, clothing, and equipment is a necessary.

The face shield must cover the entire face.

The cuis of the asbestos gloves must be tucked inside the sleeves of your uniform to prevent spills from running down inside the gloves.

The apron <u>must</u> cover the body at least down to the knees. It can be longer.

Shoes must be laced tightly and rubber boots may be worn as additional foot protection. Trouser cuffs must cover the tops of the shoes or boots.



Frame 30 (Cont'd)

Complete the following statements by filling in the word or words needed to finish the statement.

1.	The protective devices which are mandatory when handling liquid
	oxygen are a long, loose fitting
	and a
2.	Oxygen vapors mixed with or can cause an explosion if ignited.
3.	Always wear tightly woven clothing whenever working with liquid oxygen.
4.	It is necessary to oxygen tanks during transfer and storage.

Answers to Frame 30: 1. rubberized apron, gauntlet gloves, face shield

2. diesel fuel, tar 3. cotton 4. ground

Frame 31

Review Exercise

The following questions are to help summarize the macerial which has been presented in the preceding text. If you cannot answer the questions refer to the frame numbers at the end of the questions.

- 1. What are three ways in which heat can be transferred? (Frames 20, 21, 22)
- 2. Where is the annular space located in liquid oxygen storage tanks? (Frame 19)
- 3. What gages are located on the cryotainer hood? (Frame 29)
- 4. Define a perfect vacuum and explain how a vacuum is used to prevent vaporization. (Frame 23)
- 5. What type of gage is used to measure the vacuum in the annular space? (Frame 24)
- 6. When the tank is cool, how many microns are allowed in the annular space? (Frame 25)
- 7. What are the four types and sizes of storage tanks used with oxygen/nitrogen plants? (Frame 28)
- 8. Describe the capacity gage and its use. (Frame 29)
- 9. What defety devices are installed in the storage tanks to prevent excessive pressure? (Frames 6 and 7)
- 10. Why do the three main control valves have extended stems? (Frame 2)



Frame 32

From the following list of cryotainer components, match the function/operation to the numbered component.

- 1. Pressure gage 2. Filler valve 3. Transfer hose 4. Rupture disc 5. Pressure buildup valve 6. Capacity gage 7. Fill/drain valve 8. Vent valve
- a. For moving liquid from one tank to snother.
- b. Used to buildup pressure in the tank when needed to transfer.
- c. Measures pressure buildup within the tank caused by vaporizing LOX.
- d. Shows the amount of liquid oxygen in the tank.
- e. To release pressure in the inner tank and hose.
- f. Opened by 30 psi pressure from the LOX tank.
- g. To fill or drain liquid from the tank.
- h. Lets pressure out of the tank.
- i. Breaks when pressure in the annular space reaches 30 psig.
- j. Breaks if the pop-safety valve fails to open.



Answers to Frame 32: $\frac{c}{b}$ 1. $\frac{f}{d}$ 2. $\frac{a}{g}$ 3. $\frac{1}{h}$ 4. 2901

INSPECTION, MAINTENANCE AND OPERATIONAL PROCEDURES OF LOX EQUIPMENT

INTRODUCTION

In the first 32 frames we learned how the cryotainers were built. In these next frames we will learn how to maintain the parts which make up the cryotainer system. Methods of purging a contaminated storage tank will be explained. Operation of the vacuum pumps will be discussed and operator maintenance which will be required as well as a troubleshooting chart. All of these are necessary if we are to keep the equipment in the best possible condition for a long period of time.

Frame 33

Cleaning and Degreasing Liquid Oxygen Tanks

After the inner tank or inner lines of a storage tank have been repaired they may have a residue of flux, dirt, or oxidation. Cleaning, if required, is usually done by depot or contractor personnel. Normally, an organization does not have the equipment to degrease and clean the tank. Even though you may only help clean a tank you should know how it is done.

Procedures for Cleaning and Degreasing

Note: Before cleaning and degreasing the inner tank and lines of a storage tank, the tank must be drained, purged and warmed. Refer to TO 37Al2-1-101 for specific procedures.

Complete the following statement.

1.	The tank mus	t be	_,	, and	·	before
	cleaning and	degreasing.	•			

1907Answers to Frame 33: <u>drained</u>, <u>purged</u>, and <u>warmed</u>

Frame 34

The inner tank is cleaned with a degreasing solvent and trichloroethylene,. A degreasing machine is connected to the vent line of the tank. The tank fill/itain valve is closed and its vent valve is open. The degreaser pumps a degreasing solvent into the inner tank. The vapors from the degreasing solvent forms on the inner surface of the tank, washing any contaminants to the bottom. The pumping continues until the vapor pressure within the tank reaches 30 psig. degreasing machine is then disconnected from the tank and the vent valve on the tank remains open. Then trichloroethylene is pumped into the tank through the fill/drain line. With the cleaning solvent in the tank, the tank must be agitated. Slings are placed on the tank and it is lifted with a crane. The crane operator shakes the tank from end to end and side to side. then lowers it so the cleaning solvent can be removed. The tank is pressarized through the vent line with 30 psig of gaseous nitrogen. Then the fill/drain valve is rapidly opened to remove the solvent and residue. The above cleaning procedures are repeated to insure the inner tank is clean. The tank is then purged with the GSU-62/M purging unit to remove all traces of the vaporous degreasing solvent and cleaning solvent.

	Seled	t the following statement(s) that is/are true.
	_1.	The tank is pressurized with 30 psig of gaseous nitrogen.
***	_2.	Trichloroethylene is pumped into the tank through the buildup valve.
	3.	The tank is agitated once the cleaning solvent is inside.



Frame 35

INSPECTION OF STORAGE TANKS

(

Storage tanks operate under field conditions for long periods of time without major overhaul unless they are damaged through carelessness or accidents. The correct operation of the storage tank is the most important factor concerning safety and the storage of liquids. To maintain the tank in the best possible operational condition at all times, the following are checked as often as indicated:

- 1. Vacuum assembly. (Monthly)
- 2. Batteries (power supply for vacuum gage assembly). (Wee':1y) (Check for corrosion.)
- 3. Pressure relief valves. (Check as necessary by building up pressure in the cryotainer as specified in the TO.)
 - 4. Outer shell rupture disc. (Weekly)
- 5. Filter container. (Before use.) (Monthly, remove and clean with trichloroethylene.)
- 6. Hose transfer. (Before use; visually inspect.) (Also, once a month, pressurize with nitrogen or oxygen and leave overnight.)
- 7. Vacuum gage. (As necessary.) (At least weekly check the operation and microns of vacuum.)
- 8. Capacity gage. (As necessary.) (At least weekly check the reading and operation.)
- 9. Lines and valves. (Check daily for leaks.) (Visually inspect while under pressure.)
- 10. Pressure buildup gage. (Each time used or at least weekly.) (Check the operation.)
- 11. Valves (PBU, vent, fill/drain). (Daily). (Visually inspect and pressure test for leaks.)
- 12. Pressure buildup coil. (Weekly) (Visually inspect and pressure test for leaks.)
 - 13. Container. (Monthly) (Visually check for damage.)
- 14. Safety disc (vent and PBU). (Monthly) (Check for an accumulation of moisture and dirt.)

7704 Frame 35 (Cont'd)

Select the following statement(s) that is/are true.

1. Correct operation of storage tanks is an important factor concerning safety and storage of liquid oxygen.

2. Major overhauls must be accomplished very frequently.

3. The pressure relief valves are checked by building up pressure according to the TO.



2905

Answers to Frame 35: T 1. 2. T 3

Frame 36

Most of the above checks are made without disassembling the storage tank, but occasionally the hood assembly has to be removed. When disassembling the hood assembly make sure all the liquid oxygen has been removed from the tank. Removing the liquid oxygen and allowing the inner tank to warm up provides for safe working conditions. Use the proper tools to perform all maintenance. Always handle component parts and assemblies with extreme care to prevent creating new troubles. After disassembling, all parts that contact the liquid oxygen must be cleaned with trichloroethylene before they are replaced. DO NOT touch them with your hands; use clean gloves because the human skin contains oils which rub off on what you touch. When assembling component parts, use Teflon tape to seal each connection. Teflon tape does not react with liquid oxygen. All valve gaskets that have been removed must be replaced with new Teflon gaskets.

Select the following statement(s) that is/are true.

1.	Clean	gloves	must	be	used	when	handling	parts	that	contact	LOX
----	-------	--------	------	----	------	------	----------	-------	------	---------	-----

- 2. The hood assembly may be disassembled with LOX in the tank.
- 3. During maintenance Teflon tape is used to seal each connection.
- 4. Gaskets may be reused depending upon their condition.

1706Answers to Frame 36: <u>T</u> 1. <u>2. T</u> 3. <u>T</u> 4.

Frame 37

TESTING STORAGE TANKS FOR LEAKS

To test for leaks, pressurize the warm tank with dry oil-free air or N, gas. Never exceed the maxigum pressure specified in the applicable TO for the tank. With the tank pressurized, use a brush to completely coat all seams and connections with an approved oxygen leak test liquid soap. If there is a leak, bubbles will appear wherever the soap solution has been applied. To repair a leak, first release the pressure and then eliminate the leak by tightening, repairing, or replacing the faulty fittings. Repressurize the tank and then apply another coat of the leak test solution to make certain that the leak has been eliminated. If an approved oxygen leak test liquid soap is not available; a liquid solution made with water and ivory or castile soap can be used. These soaps are oil-free and safe for oxygen equipment. This type of solution is used in the same way as the preferred oxygen leak test solution. After the testing has been completed, use trichloroethylene to remove all traces of the testing solution from the equipment. While repairing any leak make sure that the equipment-does not become contaminated with oil or grease.

26T	ect the following statement(s) that is/are/true.
_1.	Nitrogen is used to test tanks for leaks.
_2 .	Any type leak test solution may be used.
_3.	To repair a leak all pressure must be released.
_4.	After testing the tank must be cleaned with trichloroethylene.

2907

Answers to Frame 37: T 1. 2. T 3. T 4.

Frame 38

SERVICING THE PRESSURE GAGE

The pressure gage, shown in figure on bottom of page 74, measures the pressure buildup within the tank which is caused by the "vaporizing" of the liquid oxygen in the pressure buildup coil. The gage is located in the vent line which prevents liquid oxygen from reaching the gage. It measures the gas r essure in pounds per square inch and will not measure liquid pressure. This gage is one of the most important instruments to the operator, especially when transferring liquid. Air Force specifications require a pressure of approximately 30 psi for most transfers. The tank pressure should never be allowed to build up higher than 30 psi.

Note: If for some reason the gage does not work and the popsafety valve and the safety disc are not working properly because of frozen moisture or dirt, the tank could build up sufficient pressure to rupture itself. Such a rupture would cause a great deal of equipment damage, severe injury, or fatalities.

Complete the following statements by filling in the blanks.

1.	Pressure buildup within the container caused by vaporizing liquid
-	oxygen is measured by the
2.	To prevent liquid oxygen from reaching the pressure gage, the gage is
	located in the
3. /	When transferring liquid oxygen, the tank pressure should never
	exceed

, 2908`

Answers to Frame 38: 1. pressure gage 2. vent 11 ie 3. 30 psi

Frame 39

A defective pressure gage can measure either low or high. If the gage measures high, there will be insufficient pressure to transfer the liquid. In case the gage measures low, the pressure can exceed the normal transfer pressure of 30 psi, causing the pop-safety valve to operate or the fety disc to rupture. Under no circumstance should the pressure in tank exceed 45 ± 5 psi, the pressure needed to operate the pop-safety e, You can detect a faulty gage while making a transfer or by the operation of the safety valve. If you determine that the pressure gage is defective, replace the complete gage assembly immediately.

- 1. A defective pressure gage can measure either high or low.
- 2. The tank pressure should never exceed 45 ± 5 psi.
- 3. If the gage is determined to be defective, replace the complete gage assembly.

2909

Answers to Frame 39: $T \setminus 1$. T = 2. T = 3

Frame 40

SERVICING THE CAPACITY GAGE

The capacity gage, shown in figure on bottom of page 74, operates the same as the bellows used by a blacksmith. As the pressure goes up on the bellows, the needle of the gage moves toward maximum. The operation of the gage is all mechanical, using the pressure caused by the weight of the LOX in the tank to expand the bellows of the gage. Movement of the bellows moves the needle, in reference to the pressure on the second bellows, to show the amount of LOX in the tank.

A defective tapacity gage will show no measurement, or indicate a smaller quantity than is stored in the tank. To replace a defective gage, remove the complete gage assembly. The letters P (liquid side) and S (gas side) on the back of the gage indicates how the gage assembly is to be installed, shown in figure on bottom of page 74. If the gage is not correctly installed, it will become damaged or give a wrong reading of the liquid oxygen in the tank.

Fill in the blanks to complete the following statements.

1. As the pressure goes up on the ______, the _____ of the gage moves toward _____.

2. To replace a defective capacity gage, the complete assembly must be _____.

3. If the gage is installed incorrectly, it will give a _____ of the liquid oxygen in the tank.

Answers for Frame 40: 1 bellows, needle, maximum 2. removed
3. wrong reading

Frame 41

The capacity gage is a sensitive differential pressure gage. It is protected by the surge tank which reduces the surging of gas or liquids within the gage lines. An added feature that protects the gage from high-pressure surges are the .013 inch orifices which reduce the high pressure entering the gage.

When transferring liquid oxygen the capacity gage bypass valve is always open. This is to protect the capacity gage from high pressure and sudden surges during the transferring operations. When transferring, the liquid oxygen is boiling, thus it induces a great disturbance within the tank. If the capacity gage bypass valve were closed, this disturbance would damage the gage.


1.	The capacity gage bypass valve is closed when transferring liquid
2.	The surge tank protects the buildup system from sudden pressure changes.
3.	The capacity gage is a sensitive differential pressure gage.
40	Orifice siz has a definite bearing on the gage's operation.

Frame 42

ADJUSTING THE FOP-SAFETY VALVE

The pop-safety valve is set to open at 45 ± 5 psi and protects the equipment and operator. This type of valve can be adjusted to operate at the correct pressure if necessary. If an adjustment is required, the valve is installed in a test stand. If a test stand is not available, the pressure test can be performed by connecting the valve to a compressed air source of 45 ± 5 psi.

Cantion: Use a calibrated air pressure gage to determine the pressure of the air source.



- Cover valve '
- 2. Washer valve spring
- 3: Spring
- 4.7 Stem
 - 5. Pin
- 6. Nut star
- 7. Star disk ~
- 8. Ring volume adjusting
- 9. Base assembly and sept

- · 10. Screw lock adjusting ring
- 11. Screw pressure adjusting
- 12. Nut lock pressure adjusting
- 13. Nut →valve stem (som cases 2 each instead of pin cutter #14)
- 14. Pin Cotter
- 15. Cap
- 16. 'Screw cap holding
- 17. Lever manual release
- 18. Pin lever to cap

Pop-Safety Valve.

- 1. The pop-safety valve protects the equipment and the operator.
- _____2. To adjust the valve, it is installed in a test stand or connected to a compressed air source of 45 ± 5 psi.

Answers to Frame 42: T 1. T 2.

Frame 43

To adjust the valve, remove the cap and lever (15 and 17, Frame 42) from the valve to expose the pressure adjusting screw (11, Frame 42). Slowly turn this screw to increase the pressure on the valve to the popping pressure of 45 ± 5 psi. Adjust the pressure adjusting screw (11, Frame 42) until the air pressure on the lower part of the disc is slightly more than the spring tension which holds the disc on its seat. When this point is reached, the air pressure will force the disc off of its seat. This will cause the valve to pop. Check the valve to make certain that it pops at the correct pressure. Tighten the nut and replace the cap and lever. Be sure to clean the valve assembly in trichlorouthylene and replace it as a complete assembly. After replacing the pop safety valve, test the tank for leaks with compressed air and an approved liquid soap solution.

\$elect the following statement(s) that is/are true. *

1. When air pressure forces the disc off its seat the valve will pop.

2. The popping pressure of the pop-safety valve is 45 \pm 5 psi.

3. The valve must be cleaned with soap solution prior to reinstallation.

4. An operational check of the valve is required after adjustment.

5. After installation on the tank a leak check is required using an approved soap solution.

Frame' 44

There are two foil discs on most cryotainers. These are called safety discs, and are in the lines in parallel with the pap-safety valves. If the pop-safety valves fail to open or cannot get rid of

the pressure fast enough, the discs will break and help to vent the

pressure.

Most tanks have a third disc, called a rupture disc, which breaks at 30 psig. If a leak should develop in the inner tank, liquid will escape into the annular space, gassing off and building pressure in the space between the tanks.

Fill in the blanks to make a complete statement.

The safety device which is in the line in parallel with the

pop-safety valve is the

- The rupture disc will break at psig.
- The safety disc will break if the por-safety valve fails to

Answers to Frame 44: 1. safety disc 2. 30 3. open

Frame 45

SERVICING THE FILLER VALVE

The filler valve is located on the hose assembly that is used to transfer liquid oxygen from the LOX tank to the aircraft. Before liquid oxygen can be transferred to an aircraft the hose is connected to the LOX tank. Then the hose assembly is purged by opening the LOX tank fill/drain valve. When the female connector is plugged in the aircraft, the liquid oxygen begins to flow from the LOX tank. The pressure (30 psi) in the LOX tank will cause the liquid oxygen to flow by exerting sufficient pressure on the filler valve to open it. Often the filler valve will leak or freeze. This valve must be very closely checked to see if it functions properly. A filler valve that leaks will cause a loss of liquid oxygen, which is a safety hazard to operators. Do not use force to disconnect a frozen, valve from the aircraft. This can cause damage to the filler valve. In case the valve is frozen, it can be thawed with water or by the ambient air, providing the flow of liquid oxygen is stopped for a short time. To stop the flow of liquid oxygen the operator must close the fill/drain valve and relieve the pressure from the nose by operating the hose pressure relief valve. Refer to illustration on page 65 figure 5, for an illustration of a filler valve.


Select the following statement(s) that is/are true.

1.	The transfer hose must be purged prior to aircraft servicing.
2:	The servicing valves seldom leak.
3.	Servicing valves should never be forced onto filler valves.

4. Pressure must be relieved from the hose after servicing operations are complete.

Frame 46

The second common trouble is leaks between the disc and seat. When this is known install a new valve. A valve that has a damaged disc or seat is detected by a leak in the lines, thus the lines will frost. Liquid loss in the LOX storage tanks should be limited to evaporation, some spillage, and gas out through the vent line.



Filler Valve.

	Complete the following statements by filling in the Blank	s.
۱1.4	Another common trouble with the filler valve is	between j
-	the and	
2.	A leak in a line is detected by on the line.	
3.	Liquid loss in the storage tank should be limited to, and gas out the line.	

29/6.


Answers to Frame 46: 1. Leaks, disc, seat 2. frost

2. evaporation, spillage, vent

Frame 47

SERVICING THE HOSE ASSEMBLY

The tank and servicing hose couplings are made to hold the pressure and temperature, and slow down the loss of liquid oxygen through transfer and handling. Check the ends of the hose for foreign material before each transfer. Do not drag the hose assembly or run over it with any vehicle. Both of these will break or damage the hose. This will cause it to leak. Leaks can be found by frose spots on the outside of the hose. The transfer hose is for moving liquid from one tank to another.




Tank and Servicing Hose Couplings.

1.	Frost spots on the outside of the hose indicates a leak.
2.	The hose must not be dragged or run over with a vehicle.
3.	The hoses are fairly durable and us not require special handling.
4.	Hoses should be checked for FOD prior to use.

Frame 48

SERVICING THE VENT, PRESSURE BUILD-UP, AND FILL/DRAIN VALVES

These valves are all similar in design and are globe valves. Two troubles are common to globe valves; stem leakage and leakage between their discs and seats. The most likely trouble is the leakage between the stem and packing, which is easy to fix. Stem leakage occurs only while the valve is open because all globe valves are installed so that the pressure is against the seat and disc when the valve is closed. An arrow is often stamped on the valve body which shows the correct installation according to the direction of flow. Visually inspect the valve through its two openings before installation, this will also show you its correct installation according to the direction of flow. To stop the packing from leaking, torque the packing nut. If a valve is frozen from meisture, pour water over it to thaw it out.



- 1. Bonnet
- 2. Stem
- 3. Nut Disc
- 4. Disc Valve
- 5. Gasket
- 6. Seat Valve
- 7. Body Valve

- 8. Ring Packing
- 9. Packing
- 10. Gland Packing
 - 11. Nut Packing
- 12. Handwheel
- 13. Disc Identification
- 14. Nut Handwheel

Globe Valve.

Caution: Do not torque the packing nut too much. If the leak does not stop under normal tension on the nut, remove the pressure from the system and remove the packing nut. Replace the old packing with a new teflon packing ring.

These values are used for just what their names imply. The vent value lets pressure out of the tank when it is no longer needed to transfer. The pressure buildup value is used to build up pressure in the tank when needed for liquid transfer. The fill/drain value is used to fill or drain liquid from the tank.

- 1. The most likely leaks on globe valves is between the stem and seats.
 - . An arrow on the valve body indicates the direction of flow.
- 3. If the packing is leaking it must be replaced.
- 4. If the valve freezes, water may be used to thaw it out.

29/9

Answers to Frame 48: T 1. T 2. T 3. T 4.

Frame 49

TROUBLESHOOTING

The method used to find the various troubles associated with liquid oxygen storage tanks is a systematic procedure of elimination. In order to use this method, it is important to know fully the operation of these tanks. Since troubles which occur with tanks are numerous, it is neessary to refer to a troubleshooting chart, Table 1, pages 70 and 71. Study the various troubles, their probable cause, and remedies.

There are other malfunctions that may occur; but they are of a minor nature and will not affect the transfer, storage, or safety in handling of liquid oxygen. A small amount of mechanical ability and a little common sense will generally suffice to make necessary repairs, since the malfunction and the solution are generally quite obvious. For information about the procedures used in making the repairs or replacements indicated in the troubleshooting chart, refer to TO 37Al2-1-101 which contains the repair instructions.

1.	Troubleshooting storage tanks is a systematic process of elimination.
2.	Troubleshooting charts are used to help you troubleshoot the system.
3.	In order to troubleshoot, a thorough knowledge of the tank operation is required.
4.	Repair instructions will be found in the applicable TO

• • •					_		
Answers	to	Frame	49:	T1.	$\frac{\mathbf{T}}{2}$.	T_3.	<u>T</u> 4.


Safety disc Defective pop safety value Replace Defective or kinked disc Replace Defective gage Defective gage Disc not centered Replace Replace Defective gage Disc not centered Replace Replace Defective gage Defective gage Defective gage Defective gage Defective gage Defective gage Plugged Defective Gage Defective gage Plugged Defective Gage Plugged Defective Gage Defective Gage Plugged Defective Gage Defect	
Defective or kinked disc Replace Defective gage Lines frozen or plugged Replace Thaw or clean Pressure gage does not show any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose Replace Unplug Tighten connect Replace Unplug Replace Unplug Replace Unplug Replace Unplug Replace Unplug Replace Replace Unplug Replace Replace Unplug Replace Unplug Replace Replace Replace Replace Unplug Replace Replace Unplug Replace Replace Replace Replace Replace Unplug Replace Replace Replace Replace Replace Unplug Replace Replace Replace Replace Unplug Replace Repl	
Defective or kinked disc Replace Disc not centered Replace Replace Defective gage Lines frozen or plugged Thaw or clean Pressure gage does not show any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose Replace Depair or replace Replace Unplug Tighten connect Replace Unplug Replace Unplug Replace Unplug Replace Unplug Replace Unplug Replace Unplug Replace Replace Unplug Replace Unplug Replace Unplug Replace Replace Unplug Replace Replace Replace Unplug Replace Replace Replace Unplug Replace Unplug Replace Replace Replace Replace Replace Unplug Replace Replace Replace Replace Unplug Replace Replace Replace Replace Unplug Replace Replace Replace Replace Replace Replace Unplug Tighten connect Replace Repl	
Malfunctioning of capacity gage Unstable liquid condition Leak in gage line Clogged line Defective gage Lines frozen or plugged Pressure gage does not show any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose To gage not Bateries dead Tighten or repl packing Wait Tighten connect Replace Replace Close' vent and buildup v Fill Replace Unplug Tighten connect Acpair of repla	
Malfunctioning of capacity gage Unstable liquid condition Leak in gage line Clogged line Defective gage Lines frozen or plugged Pressure gage does not show any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose TC gage not Balteries dead Tighten or replancking Wait Tighten connect Replace Replace Replace Unplug Tighten connect Acpair of replance Replace Unplug Tighten or replance Tighten connect Acpair of replance Replace	
Unstable liquid condition Leak in gage line Clogged line Defective gage Lines frozen or plugged Pressure gage does not show any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose TC gage not Balteries dead Packing Wait Tighten connect Replace Replace Replace Unough and buildup v Fill Replace Unplug Tighten connect Replace No pressure Replace Unplug Replace Replace Replace Replace Replace Replace Replace Replace Replace	
Leak in gage line Clogged line Defective gage Lines frozen or plugged Pressure gage does not show any pressure Empty container Plugged lines Plugged lines Defective gage Plugged lines Needle valve loose TC gage not Batteries dead Tighten connect Replace Replace Plugged Tighten connect Replace	lace,
Leak in gage line Clogged line Defective gage Lines frozen or plugged Pressure gage does not show any pressure Empty container Plugged lines Plugged lines Loose or leaky fittings Needle valve loose TC gage not Bateries dead Tighten connect Replace Replace Plug Vent And buildup v Fill Replace Unplug Tighten connect Replace Replace Replace Replace Replace Replace Replace Replace Replace	
Clogged line Defective gage Lines frozen or plugged Pressure gage does not show any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose TC gage not Batteries dead Replace Replace Replace Fill Replace Unplug Tighten connect Aepair of replace	ion
Defective gage Lines frozen or plugged Pressure gage does not show any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose TC gage not Balteries dead Replace Thaw or clean Close' vent and buildup v Fill Replace Unplug Tighten connect Replace Replace Replace Replace	
Pressure gage does not show any pressure Defective gage Plugged lines Loose or leaky fittings Needle valve loose TC gage not Balteries dead Replace	
Pressure gage does not show any pressure Empty container Defective gage Replace Plugged lines Loose or leaky fittings Needle valve loose TC gage not Balteries dead Close' vent and buildup v Fill Replace Unplug Tighten connect Aepair of repla	
does not show any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose TC gage not, Balteries dead Empty container Fill Replace Unplug Tighten connect Aepair or repla Replace hose	
any pressure Empty container Defective gage Plugged lines Loose or leaky fittings Needle valve loose Tighten connect Replace Replace Replace Replace Replace hose TC gage not, Balteries dead Replace	ual was
Defective gage Replace Plugged lines Unplug Loose or leaky fittings Tighten connect Needle valve loose Replace Leaky transfer Damaged Replace hose TC gage not Balteries dead Replace	/alves
Plugged lines Loose or leaky fittings Needle valve loose Leaky transfer hose Plugged lines Unplug Tighten connect Replace hose Replace hose	
Loose or leaky fittings Tighten connect Repair of repla Leaky transfer Damaged Replace hose TC gage not Balteries dead Replace	
Leaky transfer Damaged Replace hose TC gage not Balteries dead Replace	- 1
Leaky transfer Damaged Replace hose TC gage not Balteries dead Replace	
TC gage not, Balteries dead Replace	
reading (but you loose electrical connections lighten	
Defective gag Replace	
Safety disc Wrong size disc Replace does no blow at prescribed pressure	
Pressure relief Frozen . Warm, work open	
valve (does not Leak Replace, adjust open at prescribed pressure setting	

Table 1. Troubleshooting Chart.



TROUBLE '	PROBABLE CAUSE	REMEDY
V -		
Flow of liquid	Foreign matter in hose	Purge, clean filters
restricted	Defective fill/drain valve	Repair or replace
No pressure	Vent valve open	Close valve
buildup	Defective pressure gage '	Replace gage
,•		Warm up
•	Insufficient LOX	Refill
	Safety disc ruptured	Replace
•		Unplug
_	Leaks in lines and valves	Check fittings
Losing vacuum	Rupture disc blown	Replace
	Leak in weld	Reweld outer shell
	Defective gage	Replace
	Dirt in "O" ring grooves	lean and replace
	Vacuum tube leaks	Replace
	· Opened vacuum valve	Check safety wire
•	Defective diaphragm on	•
	the vacuum valve	Replace
	Leak through rough edges of	
arching.	rupture disc	Cut foil, replace
	Gasket leak	Replace

Table 1. Troubleshooting Chart (continued).




Thermocouple Gage and Tube.

SERVICING THE VACUUM GAGE ASSEMBLY,


Turn on the toggle switch, figure aboye, push the momentary on switch and the gage should give a reading of zero. If the gage needle does not go to zero, adjust the potentiometer knob while pressing the momentary contact switch. Turn the potentiometer knob until the gage needle goes to zero. Then release the momentary contact switch and the gage should give the correct micron reading. If this adjustment does not cause the gage needle to return to the zero position, the batteries are probably dead. If the batteries are replaced or it is determined that they are in good condition, the TC (thermocouple) tube is probably defective. Replace the thermocouple tube by unplugging it from the female connector (the electrical cable connection to the gage). Now close the small diaphragm valve (vacuum valve) to prevent the loss of vacuum. With the valve closed, the thermore uple tube can be removed and replaced. Place teflon tape on the threaded connections, to prevent leakage, and replace the thermocouple tube to the female cable connector and gage cable. The gage should now operate properly. If not, the wiring within the cable may be defective. Diagram shown on top of page 73 is a complete wiring diagram and should be used to check for defective circuits.

- 1. If the gage needle will not zero it must be replaced.
 - 2. The vacuum valve must be closed to change the thermocouple.
- 3. The game cannot be adjusted unless the momentary contact push switch is depressed.
- ____4. Teflon tape is required when replacing the thermocouple.





Thermocouple Wiring Diagram.




Differential Gage System.

PRINCIPLES OF OPERATION OF A VACUUM PUMP

The model KS-13 vacuum pump, illustration below, is an air-cooled, single stage, mechanical pump. The pump is designed to pump air out of the annular space of a LOX tank.

When pumping a vacuum the molecules of gas (air) in the annular space of the LOX tank must be removed. The air is pumped cut by a high-vacuum pump. The term "high vacuum" is used rather loosely for pressure:/below lmm (mercury). It can be said that high vacuum is the molecules of gas colliding more often with the wall of the tank than with each other. Pumps that are effective at ordinary pressures become inoperative with high vacuums. In a previous study guide, you should recall that a partial vacuum can be measured in inches of mercury by a barometer or manometer. To measure the small degree of pressure (vacuum) that is required for storing liquid oxygen a micron is used as the unit of measurement: (25,400 microns are 1 inch of mercury pressure.)




Model KS-13 High Vacuum Simplex Pumping Assembly Operating Valves.

- 1. The KS-13 vacuum pump is used to evacuate the annular space between the inner and outer walls of the LOX tank.
- 2. Vacuum is measured in microns.

Answers to Frame 51: <u>T</u> 1. <u>T</u> 2


Frame 52

The effectiveness of a high-vacuum pump depends on the oil seal that is formed between the piston and the inside of the pump chamber, illustration below. A source of newer is applied to the pump shaft, causing the circular movement of the piston. As the piston moves in its circular motion, a suction or low pressure is formed in the pump. The low pressure is developed with each turn of the shaft and piston. The intensity of the low pressure, formed in the pump, depends on the quality of the oil seal. Thus, the low pressure will cause the molecules of air to flow in the inlet of the pump. The movement of the air molecules in the pump is indicated by the arrows shown in the pump inlet, illustration below.



Cycle of Operations.

The low pressure in the pump pulls the molecules of air from the LOX tank being pumped. The air is drawn through the inlet (vacuum) hose into the cylinder when the piston is in the down ctroke. On the up stroke of the piston, the air molecules removed from the LOX tank, are forced out the the outlet valve and discharged through the oil separator, page 77, to the atmosphere. Repetition of this operation for a period of time continues to improve the vacuum in the tank.



Model KS-13 High Vacuum Pump Assembly Oil Separator.


- 1. The effectiveness of the vacuum pump depends on the teflon seal between the piston and outside chamber.
- 2. Air is pumped from the LOX tank, thru the pump and descharged to atmosphere.
- 3. As the piston moves in its circular motion, a suction or low pressure is formed in the pump.

1928.
Answers to Frame 53: _____1. __T

r_2. <u>r_</u>3

Frame 53

The model KTC-21 vacuum pump, below, is a three cylinder air-cooled; two-stage, mechanical pump. The pump is designed to evacuate the annular space of a cryotairer.



Frame 54

VACUUM PUMPING OF LIQUID STORAGE TANKS

When the vacuum of a tank, with liquid in the inner tank, is greater than the micron reading specified by the applicable TO, a pump-down is required. Prior to pump-down of the vacuum in the annular space of a LOX tank, be sure the inner tank is empty and warm. After the inner tank has been drained, a hot purge kit is used to warm the inner tank before pumping the vacuum. The lower the vacuum reading, the more effective the tank is for storing LOX.

When vacuum pumping has been completed, the vacuum value on the tank is closed tightly before the pump is stopped. This value is then rewired in the closed position. Removing the pump and then filling the tank with liquid oxygen is the way to determine if the vacuum in the insulated annular space is sufficient to store liquid oxygen. The procedures for vacuum pumping the insulated annular space of a LOX storage tank are listed in TO 37A12-1-101. These TO procedures and checklist must be followed during operation.

Note: Many more hours of pumping will be required to pump down the vacuum if the inner tank has liquid oxygen in it.

1.	The tank must be warm and empty prior to pump down.
2.	The higher the vacuum reading the more efficient the tank is for storing LOX.
3.	After pump down is completed the vacuum valve is safety wired in the closed position.
<u></u> 4.	Vacuum pump down may be accomplished quicker if LOX is in the tank during pump down.



2930Answers to Frame 54: <u>T</u> 1. <u>2. (T</u> 3. 4.

Frame 55

VACUUM PUMP OIL


The oil used in the vacuum pump is MIL-L-83767, Tape IL

Tricresylphosphate is a special grade of oil used in oil-seated vacuum pumps. It has the two characteristics that are required for best operation at high vacuum.

- 1. A very low vapor pressure which does not rise materially at temperatures up to 122 F.
- 2. A degree of viscosity which does not become too great at temperatures of 60°F and which stays the same at temperatures of up to 122°F.

The low vapor pressure is of extreme importance for use in all vacuum pumps. Because of the high vacuums involved, any fraction with appreciable vapor pressure, even in minute quantities, remaining in the oil reduces the speed of evacuation. This oil must always be used to achieve the guaranteed performance of all oil-seated vacuum pumps.

1.	Tricresylphosphate is a special oil used in vacuum pumps.
	Oil is used to achieve the "seal" in all oil seated vacuum



2432

Answers to Frame 55: T 1. T 2.

Frame 56

Tricresylphosphate is a toxic oil. While you are operating or servicing the vacuum pump, the lubricant may come in contact with your skin. If this happens, wash the affected area thoroughly with soap and water. Any time the pump is to be operated make sure it is in a well ventilated area. Avoid breathing the vapors from the pump exhaust.

The oil in the vacuum pump should be changed when it becomes dirty or contaminated. Anytime the oil becomes discolored it is an indication of contamination. This oil normally is clear. In case of an emergency, oil can be poured through a strainer and dry nitrogen blown through it to take out any trace of moisture.

Select the correct statement(s) that is/are true.

1.	Tricresylphosphate is toxic and should not be allowed	to com
	in contact with the skin.	

- 2. The pump may be operated indoors in a closed area.
- 3. The oil must be changed after 200 hours of pump operation.

Answers to Frame 56: __T_1. ____2. ___3

Frame 57

PERIODIC INSPECTION OF VACUUM PUMP

To keep the vacuum pump in a safe operational condition the following items should be inspected as indicated:

- 1. Lubricant: When applicable, drain a small amount of oil through the drain valve on the oil separator into a glass container. Let it set for 1 hour, then examine for solid particles, sludge, and water.
- 2. Check oil level daily for first week of operation and weekly thereafter. Oil level should be midway on the sight glass when operating at low inlet pressures.
 - 3. Inspect suction filter each 250 hours.
 - 4. Inspect oil mist eliminator each 250 hours.
 - 5. Check cart casters (apply correct grease) each 100 hours.
- 6. Check all attaching hardware for security, damage, and wear each 250 hours.

NO RESPONSE REQUIPED

2934
Answers to Frame 57: NO RESPONSE REQUIRED

Frame 58

The air purging unit, type GSU-62/M, is intended primarily for use in purging liquid oxygen storage tanks, two illustrations shown on next page.

PURGE UNIT

The motor is a 5 - horse power, 3-phase, 60-cycle unit operating at 3600 rpm. The motor is designed to operate on 220 or 440 volts AC.

The blower is a rotary, positive displacement, 3-lobe rotor designed unit. It is capable of delivering oil free air to the heater at 6 pounds per minute. The blower end plates have oil passages to allow free flow of lubricant between the bearings and seals without contaminating the air being delivered.

The heater assembly consists of six electrical heating elements mounted in an insulated cylindrical chamber. Its purpose is to heat the incoming air from the blower that is thermostatically controlled. The air at the outlet of the purge unit is 35°F.


The air intake opening of the blower is protected by a permanent type washable filter. The air filter can be disassembled and cleaned by washing it in water and a household detergent. Wipe the filter and blow it dry after cleaning.

From the list of statements below, match the component to its stated purpose/function.


- Used to heat the incoming air from the blower
- Can be disassembled and cleaned by washing it in water and a detergent.
- Capable of delivering oil-free air to the heater at 6 lbs per / minute.
- 4. A 5 hp 3 ph. 60 cycle unit which operates at 3600 rpm.

- a. motor
- b. blower
- c. heater assembly
- d. air filter





Air Purging Unit, Type GSU-6/2/M - Left Side.



- 1. Heater assembly.
- 2. Motor.
- 3. Blower.

5.

Electrical power calle.

Air Purge Unit, Type GSU-62/M - Right Side.

85



Answers to Frame 58: 1. c 2. d 3. b 4. a

Frame 59

HEATER MAGNETIC CONTACTOR

This control receives power from the heater circuit breaker and is controlled by a thermoswitch located in the heater outlet line. If the heater outlet temperature exceeds 350° F, the magnetic contactor will cycle automatically and interrupt power to the heater.

THERMOSWITCH

This switch is factor adjusted at 350°F. In the field, you can adjust the switch with a screwdriver. Rotate the adjustment clockwise to increase the temperature setting and counterclockwise to decrease it.

Caution: Do not attempt to change the temperature setting more than a few degrees at a time.

OVERHEAT THERMOSTAT

This is a protective device located inside the control panel, but its sensing element is in the heater chamber. The overheat thermostat is factory set at 400°F, but it can be readjusted by rotating the control knob. If this thermostat opens, the entire 110 volt control will be disconnected and the blower and heater will not operate.

1.	In the field, the thermoswitch can be adjusted with a screwdriver
2.	If the heater outlet temperature exceeds 350°F, the magnetic contactor must be cycled manually.
3.	If the overheat thermostat opens, the 110 volt control is disconnected.

2937

Answers to Frame 59: T 1. 2. T 3

Frame 60

PRESSURE SWITCH

The pressure switch is activated by air through a connection on the blower outlet. Its purpose is to check for positive air pressure and must remain closed for blower operation.

TIME DELAY

The time delay relay is a thermal relay that provides the initial method of starting the motor. However, 45 seconds after the motor is started the relay will open and the pressure switch will maintain motor operation.

OPERATING CONTROLS

HOURMETER

The hourmeter is a time totalizer which indicates the number of hours the equipment has been in operation. It serves as a guide for determining when the unit is to be inspected.

NO RESPONSE REQUIRED



2938
Answers to Frame 60: NO RESPONSE REQUIRED

Frame 61

THERMOMETER

There are two dial gages. One, which is located on the outlet line of the heater, indicates the outlet air temperature of the heater. The other is a clamp-on device, which indicates the temperature out of the system being purged.

48 VOLT POWER (GRID SYSTEM)

This is a switch with a red indicating light (1) to show when power is available to the unit for operation, page 89. The indicating light is mounted above the phase reversal switch.

MOTOR CIRCUIT BREAKER

This circuit breaker, page 89 (3), controls energizing power to the motor and permits the motor to be started by pressing the motor START-STOP switch. In the event of an overload the circuit breaker will trip to the OFF position, stopping the motor.

HEATER CIRCUIT BREAKER


This circuit breaker (4) controls the electrical power to the six heater elements. If the heater overloads for any reason the circuit breaker will trip, interrupting the power to the heater elements.

PHASE REVERSAL SWITCH

The purpose of this switch (1) is to prevent damage to the blower by driving it in the wrong direction. Always wait for the blower to come to a dead stop before attempting to reverse its direction.

- 1. The thermometer on the outlet line of the heater indicates outlet air temperature.
- 2. The unit which permits the motor to be started by pressing the Start/Stop switch is the heater circuit breaker.





- Power on 48 volt grid system. Start/Stop Blower/Motor. ·1.
- Circuit breaker blower.
- Circuit breaker heater.
- Hourmeter.

Air Purging Unit Control Panel.



From the list of functions/operations below, associate 8 of 10 to the components of the air purging unit and control panel. Match, by number, the function/operation to the component. Heater magnetic contactor Indicates the outlet air a. . temperature out of the Thermoswitch Ъ. system being purged. Overheat thermostat 2. A red indicating light to show that power is available for d. Pressure switch operation. Time delay Controls energizing power to the motor and permits the motor Hourmeter f. to be started by pressing the START/STOP switch. Phase reversing switch g. Prevents damage to the blower Motor circuit breaker h. by its being driven in the wrong direction. 48 valt power (grid system). Indicates the number of hours Thermometer. the equipment has been in operation. Provides the initial of starting and opens 45 seconds after motor is started. 7. Checks for positive air pressure and maintains motor operation. When open, disconnects the entire 110 volt control and the heater will not operate. May be adjusted in the field with screwdriver.

Cycles automatically at 350°F and interrupts power to the

heater.

Answers to Frame 62: 1. $\frac{1}{6}$ 2. $\frac{1}{d}$ 3. $\frac{h}{c}$ 4. $\frac{g}{b}$ 5. $\frac{794}{6}$ 10. $\frac{a}{a}$

The following are questions for you to use in summarizing pages 50 thru 90. Try to answer the questions on your own but if you are uable to do so, turn to the top of the next page and you will find the frame number where each question may be located.

QUESTIONS

- 1. How are LOX storage tanks cleaned and degassed?
- 2. What approved cleaning solvent is used for cleaning parts of the LOX storage tank plumbing?
- 3. What is the required pressure when transferring liquid oxygen?
- 4. What is used to pressurize a LOX storage tank when checking for leaks?
- 5. What conditions affect the performance of the vacuum nump?
- 6. When should the lubricant in the vacuum pump be changed?
- 7. What type of lubricant is used in vacuum pumps?
- 8. The effectiveness of a high vacuum pump depends upon?
- 9. The controlled outlet temperature of the air leaving the purge unit heater is?
- 10. What is the function of the phase reversal switch on the purge unit?
- 11. What type of sealing compound is used on connections on LOX storage tanks?
- 12. What is the indication that the transfer hose has developed a leak?

Answers to questions on page 91.

- 1. Frame 32
- 2. Frame 32
- 3. Frame 36
- 4. Frame 35
- 5, Frame 50
- 6. Frame 55
- 7. France 54
- 8. Frame 51
- 9. Frames 58 and 59
- 10. Frame 61
- 11. Frames 34 and 35
- 12. Frame 45

Technical Training

Aircraft Environmental Systems Mechanic

,INSPECTION AND MAINTENANCE OF CRYOTAINERS

6 March 1979



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE

DO NOT USE ON THE JOB

Environmental/Pneudraulic Branch Chanute AFB, Illinois 61868

Service Test 3ABR42331-WB-404

INSPECTION AND MAINTENANCE OF CRYOTAINERS

OBJECTIVES

- Using a cryotainer, tools, inspection, workcard, inspect cryotainer and components, locating three discrepancies and record on AFTO Forms 349. One instructor assist per form is permissible.
- Using a TMU-27M LOX cart, GSU-62M purging unit, and 2. workbook, purge cryotainer. Four instructor assists are permissible.
- Using a KQ-15 vacuum pump, vacuum microngage and 50gallon cryotainer, evacuate cryotainer. Three instructor assists are permissible.
- Using assigned cryotainer and proper tools, remove and reinstall three of the eleven selected components. One instructor assist is permissible.

Basis of Issue

EQUIPMENT

3ABR42331-WR-404	1/student
Cryotainer	1/4 students
TO 37A12-1-101	1/4 students
TO 36F2-3-1	1/4 students
Vacuum pump	1/4 students
Purge unit	1/4 students 🖟
Microngage	1/4 students
Tools	As required (kit)
TO 00-25-06-2-2	1/student
AFTO Form 26	As required
AFTO Form 349	As required

INSTRUCTIONS

This workbook contains information to guide you in performing the inspection and maintenance of cryotainers. Use the technical orders while you work and to complete the AFTO Forms 349. The technical orders provide specific instructions to follow and the

OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/TTGU-P - 400, TTVSA 1

necessary procedures which may prevent injury to you or others and damage to valuable equipment. As you complete each phase, have your instructor check your work and initial in the space provided. Work carefully and observe all safety precautions. DO NOT HURRY!

PART I - INSPECTION

Using the AFTO Form 26, Inspection Workcard, inspect the assigned LOX cart. Locate and document three discrepancies. Using the TO 00-25-06-2-2, complete the three discrepancies on AFTO Forms 349 with one instructor assist permitted per form.

PART II - VACUUM CHECK

A microngage and thermocouple is used to check for the amount of vacuum present in the annular space of a cryotainer.

- 1. Read TO: 37C11-3-1, Section II, park 2-1 and 2-2 and study Figure 1-2.
- 2. Perform a vacuum check on the MA-1, TMU-27M cryotainer assigned by the instructor and determine if it is good or bad.

Instructor's Initials____

PART III - VACUUM PROCEDURES

Vacuum the annular space of the LOX cart with KTC-21 vacuum pump. Before using the vacuum pump, refer to Figure 2 ir TO 37A12-2-101 and become familiar with the various components of th. unit. Follow the step-by-step procedures listed below for vacuuming the LOX cart. DO NOT DEVIATE FROM THESE STEPS. If there is bomething that does not work or is broken or damaged, tell your instructor INMEDIATELY.

1. Close the vacuum valve tightly. Have your instructor check it.

Instructor's Initials

- 2. Remove the bolts, nuts, and flat washers (Figure 3, Items 1, 2, 3) that secure the coupling cap (Item 4) to the coupling plate (Item 7) on the vacuum line.
- 3. Remove the coupling cap (Item 4) and seal (Item 6) from the coupling body (Item 7). Discard the old seal but save the blank plate (Item 4) for reinstallation after pump down.
- 4. Lightly coat a new seal with vacuum grease H-90. Nert, install the seal into the coupling body and install the vacuum pump hose fitting (Item 8) on the coupling plate (Item 7). Reinstall the two bolts, flat washers, and nuts. Tighten the nuts until there is metal to metal contact between the hose fitting and coupling plate.



- 5. Lightly coat the hose coupling of the vacuum pump hose fitting (Item 8) with vacuum grease. Install the servicing hose from the vacuum pump over the male end of the vacuum pump hose fitting (Item 8). Secure the hose to the fitting with a hose clamp. Coat the joint between the hose and fitting with vacuum grease.
- 6. Remove the safety wire from the vacuum valve but $\overline{\text{DO}}$ NOT OPEN the valve.

7. Start the vacuum pump to evacuate the air from the vacuum hose. With the vacuum pump running, SLOWLY open the vacuum pump not more than ONE-QUARTER TURN. This is necessary to prevent a sudden inrush of air into the vacuum filter within the tank annulus, which could cause packing of insulation against the filter. Wait a few minutes and SLOWLY open the vacuum valve to the fully open position.

Instructor's Initials

- 8. The tank can be considered to have adequate vacuum when the micron reading is less than 100 microns with the tank at purging temperature. Pumping should be continued, however, to the lowest possible micron, reading, preferably below 100 microns. If the tank cannot be pumped down to 300 microns measured on the thermocouple gage after 3 to 3½ hours of continuous pumping, there is a leak in the vacuum system. For leak detection and repair beyond base capability, request depot assistance in accordance with TO 00-25-107.
- 9. With the vacuum pump running, close and safety wire the vacuum valve to prevent accidental opening of the valve.

Instructor's Initials_____

- 10. Stop the vacuum pump and disconnect it from the vacuum pump hose fitting (Item 8). Remove the two bolts, four flat washers, and two nuts that secure the vacuum pump hose fitting to the coupling plate (Item 7), remove the hose fitting end seal. Discard the seal.
- 11. Coat the new seal with vacuum grease and install the seal in the coupling body (Item 6). Position the coupling cap (Item 4) on the coupling plate (Item 7) and coupling body. Secure with two bolts, four flat washers, and two nuts.

Instructor's Initials____

The next part of this workbook will direct you in performing maintenance in selected components. This is to prepare you for maintaining the explanat you will be working with. The technical order containing the incormation you need to repair the units listed beside each item. Work carefully and do not hurry.

PART IV - PURGING PROCEDURES

Cryotainers are not purged on a periodic (rime) basis, but rather when the permentages of contaminants reaches an undesirable level as determined by (1) laboratory tests, (2) odor of particulate testing. In this event, the storage tank must be drained and purged. Purging is the process of forcing heated air or nitrogen through the drained tank causing residual liquid oxygen (LO₂) and any contaminants which effected the tank to be converted to a gaseous state and dispelled from the tank.

NOTE: The contaminants primarily consist of acetylene (C_2H_2) , carbon dioxide (CO_2) , nitrous oxide (N_2O) , and other thank as solids at the cold liquid oxygen temperature.

PURGING FREQUENCY

- (1) No periodic schedule for purging of tanks or carts.
- (2) Requirements for draining and purging are established in Technical Order 4286-1-1.
- (3) Evidence of contamination of a storage tank will require all servicing carts used to transport liquid oxygen from the source to be purged along with the tank to assure complete disposal of the contaminated LO_2 .

Instructor's	Initials	
--------------	----------	--

SAFETY: Before you begin to work with liquid oxygen, you must first be aware of some of the hazards in working with oxygen. Observe all safety precautions outlined in technical orders, including the wearing of protective devices to prevent bodily contact with liquid oxygen. Make certain the ground areas onto which the LO, will be discharged are free of all hydrocarbons (oil, grease, lumber or wood, macadam, grass, etc). These are not compatible with liquid oxygen and spontaneous fire or explosion may result.

STEP 1

- 1. Remove the filter from the fill and drain line. On units which have separate fill and drain filters, remove both filters.
- 2. Before starting the purging procedures, make sure that the LOX cart has no liquid or pressure in it.



- 3. Position the air purging unit type GSU-62/M within 10 feet of the tank vent line. (If purging unit is not available, heated nitrogen gas may be used.) Connect the puring unit to a source of 220/440-volt, 3-phase, 60-hertz AC power. Connect the servicing hose of the purging unit to the tank vent line. Vent line adapters are available with the unit. Attach the temperature gage furnished with the purging unit to the male fitting of the fill and drain line.
- 4. Before operating the purging unit, read TO 36G2-3-1, Section 2, page 3-9.

Instructor's Initials

- 5. Start the purging unit and et it run for 20 minutes with the heater switch "OFF."
- 6. After running the unit for 20 minutes with the heater switch "OFF," turn the heater switch "ON" and let the unit run until the drain line fitting 1. approximately 104°C or 220°F.
- 7. After the unit has been stopped, open the pressure buildup valve and close the fill and drain valve.
- 8. Disconnect all tubing at the liquid level gage, pressure gage, hose pressure relief valve, and rupture disc. Remove the thermometer from the hose quick disconnect fitting and replace with a dust cap.

Instructor's Initials

- 9. Start the purging unit. Crack the fill and drain valve enough to get a moderate flow at the hose relief valve and rupture disc opening. Continue the purging until all circuits have been purged for at least one hour or until all solvent vapors or fumes have been removed. Reassemble all instruments and safety device tubing.
- 10. Disconnect the purging unit servicing hose and remove the temperature gage from the tank. Store them in the purging unit.
- 11. Reconnect the pressure buildup line to the vent line. When making the connection, use anti-seize tape on the pipe threads before assembling the pipes. Start the application of the tape at the third thread to prevent contamination of the system.
- 12. Closewhe fill and drain valve and the vent valve and leave them closed until the tank is filled with liquid oxygen. This will prevent moist air or other contaminants from entering the tank.



Instructor's Initials

- 13. Clean the filters and flush the hose with trichloroethylene and then dry them with the purging unit.
 - 14. Install the dry filters in the fill and drain lines.
 - 15. Install the transfer hose.

Instructor's Initials

PART V - MAINTENANCE

The instructor will select and give to you three out of the 11 components listed below. These components with TO number, page, and paragraph number listed along side of it, refer to that reference and follow the step-py-step procedures you will find there. Those items without the TO reference listed follow the Ltep-by-step procedures listed in this workbook.

NOTE: Before performing any maintenance on the LOX cart. make sure that the cart is empty and there is no pressure in the lines.

- Pressure rupture disc/MA-1/TO 37A12-1-101 page 4-5, para 4-
- 18, fig 4-7.
- Quantity gage/MA-1TO 37A12-1-101, pages 4-8 & 9, para 4-35. . 2)
- 3) Pressure gage/MA-1/TO 37A12-1-101, page 4-8, para 4-34.
- 4) Transfer hose/MA-1
- Using a spanner wrench, loosen the end of the hose that connects the hose to the cart.
- After the hose is loose, use your hands to remove the hose completely.
 - c. To reinstall the hose, reverse the steps.
 - 44) Transfer hose/TMU-27M
 - Using a ford wrench, unscrew the hose from the cart.
 - After the hose has been removed, clean both ends thoroughly.
 - After both ends have been thoroughly cleaned, apply new anti-seize tape to the male part of the cart.
 - After the anti-seize this has been installed, acrew the hose back in to the cart and use a ford wrench to tighten.



- 5) Transfer hose filler valve/MA-1/TMU-27M/TO 37A12-1-101, fig 4-11, page 4-13.
- a. Using a $7/8^{n}$ and a $9/16^{n}$ wrench, unscrew the filler valve from the transfer hose.
- b. Remove the old anti-seize tape from the valve and clean the hose and the valve thoroughly.
- c. After the hose and valve have been cleaned thoroughly, apply new anti-seize tape to the valve.
 - d. To install the new part, reverse step (a).
- 6) Transfer hose shutoff.valve/MA-1/TMU-27M-
- a. Using a ford wrench, turn the base of the valve counter-clockwise and then remove the valve.
- b. After the valve has been removed, clean the male portion of the manifold. Then clean the female portion of the valve, making sure both parts are free from dirt, dust, oil. etc.
- c. After both parts have been thoroughly cleaned, apply anti-seize tape to the male portion of the manifold.
- d. Now you are ready to install the part onto the cart.

 Place the valve squarely on the male part of the manifold and screw the valve clockwise (making sure the valve is not crossthreaded).

 Now tighten the valve using the ford wrench.

7) Tubing/MA-1/TMU-27M

- a. Using the appropriate size wrench, depending upon the size of the tubing and $^{\rm HBH}$ nuts, turn the $^{\rm HBH}$ nuts counterclockwise and then remove.
- b. To install the tubing, reverse step (a) (making sure that the "B" nuts are not crossthreaded).
- 8) Cart filler valve/TMU-27M
- a. Using a ford wrench, turn the base of the valve counter-clockwise and then remove the valve.
- v. After the valve has been removed, clear the male portion of the manifold. Then clean the female portion of the valve, making sure both parts are free from dirt, oil, dust, etc.
- c. After both perts are thoroughly cleaned, apply antiseize tape to the ma; portion of the manifold.

d. Now you are ready to reinstall the part back onto the cart. Place the valve squarely on the male part of the manifold and screw the valve clockwise (making sure the valve is not crossthreaded). Now tighten the valve using the ford wrench.

9) Vent valve/MA-1

a. Use the samp steps as for the shutoff valve.

9a) Vent valve/TMU-27M

- a. Using a 12" crescent wrench, turn the base of the valve counterclockwise and then remove the valve.
- b. After the valve has been removed, clean the male portion of the valve and the female portion of the manifold, making sure both parts are free of dirt, oil, dust, etc.
- c. After both parts are thoroughly cleaned, apply antiseize tape to the male part of the valve.
- d. Now you are ready to reinstall the part back onto the cart. Place the valve squarely in the female part of the manifold and screw the valve clockwise (making sure the valve is not crosathreaded). Now tighten the valve using the crescent wrench.
- 10) Buildup valve/TMU-27M/MA-1
 - a. Use the same steps as for the shutoff valve.
- 11) Pressure relief valve/MA-1
- a. Using a 5/8" open end wrench, remove the tubing attached to the rear end of the valve, turning the "B" nut counterclockwise.
- b. Now remove the cotter pin connecting the pull handle to the valve and remove the handle.
- c. Using a common screwdriver and 3/8" wrench, remove the two screws and bracket holding the relief valve to the side of the cart.
 - d. For installation, reverse the ateps for removal.

Instructor's Initials

PART VI - OPERATIONAL AND LEAK CHECK

Upon completion of Parta I-V, it will be necessary to perform a leakage and operational check on the cryotainer.



9

PROCEDURE

Obtain a servicing checklist from your instructor and follow all safety and general instructions. Pay strict attention to all procedures, especially safety. If you have any questions, ask your instructor. You will be working with liquid nitrogeny therefore, it is imperative that you be sure of what you are doing before you do it.

 $\dot{3}36$

Technical Training

Aircraft Environmental Systems Mechanic

Į.

LIFE RAFT INFLATION EQUIPMENT

22 September 1977



3350 TECHNICAL TRAINING WING 3370 Technical Training Group Chanuta Air Force Base, Illinois

DO NOT USE ON THE JOB

FOREWORD

This programmed text was prepared for use in the 3ABRA2331, Aircraft Environmental Systems Mechanic Course. It was validated using students enrolled in the 3ABRA2331 Course. At least 90% of the students achieved the objectivas as stated. The average time required to complete this text is 55 minutes.

OBJECTIVE

Relate three (3) of five (5) components of life raft inflation equipment to their operation.

INSTRUCTIONS

This programmed text consists of two sections. The material contained in section "A" is on the construction of life raft inflation. cylinders.

Section "B" information is on the operation of the life raft inflation cylinders.

The information in this text is presented in small steps called "frames." After reading the information in each fame, you are asked to select answers or respond, in some manner, to show that you understand the information in that frame. As you progress through the lesson you will be instructed to either write your answer in the booklet or on a separate response sheet. The answers to each frame can be found on top of the following page. If you select the correct answers, continue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before proceeding. Work carefully and DO NOT HURRY!!!

OPR: 3370 TTG DISTRIBUTION: X

3370 TTGTC - 400; TTVSR - 1



Supersedes 3ABR42231-PT-316, 19 February 1971.

Frame 1

Our career field is not responsible for the maintenance of life rafts, but we do have the responsibility of servicing, inspecting, overhauling, and recharging all life raft inflation equipment. For this reason, it is necessary for you to know the means by which these life rafts are inflated.

NO RESPONSE REQUIRED

Frame 2

High pressure carbon dioxide (CO₂) cylinders are used for the inflation of all life rafts. The cylinders are built to carry a maximum charge of 2100 psi. Because of the high pressure to which they are subjected, all life raft cylinders except those having an outside diameter of less than two inches and a length of less than two feet, must undergo a hydrostatic test once every five (5) years. This test is used to find out whether or not corrosion, metal fatigue, rough handling, or other causes may have weakened the cylinders to a point where they are no longer safe for further use.

Check the following statements that are true.

- 1. CO, cylinders are used for the inflation of life rafts.
- 2. Life raft inflation cylinders are built to carry a maximum pressure of 2100 psi.

In the following questions, select the answer which is most correct.

- 3. Life raft cylinders with a diameter of 1 1/2" would require a hydrostatic test how often?
 - a. 1 year.
 - b. 3 years.
 - c. 5 years.
 - d. Never.
- 4. Hydrostatic test determines if the cylinder is
 - a. broken.
 - b. repairable.
 - c. safe for use.
 - d. operating properly.

Answers to Frame 2:
√ 1.
√ 2. 3. d 4. c

Frame 3

All life raft cylinders are of two basic types, and they are used with either the one-men or the multiplace (two or more men) life rafts. (Throughout the remainder of this text the term one-men life raft cylinder multiplace life raft cylinder will be used.) The size difference in the cylinders and the difference in valve assemblies are due mainly to the size of the life raft to which they are attached. All of the multiplace life raft cylinders are wound with wire to give them added strength and to make them shatter resistant when they are struck by gunfire. The valve assemblies are made for rapid flow and they always have a safety rupture disc. This disa will break and permit the whole charge to escape if the pressure in the life raft cylinder should rise to a dangerous limit.

Check the following statements that are true.

- 1. The size of the life raft inflation cylinders varies with the size of the life rafts to be inflated.
- _____2. Cylinder valve assemblies always include a safety rupture disc.
- 3. All of the multiplace cylinders are wire wound.
- 4. The term multiplace means the cylinder inflates a life raft that holds more than one man.

In the following questions, select the answer which is most correct.

- 5. All multiplace life raft cylinders are wound with wire to give them added
 - 4. strength.
 - b. pressure.
 - c. resistance.
 - d. durability.
- 6. The valve assemblies of multiplace life raft cylinders are may for.
 - a. slow flow.
 - b. rapid flow.
 - c. emergency stoppage.
 - d. none of the above.

Answers to Frame 3: $\sqrt{1}$. $\sqrt{2}$. $\sqrt{3}$. $\sqrt{4}$. 5. a 6. b

All multip, ace life raft cylinders have to be serviced so that they are able to be used in the temperature range of -65°F to +160°F by adding a charge of dry nitrogen (N₂) to the cylinder. The addition of N₂ to the cylinder provides additional pressure which helps to force out the CO₂ at a much higher rate when the temperature is low, than would the pressure of CO₂ alone. This is because the pressure of N₂ does not go down as much as CO₂ when the temperature goes down. A fast rate of discharge of the life raft cylinders at any temperature is very important. The life raft cylinder valve assembly provides a way of maintaining high pressure CO₂ in the cylinder and is designed to permit an unrestricted flow of gas to the life raft when it is actuated. Should the machanic forget to add N₂ to a multiplace cylinder, it could cause under inflation of the life raft. The one man cylinders do not require an N₂ charge.

Check the following statements that are true.

1.	The valve	assembly permits	a restricted f	flow of	gas	to	the
	raft when	actuated.	w/				

- 2. Adding N₂ to the CO₂ cylinder causes a lower pressure to allow the CO₂ to be discharged more slowly.
- _____3. N₂ pressure does not drop as much as CO₂ pressure when the temperature decreases.

In the following questions, select the enswer which is most correct.

- 4. Multplace life raft cylinders may be used safely between the temperature ranges of
 - a. -50 to +150 F.
 - b. -65 to +160 F.
 - c. -80 to +170 F.
 - d. -95 to +180 F.
- 5. The component that provides a way of maintaining high pressure CO₂ in the cylinder is the
 - a. wire wound cylinder.
 - b. nitrogen cherge.
 - c. low temperature.
 - d. valve assembly.

Answers to Frame 4: ____1. ____2. ___/_3. 4. b 5. d

Frame 5

There are two types of one-man life raft cylinders that are approved for use. They are shown below. Both assemblies use the same valve head, but type FLU 2/P uses a heavy forged steel cylinder while type FLU 2-A/P uses a light weight aluminum welded cylinder. As you can see in figure 1, the light weight cylinder is slightly longer than the forged cylinder but they both contain the same amount of CO₂ by weight. These cylinders do not require a hydrostatic test.




Figure 1. One-Man Cylinders.

- cack the following statements that are true.
- 1. The FLU 2A-P cylinder is slightly longer than the FLU 2/P cylinder.
- 2. The FLU 2-A/P and FLU 2/P cylinders are less than two inches in diameter and less than two feet in length.

In the f lowing question, select the answer which is most correct.

- 3. The basic difference between the two one-man cylinders is the
 - a. valve head.
 - b. rate of discharge.
 - c. rupture disc plate.
 - d. material that each is made from.

Answers to Frame 5: $\sqrt{1}$. $\sqrt{2}$. 3. d

Frame 6

Refer to figure 2 while we discuss the operation of the valve that is used on the one-wan life raft cylinders. A round ball (not shown) on the inner end of the cable assembly (A) is engaged in a slot in the rotating cam (0). The ball is engaged in the slot by raising a small locking spring in the slot (M), then sliding the locking sleeve (N) down to expose the cam, and then positioning the cable and ball assembly. When the cable is pulled, the cam rotates and pushes down on the check (I) which is normally held against its seat by the spring (J) and CO, pressure within the cylinder. The CO, now floods out the charge/discharge port into the life raft. If the pressure in the cylinder should become dangerously high, it will break the rupture disc (C) and the CO, will pass out through the holes in the insert (D) and out through the vent holes (F) in the valve body to the atmosphere. The diffuser plug (K) is in ralled at all times except when the assembly is being recharged or it actually attached to the life raft. The purpose of the diffuser plug is to prevent a pinwheel action of the cylinder resulting from the jet effect of the escaping gas if the cylinder is wischarged.

Check the following statements that are $\underline{\text{true}}$. (Refer to figure 2 if necessary.)

- 1. When the cable (A) is pulled, the cam (0) pushes the sheck valve (I) to release the CO, from the cylinder (H).
- _____2. The diffuser plug (K) is r wed during recharging of the assembly.
- 3. If the rupture disc (C) is missing, the assembly can still be recharged.

In the following questions, select the answer which is most correct.

- 4. Using figure two as a guide, the purpose of item C is to
 - a. rclease the pressure.
 - b. recharge the cylinder.
 - c. close the valve.
 - d open the valve.
- 5. Using figure two as a guide, the purpose of item K is to prevent
 - a. rupturing.
 - b. discharging.

341

- c. pin wheeling.
- d. overcharging.






Figure 2. One-Man Assembly.

WIRMAIR CC	France C
Frame 7	
that is us cable (M) (D). A ho that is be arm which down. Wit the charge cylinder is valve (I) to insure	to figure 3 while we discuss the operation of the valve sed on the <u>multiplace</u> life raft cylinders. When the pull is pulled to discharge the cylinder, it rotates a sheave cle in the sheave fits over a pin that is located on a came alow the sheave. The rotation of the cam depresses a lever contacts the end of the poppet valve (I) and pushes it the poppe valve unseated, the gas rushes out through a discharge port (C) and inflates the life raft. When the Ls charged, the spring (J) and gas pressure hold the poppet closed. Notice that this cylinder has a syphon tube (K) that the liquid CO ₂ is discharged as well as the gas.
if necess	
1.	A syphon tube (K) is used to insure that gas escapes from the cylinder before the liquid escapes.
2.	The charge/discharge port (C) has a safety disc installed.
For correct as	the following questions, fill in the blanks with the most name.
3.	When rotated, the will cause the to open, and discharge the cylinder.
4.	When the cylinder is charged, the and closed.




Figure 3. Multiplace Assembly.

Answers to Frame 7: _____1. ___2. 3. csm, poppet valve


4. spring, gas, poppet valve

~ -me 8

The release cable can be rigged in either the DOWN PULL position as shown in figure 4, or in the UP PULL position by reversing the positions of the cable housing (N) and the plug assembly (A) as shown in figure 3. The ball on the end of the cable must be engaged in the proper recess on the sheave marked DOWN PULL or UP PULL. As long as the control cable has not been pulled to discharge the cylinder, a green dot on the sheave shows through the window in the sheave cover plate, as indicated in figure 4. When the cylinder is charged and rigged for use, a lead seal is placed on the safety wire which passes through two holes in the sheave cover plate and is twisted around a cover hold-down screw (figure 4). Once the cable has been pulled and the sheave rotated to discharge the cylinder, it cannot be reset without breaking the seal and removing the cover plate. Items 0, P, and Q in figure 3 are the rupture disc, insert, and plug which allows escape of the gas if the cylinder pressure should become dangerous 1 high.

Check the following statements that are true. (Refer to figures 3 and 4 if necessary.)

- 1. If the control cable has not been pulled, the green det normally indicates a charged cylinder.
- 2. The sheave cannot be reset unless the safety wire, seal, and cover plate are removed.







Figure 4. Multiplace Control Head.

Answers to Frame 8: $\sqrt{1}$. $\sqrt{2}$.

В





2

3ABR42331-PT-405A

Technical Training

Aircraft Environmental Systems Mechanic

RECHARGING EQUIPMENT FOR AND MAINTENANCE OF LIFE RAFI CYLINDERS

28 November 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

Designed for ATC Course Use.

Do Not Use on the Job.



FOREWORD

This programmed text was prepared for use in the 3ABR42331 instructional system. The material contained herein has been validated using 30 42010 students enrolled in the 3ABR42331 course. The average student required 54 minutes to complete the text.

OBJECTIVES

After completing the programmed text, you will be able to:

Relate four (4) of five (5) life raft inflation equipment components to their purpose.

INSTRUCTIONS

This programmed text presents material in small steps called frames. After each frame you will find questions. Read the information given and respond by entering the correct response on your response sheet. The answers to each frame are at the top of the next page. Anytime you respond incorrectly, reread the frame to get the information straight in your mind. Some frames do not require a response. When you have finished reading a frame that does not require a response, go directly to the next frame.




Frame 1

Figure 1 shows a typical equipment setup for charging one-man and multiplace life raft inflation cylinders. It consists of a motor driven pump, a scale, one CO₂ cylinder, one N₂ cylinder (both cylinders are placed on the same stand), dehydrator filters, a gage, shut-off valves, assorted metal hoses and adaptors. This is just a basic setup. Other variations may be used, but all will have much the same equipment as shown in figure 1.

NO RESPONSE REQUIRED









Answers to Frame 1: NO RESPONSE REQUIRED

Frame 2

The pump drive motor may be a three phase, 220 VAC unit or a single phase, 115 VAC unit of sufficient horsepower to drive the charging pump. Power is transferred from the motor to the pump by a drive belt. The pump is a ram type unit that will pump only liquid, it will not pump gas of any kind. Since the pump will pump only liquid, it is important to keep the CO, as cool as possible in order that more liquid will be available for cylinder charging. The pumping equipment is protected from damage by a rupture disc or by a spring-loaded relief valve that will relieve the system if the pressure becomes excessively high. The maximum pressure for a specific pumping unit may be found in the applicable technical order.

Complete the following statements by writing in the words from the frame above.

ę.	One requirement for t	the pump drive motor, reg	ardless of its
power req	uirement, is that it h	mave sufficient	to
	- بي -	u-1	
ъ.	CO2, in the storage of	cylinder, must be kept as	
as possib	le because the pump wi	111 not transfer	of any kind.
` c.	If charging pressure	should become excessivel	y high, the
pumping e	equipment is protected	from damage by a	disc
or a spri	ng-loaded	valve.	•

Answers to Frame 2: a. horsepower, pump b. cool, gas

c. rupture, relief

Frame 3 .

Four shutoff values are located on the charging control panel to control the flow of liquid and gas to the cylinder being charged. Value 0 controls the flow of M, to the charging hose from the supply cylinder; value L controls the flow of CO, from the charging pump; value M is the shutoff value to the charging hose for both liquid and gas. Value N is a dump value which is used to dump pressure from the supply hoses after the cylinder has been charged and vr ves L and O have been closed.

Mark the following statements with a T for True or an F for False.

1. The purpose of the shutoff valves is to control the flow of liquid and gas that are used to charge the inflation cylinder.

2. The flow of liquid or gas into the charging hose is controlled by valve M.

3. After the cylinder has been charged, pressure is dumped from the supply hoses by opening valve Z.

Answers to Frame 3: T_1 . T_2 . F_3 .

Frame 4

Dehydrator filters E are installed in both the liquid and gas supply hoses D from the supply cylinders A and C to remove any moisture from these agents before they are put into the cylinder R. One filter E is installed in the \mathbb{F}_2 supply hose and two are installed in the \mathbb{C}_2 supply hose, in series. The hoses, fittings, claptors and shutoff valves are of the brass, high pressure type. The adaptors S are used to connect the charging hose to the cylinder R that is to be charged. A gage P is installed in the \mathbb{N}_2 supply hose, on the control panel, as a means of determining ghe quantity of \mathbb{N}_2 supply. The scale Q used to weigh the cylinder assembly and the \mathbb{N}_2 and \mathbb{C}_2 charges must be graduated to read in hundredths of a pound.

Complete the following statements by writing in the words from the frame above.

a. Dehydrator filters are installed in the _____ and _____

supply hows to removeput into the cylinder.	from these agents before the; are
b	filters are installed in in the
CO2 supply hose and one is	installed in the supply hose.
c. A	is installed in the N_2 supply hose as a means of
determining the quantity of	thesupply.
d. The scale used to	weigh the cylinder and the and
pound.	ist be graduated to read in of a
e, The hoses, fitting	ngs, adaptors and
values are of the brass	hroseura tuna



Answers to Frame 4: a. N_2 , CO_2 , moisture b. Two, series, N_2 c. gage, N_2 d. N_2 , CO_2 , hundredths e. shutoff, high

Frame 5

The source of supply for the CO₂ is a standard ICC (Interstate Commerce Commission) shipping and storage cylinder C (N₂ comes in a similar cylinder). The CO₂ cylinder, when fully charged, contains 50 pounds of CO₂. At 70 F, 12 pounds of this weight will be gas and 38 pounds will be liquid. The proportion of liquid will be greater at lower temperatures. Before installing a new cylinder of CO₂, determine if the cylinder has a syphon tube. If the cylinder has a syphon tube, it must be installed with the valve up so that the liquid may be drawn off before the gas. If the cylinder does not have a syphon tube, it must be installed with the valve down so that the liquid may be drawn first. The N₂ cylinder A is always installed with the valve up. Both cylinders must be firmly secured to keep them from falling over.

Complete the following statements by writing in the words from the frame above.

a.	The shipping and storage CO ₂ cylinder contains
pounds o	of when fully charged.
ъ.	At 70°F, a fully charged CO ₂ shipping and storage cylinder
will con	pounds of liquid and pounds of
c.	At 0°F, the weight of the liquid CO2 in the cylinder will be
	(greater, less) than the weight of the liquid CU,
at 7007.	
d.	If the CO ₂ cylinder has a syphon, it must be
installe	d with the valve
e.	The N ₂ cylinder is always installed with the valve

Answers to Frame 5: a. 50, CO₂ b. 38, 12 c. greater d. tube, up e. up

Frame 6

Before the charging hose T is attached to the cylinder, it must be purged of air to insure that no moisture is injected into the cylinder R along with the liquid or gas. To purge the charging hose, the N₂ valve O, the charging hose shutoff valve M and the N₂ cylinder, shutoff valve B must be opened to allow N₂ to flow through the charging hose. After the charging hose has been purged, it is immediately attached to the cylinder R to be charged. This prevents moisture laden air from reentering the charging hose to be injected into the cylinder. The cylinder and valve assembly, with the charging hose attached, is placed on the scale Q to obtain its empty weight reading. This is used as a reference weight to determine what the full weight indication on the scale should be when the specified pounds of N₂ and CO₂ are added during the charging operation. The full weight will be the empty weight plus the specified pounds of N₂ and CO₂ to be added.

Mark the following statement with a 1 for True or an F for False.

1.	The charging hose must be filled with air before it is attached to the cylinder.
2.	Purging the charging hose insures that no oxygen is injected into the cylinder.
3.	After the charging hose has been purged, it is immediately attached to the pump.
4.	The cylinder and valve assembly, with the charging hose

attached, is placed on the scale to obtain a reference weight.

Answers to Frame 6: F 1. F 2. F 3. T 4.
Frame 7
The charging equipment does not require a great amount of maintenance. Before using it, give it a visual inspection for obvious defects and cleanliness. Scheduled inspections, lubrication intervals and types of lubricants are given in the applicable technical order. The TO also gives instructions for repair and overhaul of this equipment. The more common troubles encountered with this equipment are also listed in the TO along with the remedies for them. Complete the following statements by writing in the words from the frame above.
a. Before operating the charging equipment, give it a
inspection for defects and
b. Requirements for inspections, lubrication intervals and types
of required are given in the applicable
·
c. Most common and the for them are given
in the TO along with instructions for and overhaul.





Answers to Frame 7: a. visual, obvious, cleanliness

b. lubricants, TO c. troubles, remedies, repair

Frame 8

All cylinders returned for charging are subjected to a very thorough inspection to insure that they are free from defects and that they are protected from exposure to corrosion. The specific inspection requirements are given in the applicable technical order. Any cylinder that fails to meat these inspection requirements is tagged as reparable and set aside for further inspection and repair. Only those cylinders having no defects may be recharged.

Mark the following statements with a T for True or an F for False.

- a. Before a cylinder is recharged, it is inspected to insure that it is free from defects and protected from exposure to corrosion.
- b. Cylinders that fail to meet inspection requirements are tagged as serviceable and set aside for further use.
- ____c. Cylinders that have no defects may be recharged.



Answers to Frame F: 1 a. F D. 1 C.
Frame 9
General overhaul of multiplace cylinders includes disassembly, cleaning, inspection, repair and reassembly as directed by the applicable technical order. The cylinders are hydrostatically tested every five (5) years (quinquennial test) at 5/8 the cylinder working pressure (Example: 5/3 x 2100 psi = 3500 psi). Cylinders having an outside diameter of less than two inches and a length of less than two feet are exempt from the quinquennial test.
Complete the following statements by writing in the words from the frame above.
a. A hydrostatic or quinquennial test is not required on the
one-man cylinder because it is less than inches in
diameter and than feet in length.
b. The hydrostatic or quinquennial test is performed on cylinders
every years at the cylinder working pressure.
c. General overhaul of the multiplace cylinder includes
disassembly, cleaning,, and reassembly
d. A cylinder having a working pressure of 2400 psi would be
hydrostatically tested using psi.

Answers to Frame 9: a. two, less, two b. 5, 5/3 c. inspection, repair d. 4000

Frame 10

The hydrostatic or quinquennial test indicates the permanent volumetric expansion of the cylinder. The test is conducted by placing the cylinder in a water jacket and measuring the amount of water displaced when the cylinder is pressurized. Water is forced into the cylinder under pressure to meet the requirements indicated in the formula given in frame 9 in order to stretch the cylinder. Internal water pressure must be maintained for not less than 30 seconds. After the water pressure has been released from the cylinder, the remaining permanent volumetric expansion of the cylinder must not exceed 10% of the total volumetric expansion which occurred during pressurization. The date of the latest hydrostatic test is stamped on the cylinder below the previous date mark. Cylinders that fail the hydrostatic test are made unserviceable by damaging the threads and tagging the cylinder CONDEMNED.

		the lottowing statements with a 1 lot line of an 1 lot raise.
	_a.	Permanent volumetric expansion is shown by the hydrostatic test.
	_b.	The permanent volumetric expansion remaining after pressure has been released from the cylinder must not exceed 15 percent of the total volumetric expansion which occurred during pressurization.
1-12-1-2-1-2-1-2-1-2-1-2-1-2-1-2-1-2-1-	_c.	Cylinders that fail the hydrostatic test are made unserviceable by dama, ing the threads and tagging the cylinder as serviceable.
<u>.</u>	_d.	The date of the hydrostatic test is painted on the cylinder below the previous date.

Answers	to	Frame	10:	<u>T</u> a.	<u> </u>	Fc.	F d.
---------	----	-------	-----	-------------	----------	-----	------

Frame 11

Before the charging operation is begun, each cylinder must be weighed individually and the weight checked against the weight stenciled on the cylinder. These two weights should be the same. If they are not the same, the cylinder must be restenciled with the weight down on the scale. Different, information is required on the one-man than on the multiplace cylinders, so check the applicable TO before you cut the stencil and start spraying paint. For your information, this information is also included in frame 19 of this text.

Mark the following statements with a T for True or an F for False.

a. After the cylinder has been inspected, it must be weighed and the date checked against the date stenciled on the cylinder.

b. If the two weights are not the same, the cylinder must be restenciled with the weight shown on the scale.

c. The information to be stenciled on the one-man cylinder is different from the information to be stenciled on the multiplace cylinder.

Answers to Frame 11: F a. T b. T c.

Frame 12

Remember from a previous text, that at cold temperatures, CO_2 gas changes to a liquid. Consequently, at temperatures below $0^\circ\mathrm{F}$, the CO_2 pressure in the cylinder will drop considerably—possibly to the point where the CO_2 will not discharge fast enough to effectively inflate the life raft. For this reason, multiplace cylinders are given a charge of dry nitrogen, N_2 , to serve as a propellant for the CO_2 charge. Nitrogen pressure will remain high at temperatures as low as $-65^\circ\mathrm{F}$. The amount of nitrogen to be added to the cylinder, by weight, may be found in the applicable technical order. This information is also included as a part of frame 13 of this text.

Complete the following statements by writing in the words from the frame above.

a. At low temperatures, CO ₂ tends to, there	fore,
at 0°F, the liquid content of the cylinder would be(greater, less) than at a temperature of 80°F.	-
b. At temperatures below 9°F, CO ₂ pressure in the cylinder will	
considerably and may not effectively the	:
life raft.	
c. For cold weather operation, N ₂ is added to the	
cylinder to act as a for the CO ₂ charge.	
d. The pressure of will remain high at	
temperatures as low so	



Answers to Frame 12: a. liquefy, greater

c. dry, propellant

b. drop, inflate

d. N₂, -65

Frame 13

When charging the multiplace cylinder, N_2 is first injected into the cylinder as directed in the applicable TO. After the specified amount of N_2 , by weight, has been added to the cylinder, the CO_2 , is added. The N_2 and CO_2 charges have specified weights which must be within the weight limits shown in the technical order. The amount of N_2 added to the cylinder depends on the capacity of the cylinder in cubic inches. Charging procedures for the one-man cylinder are the same as for the multiplace cylinder, except that the N_2 charge is left out. When charging any inflation cylinder, protective clothing consisting of gloves and a face mank or goggles must be worn.

Mark the following statements with a T for True or an F for False.

- a. The amount of N₂ added to a cylinder depends on the capacity of the cylinder in cubic inches.
- b. Charging procedures for the one man cylinder are the same as for the multiplace cylinder, except that the N₂ charge is not of the one-man cylinder.
- c. When charging any cylinder, a face mask or goggles and rubber apron must be worn.



Answers to Frame 13: Ta. Tb. Fc.
Frame 14
The CO ₂ used to charge all life raft cylinders must conform to Grade B, Type I or II of Specification BB-C-101. All CO ₂ used to charge life raft cylinders is passed through two dehydrator filters connected into the supply hose in series before it is injected into the cylinder. The dehydrator filter cartridges, to insure continued drying action, must be replaced whenever 250 pounds of CO ₂ have passed through them.
Complete the following statements by writing in the words from the frame above.
a. All CO ₂ used rocharge cylinders is passed
through dehydrator filters connected into the supply hose
in before it is injected into the cylinder.
b. The CO ₂ used to inflate life raft cylinders is passed through
dehydrator filters to insure that there is noin the CO ₂ when it is injected into the cylinder.
c. To insure the continued effecti eness of the
filters, they must be replaced after pounds of / have been passed through them.



Answers to Frame 14: a. life raft, two, series b. nwo, moisture c. dehydrator, 250, CO₂

Frame 15

As mentioned in a previous frame, recharging procedures for the multiplace and one-man cylinders are generally the same. There are some small differences, one of which was the omission of the N_x charge from the one-man cylinder. Another difference is based upon the construction of the valve assembly. On the one-man cylinder, you will find it necessary to open the valve before you can charge the cylinder with CO₂. The multiplace assembly may be charged without rotating the sheave to open the valve. This is due to the construction of the valve assembly, which acts as a check valve. Just hook it up and its ready to receive the charge.

Complete the following statements by writing in the words from the frame above.

	4.	When narging the one-man cylinder the charge is
	ъ.	To charge the multiplace cylinder, it is not necessary to
open	the	because the internal construction of the unit
acts	48 &	valve.
	c.	The valve assembly on the cylinder must
be		before it will accept a charge.



368

Answers to Frame 15: a. N₂, left out b. valve, check c. one-man, open

Frame 16

It may require some practice on your part before you will be able to charge a cylinder and get it within the tolerances specified in the technical order. The tendency is to overcharge the cylinder. If the cylinder is overcharged, the excess charge must be removed. Check the technical order for "bleed off" procedures and don't forget to install the diffuser plug before you "bleed off" the excess. By installing the diffuser plug, you are protecting yourself from injury from the jet of high pressure CO₂ which will be released from the cylinder when you open the valve. Don't forget your protective equipment, this is a must throughout the charging procedure. In case you've forgotten what the protective equipment is, put on gloves and face mask or goggles during all charging operations. Remember that CO₂ absorbs a great amount of heat during the evaporation process and can cause severe frostbire to the unwary or rareless individual.

Complete the following statements by writing in the words from the frame above.

a.	The diffuser plug	is installed in	the cylinder charge/
discharge	port to prevent _	from the	ne jet of escaping high
pressure			
b.	Caution must be ex	cercised during th	ne bleed off operation because
CO ₂ absor	() a great amount (of ar	nd can cause severe
	• •		
с.	If a cylinder is	overcharged, the	excess must be
off in ac	cordance with proce	edures outlined in	n the applicable
	•		
d.	Protective equipme	ent consisting of	and a
	or	must be wor	rn during all charging
operation	.s.		

Answers to Frame 16: a. injury, CO₂ b. heat, frostbite c. bled, technical order d. gloves, face mask, goggles

Frame 17

After charging the cylinder, the charging hose T must be disconnected to permit the attachment of another cylinder to the charging equipment. First, insure that the N₂ and CO₂ control valves are closed. Open valve N to bleed off or DUMP pressure from the supply hoses. The charging hose may be cleared at this time by opening valve M and releasing the pressure through valve N. First, insure that the valve on the inflation cylinders is in the closed position. O.K., now slowly loosen the adaptors between the charging hose and the cylinder, just in case there's still some pressure and liquid left in the charging hose. After all pressure has been released from the lines, and the cylinder disconnected, close all valves to keep moisture from entering the system.

Complete the following statements by writing in the words from the frame above.

charging	hose, the charging hose must be plugged and all valves must be
١	to prevent f.om entering the system.
ъ.	The charging unit supply hoses are depressurized by
valve	•
c.	When disconnecting the charging hose from the cylinder, the
adaptor	should be loosened as a safety precaution.
d.	Before opening valve N, insure that thevalve
and the	valve have been

Answers to Frame 17: a. closed, moisture t. opening, N c. slowly d. N_2 , CO_2 , closed

Frame 18

After the fully charged cylinder has been removed from the charging unit, two leakage checks must be performed. The first is a water tank check performed under reflected light. The cylinder is submerged in a tank of water for 30 minutes and observed for bubbles rising to the surface of the water. If there are indications of leakage during this test, the point of leakage must be located and corrected. The cylinder must then be recharged and another leakage test performed. If no leakage is evident, the cylinder is stored for a period of 24 hours, as specified in the applicable TO. At the end of the 24 hour storage period the cylinder is reweighed. The allowable weight loss for the one-man cylinder is 1/100th of the weight of the CC₂ charge immediately after charging. For the pultiplace cylinder the allowable weight loss is 1/100th of a pound in 24 hours. When both of these checks have been satisfied, the cylinder is considered to be serviceable.

a. Leakage from a recharged cylinder during the water tank test is indicated by dye rising to the surface of the water.

b. During the water tank leakage check, the cylinder is submerged in the dye tank for a period of 30 minutes.

c. It requires 24 hours to perform a valid weight loss check of the cylinder contents.

d. If, during the water tank leakage check, bubbles are seen rising to the surface of the water, the point of leakage must be located and the leak repaired and the cylinder recharged.



Frame 19	
must be stenciled with specific incontents and the date that it was on the cylinder using black stenciletters are used for the one-man emultiplace cylinder. Stencile will	harged, leak tested and reweighed, it formation to identify the cylinder, its charged. This information is stenciled ink or black lacquer. One-fourth inch ylinder and one-half inch letters for the be cut to include the information on over closely so that you will know Always check this in the TO.
ONE-MAN CYL	MULTIPLACE CYLINDER
CYL AND VALVE ASSY	CYLINDER AND VALVE ASSY
TYPE FLU 2/P	PART NO.
WT EMPTY 1.55 LBS	WT EMPTY TBS (includes complete valve assy and atchs)
WT CO ₂ <u>0.50 LBS</u> TOTAL WT <u>2.05 LBS</u> DATE RECHARGED <u>1 SEP 70</u> 2100 PSI 147.63KC/CM ₂	WT CO ₂ LBS (enter nominal charge) WT N ₂ and CO ₂ LBS (enter actual weight) WT TOTAL LBS
2100 134 147.03847 4.2	DATE CHARGED
	FLEXIBLE SYPHON TUBE
	U.S. PROPERTY
Complete the following statem frame above.	ents by writing in the words from the
a. The multiplace cylinder	is stenciled using inch letters
andi	nk or black
b. The one-man cylinder is	stenciled usingach letters
and ink or black	•
c. The information stencile	d on the cylinder should identify the
cylinder, its and the	it was charged.
Answers to Frame 19: a. 1/2, bla b. 1/4, bis	ck, stencil, lacquer ck, lacquer c. weight, date

Answers to Frame 18: F a. F b. T c. T d.



3ABR42331-WB-405

Technical Training

Aircraft Environmental Systems Repairman

INSPECTION, OPERATION, AND RECHARGING LIFE RAFT CTLINDERS

14 July 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technice Training Group
Chanute Air Fo Base, Illinois

DESIGNED FOR ATC COURSE USE DO NOT USE ON THE JOB

Environmental Pneudraulic Branch Chanute AFB, Illinois

INSPECTION, OVERHAUL, AND RECHARGING LIFE RAFT CYLINDERS

OBJECTIVES

- 1. Using the inflation cylinder recharging equipment, scales, and tools, prepare and service a life raft cylinder to within 1/100 lbs of its specified weight.
- 2. Using an assigned life raft cylinder and tools, inspect the valve head assembly and cylinder. One (1) instructor assist is permissible.

EQUIPMENT

Easis of issue
1/student

PROCEDURE

Now that you have completed the programmed texts covering the operation, maintenance, and recharging of life raft cylinders, you should be familiar enough with the equipment to do the required tasks. Refer to figure 1 for an illustrated breakdown of the cylinder assembly. Do the steps given for each section of this workbook.

Section 1. INSPECTION AND OVERHAUL OF ONE-MAN LIFE RAFT INFLATION CYLINDER ASSEMBLY

- 1. Using the one-man life raft cylinder provided (type FLU-2A/2 or FLU-2/P), visually inspect the cylinder for the following conditions:
 - a. Rust on the cylinder (none allowed).
 - b. Excessive dents in the cylinder (none allowed).
 - c. Condition of the paint.

Supersede: 2ABR42231-WB-404, 1 June 1971.

OPR: 3370 TCHTG DISTRIBUTION: X

3370TCHTG/TTGU-P - 600; TTVSA - 1






Figure † Inflation Assembly (Beridix)



2. Note figure 2. Insert the end of a small paper clip in the slot in the side of the locking sleeve (3, figure 1) and raise the spring slip lock to release the locking sleeve.



Figure 2. Releasing Spring on Locking Sleeve.

- 3. Lower the locking sleeve and remove the cable and ball assembly (4, figure 1).
- 4. Inspect the locking sleeve for nicks and for free up and down movement.
- 5. Inspect the cable assembly for fraying and a loosened ball on the end of the cable. List any defects discovered:

^{6.} Note figure 3. Insert the metal rod provided into the cable ball hole of the cam and operate the cam to open the valve.






Figure 3. Operating Cam with Metal Rod.

Note: A charged cylinder can be discharged in this manner, or if the cylinder is overcharged during the charging operation, the metal rod is used to "bleed down" the cylinder to the proper weight in the event of an overcharge. The cam is also placed in this open position for charging the cylinder with CO2.

- Using the metal rod, operate the cam to the reset position. 7.
- Replace the cable and ball assembly and raise the locking sleeve to the locked position.

Section II

INSPECTION AND OVERHAUL OF MULTIPLACE LIFE RAFT INFLATION CYLINDER ASSEMBLY

Refer to Figure 4 for an illustrated breakdown of the cylinder assembly.






Figure 4. Cylinder and Valve Assembly, Part Number 55C3689.



- 1. Using the cylinder assembly provided, remove the cover plate (9) from the valve assembly by removing the two screws (10) and washers (11).
- 2. Disengage the pull cable (3) from the sheave (14) and remove the sheave by removing the screw (15) which holds it in place.
 - 3. Perform the following visual inspections of parts removed:
 - a. Surfaces of valve parts for scratches, scoring, or dirt.
 - b. Cover plate for loose rivets or damaged window.
- c. Sheave for burrs, cracks, or damage that would cause a mal-function.
- d. Pull cable for fraying and that the ball on the end of the cable is secure.

List	any	defects	discovered	:			
				-		 	—
					 	 	

- 4. Install the sheave, engaging the pin ca the cam (16) into the hole in the sheave.
 - 5. Install the sheave retaining screw.
- 6. Rotate the sheave to the charged position (all the way to the left). Charging pressure will automatically open the pilot valve.

Note: Final assembly will be completed after recharging of the cylinder.

Section III. CYLINDER RECHARGING

Warning: Any charged or partially charged gas cylinder of any size is potentially dangerous and must always be handled with caution. Handle all compressed gas cylinders carefully, never drop them or permit them to strike each other violently. Discharge valves of cylinders must not be bumped or knocked. Cylinders must be secured in a chain vise or other approved clamping device when being discharged. Protective gloves and a face mask or goggles must be worn throughout the cylinder charging process.

During your cylinder recharging procedure, refer to the diagram (figure 5) of the recharging set-up provided. For training purposes, all valves on the recharging set-up which are identified by letters on the diagram have been color coded. The instructor will inform you of the type of life raft that the cylinder you are recharging is used on.








Figure 5.

2996

- 1. For what types of life rafts is this cylinder used?
- 2. Note the empty weight of the cylinder assembly stenciled on the cylinder. The empty cylinder weight is ______ lbs.
 - Place the cylinder in the holding adapter on the scale.
 - 4. Make sure all valves on the recharging set-up are CLOSED.
- 5. Slowly open the valve (B) on the nitrogen supply cylinder by reaching through the opening in the top of the panel. Note that nitrogen supply pressure shows on the pressure gage (P). If it does not, corsult your instructor. Does a reading show on the pressure gage?

 (yes or no)
 - 6. Open the ORANGE valve (6) in the nitrogen supply line.
- 7. Open the RED valve (M) in the cylinder charging line momentarily to purge air out of the charging hose (T).
- 8. Close the RED valve (M) and immediately connect the charging hose (T) to the cylinder to be charged. Use 2 wrenches to tighten the connection.
- 9. Unlock the scale mechanism by turning the handle below the dial to the <u>left</u>. Make sure the charging hose is freely suspended and does not rest on the equipment.
- 10. Set the scale to read exactly <u>zero</u> by carefully positioning the weight on the top ba ance bar of the scale. The zero line on the scale pointer should be exactly in line with the zero line on the scale dial.
- 11. Refer to table 1 and note the weight of N_2 to be added to the cylinder you are recharging. The specified weight of N_2 is ______ 1b.

	019/61 TV	co (175)	N /7 DG	CONTINED
RAFT	CYL CAP(CU IN)	CO ₂ (LBS)	N ₂ (LBS	COMBINED CHG
MA-1	147	$2.98 \pm .06$	0.12 + .0002	3.10 + .0698
E-2B-LRU-1F	205	4.32 [±] .06	0.12 + .02	4.44 + .08
F-2B	415	$9.00 \pm .062$	0.20 ± .01	9.20 ± .072
F-2B(C121 ACFT ONLY)	386	9.00 ± 0.62	0.20 ± .71	9.20 ± .072

Table 1.

For the cylinder you are recharging, .1 lb of N₂ is within the tolerance allowed. Each graduation on the scale dial equals .1 of a pound. The scale may be read in hundredths of a pound by means of the vernier on the scale pointer. For a reading of .12 lb, the zero line on the pointer would be just past one graduation on the scale dial and the second line on the veruier would be in line with a graduation on the scale dial.

12. While watching the pointer on the scale, slightly open the RED valve (M) and when the pointer has moved one graduation on the scale dial, CLOSE the valve.

If a cylinder is overcharged with N_2 or ${\rm CO}_2$, it must be bled down to the proper weight by placing a screwdriver in the slot in the sheave and carefully rotating the sheave clockwise.

- 13. Close the valve (B) on the N₂ supply cylinder.
- 14. Open the WHITE bleed valve (N) to bleed nitrogen pressure from the line, then close the valve.
 - 15. Close the ORANGE valve (0) in the nitrogen supply line.
- 16. Again refer to table 1 and determine the weight of CO₂ for the cylinder you are recharging. The specified weight of CO₂ is _______ lbs. Although the specified weight is given in pounds and hundredths of pounds, a reading to the nearest .1 of a pound is well within tolerance. For the MA-1 raft cylinder your CO₂ weight will be 3.0 lbs. For the E-2B-LRU-1P raft cylinder your CO₂ weight will be 4.3 lbs.
- 17. Reset the scale to read exactly zero by repositioning the weight on the top balance bar.
 - 18. Slowly open the valve (Z) on the CO, supply cylinder.
- 19. Crack open the BLACK bleed valve (A) at the pump inlet until liquid CO₂ is flowing freely from the supply cylinder, then close the valve. The dehydrator filters must first fill with liquid CO₂.
 - 20. Open the GREEN valve (L) in the pump outlet line.
- 21. Crack open the WHITE bleed valve (N) which will allow ${\rm CO}_2$ gas to be purged from the pump. Close this valve as soon as liquid ${\rm CO}_2$ appears or gas no longer flows.
 - 22. Open the RED valve (M) in the cylinder charging line.
- 23. Insert the plug on the power cable into the electrical power outlet. Read the following caution and steps 23 and 24, then start the recharging unit by pressing the START button.

Caution: You must stop the pump before closing the RED or GREEN valves in the outlet charging line from the pump. Failure to do so may result in blowing the safety rupture disc at the pump outlet.

- 24. Carefully watch the scale and when it reads the weight of CO₂ to be added, quickly press the STOP button to stop the recharging unit.
- 25. As soon as the pump stops, close the GREEN valve (L) in the pump outlet line.
 - 26. Close the valve (Z) on the CO₂ supply cylinder

2998

- 27. Open the WHITE bleed valve to bleed CO, pressure from the line.
- 28. Lock the scale mechanism by turning the handle below the dial to the right.
- 29. Using two wrenches, slowly loosen the hose adapter connection at the life raft cylinder and disconnect the hose from the adapter.
 - 30. Remove the cylinder from the scale.
- 31. Unplug $\mathfrak t$ power cable from the electrical power outlet and secure the cable.

Section IV. FINAL CYLINDER ASSEMBLY - Refer to Figure 4

1. Note figure 6. Slide the pull cable through the pull cable housing and wrap it around the sheave, engaging the ball in the recess of the sheave for the DOWN PULL position.




Figure 6.

Note the small he through the top edge of the sheave for installing a piece of copper safety wire. Note figure 7. The two ends of the safety wire are passed up through the two small holes in the cover plate, wrapped around a cover plate screw, and sealed with a lead seal. This safety wire is broken when the cable is pulled to disciple the cylinder.






Figure 7. Multiplace Control Head.

Caution: Note the under side of the valve cover plate. Modified cover plates have a leaf spring installed inside the flange on the cover plate to ensure that the pull cable remains in place around the sheave. When installing the modified cover plate, first rotate it to the right approximately 40 degrees in order for the projecting end of the spring to clear the sheave.

2. Assemble the cover plate (9) to the valve body (28) with the washers (11) and screws (10). Make sure the green indicator dot is visible through the window in the cover plate.

355

3ABR42331-PT-406

Technical Training

Africaft Environmental Systems Mechanic

AIRCRAFT FIRE EXTINGUISHING LIQUID AGENT SYSTEMS

24 November 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

Designed for ATC Course Use.

Do Not Use on the Job.

FOREWORD

This programmed text was prepared for use in the 3ABR42331 instructional system. The material contained herein has been validated using 45 students enrolled in the 3ABR42331 course. Ninety percent of the students taking this text surpassed the criterion called for in the approved lesson objective. The average student required (33) minutes to complete the text.

OBJECTIVES .

After completing this programmed text, you will be able to:

- 1. Associate four (4) of five (5) components of the five extinguishing directional system with their purpose.
- 2. Select the safety precautions, without error, involved in randling fire extinguishing agents.

INSTRUCTIONS

This programmed text presents material in small steps called "frames!" After each frame you will find a number of statements and you are asked to select the statement or statements that are true. Read the material in each frame before making a selection. The answers to each frame can be found on the top of the following page. If you select the correct answers, continue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before proceeding.

Supersedes 3ABR42231-PT-305A, 14 July 4971.

OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/TTGU-P - €00; TTVSA - 1

It should be stated here that fires aboard an aircraft are not too common. Some aircraft have no fire extinguishing system at all. The B-52, for example, has a fire detection system or fire warning system, but no extinguishing system. Aircraft that do have a fire extinguishing system use it only in case of an emergency, after every attempt has been made to extinguish the fire.



Model F-Eleventeen Fire Extinguishing System.

Model F-Eleventeen Fire Extinguishing System.

- 1. The fire extinguishing system is used only when all other attempts to put out the fire have failed.
- All aircraft have fire extinguishing systems.

3063
Answers to Frame 1: 1. T 2.

Frame 2

In the past, the Air Force has experimented with several fire extinguishing agents. For years, carbon dioxide (CC₂), was the chemical they depended upon. But CO₂ cylinders are heavy and hold surprisingly little gas for the space they occupy. Also, many pilots saw the flames continue after they had used the whole load of CO₂. So the engineers looked for an easily vaporized extinguishing liquid that would allow the aircraft to carry more potential gas in the small space available. In experimenting with chemical compounds, they came up with the following liquid agents. Chloro-bromo-methane (CB), Bromo-tri-fluoro-methane (BT), and Di-bromo di-fluoro-methane (DB). Like CO₂, these agents exclude oxygen from the burning area.

Select the following statement(s) that is/are true.

1. CO₂ has been the main fire extinguishing agent for years.

2. CO₂ is not too effective for aircraft use.

3. Chlorobromomethane is a liquid agent.

4. Like CO₂, the liquid agents remove the oxygen from the burning area.

5. CO₂ is a liquid fire extinguishing agent.

7009

Answers to Frame 2: 1. <u>T</u> 2. <u>T</u> 3. <u>T</u> 4. <u>T</u> 5.

Frame 3

Of the three liquid agents listed in the previous frame, the one most used is Chlorobromomethane, or more commonly known as "CB." It will be referred to as CB in this text. CB is a heavy, colorless liquid that will evaporate from an open container faster than alcohol, but slower than ether. It produces a gas dense enough to displace most of the oxygen in the area. CB is effective on all types of fires. It will do just as much as a large cylinder of CO₂ or soda acid.

Select the following statement(s) that is/are true.

1. Chlorobromomethane is commonly called "CB."

2. CB is a heavy, colorless liquid.

3. CB will evaporate faster than alcohol.

4. When CB evaporates, it produces a very dense gas

5. CB is effective on all types of fires.

6. When CB is released, it displaces most of the oxygen in the area.

3005 Answers to Frame 3: 1. <u>T.</u> 2. <u>T</u> 3. <u>T</u> 4. <u>T</u> 5. <u>T</u> 6. <u>T</u>

Frame 4

CB begins to boil at 154° F and produces the dense gas previously described. This is a very low boiling point for a liquid considering that water boils at 212° F. CB will freeze and become a solid at -123° F. Although CB evaporates readily, it has very little compressibility when stored in a container. Therefore, CB fails to produce enough gas pressure to expel the liquid from the container when an opening is provided. To produce the required gas pressure to discharge the CB, a nitrogen gas (N₂) is added. Nitrogen was chosen as the expellant because it is not greatly affected by temperature changes. The effective discharge pressure for a CB system is 400 to 440 PSI which is obtained by using the nitrogen. Also, by using nitrogen, the CB containers will operate satisfactorily anywhere between -67° F and +160° F.

	1.	Nitrogen is added to expel the C from the container.
	2.	CB will boil at a very low temperature (154° F).
	3.	CB produces enough gas pressure by itself for expelling purposes
	4.	The effective pressure required to expel CB is 400 to 440 psi.
	_5. (With the addition of hitrogen, the CB containers will operate satisfactorily anywhere between -67° F and +160° F.
	_6.	CB will begin to boil at a very high temperature.
	7.	CB has very little compressibility when stored in the container.

Answers to Frame 4: 1. $\frac{T}{T}$ 2. $\frac{T}{T}$ 3. $\frac{T}{T}$ 4. $\frac{T}{T}$

Frame 5

The CB used in a fire extinguishing system is actually a mixture of several chemicals. Only 82% of this mixture is <u>pure</u> chlorobromomethane. For technical reasons, there is also 9% methylene bromide and 9% methylene chloride added to complete the mixture. These are also clear, heavy liquids with properties much like CB. However, they are <u>highly corresive</u> chemicals and wher mixed with water or water vapor, form hydrochloric acid. Hydrochloric acid is highly corrosive; in fact, contractors use it to clean bricks. Since the fire extinguishing system discharge nozzles at the engines are open to the atmosphere, it is almost impossible to keep water out of the system. An inhibitor (preventive) is added to the CB to reduce corrosion and prevent damage to the aluminum tubing.

Select the following statement(s) that is/are true.

1. The CB mixture used contains 82% pure CB.

2. Methylene bromide and methylene chloride are high corrosive chemicals.

3. Hydrochloric acid is not corrosive.,

4. An inhibitor is added to the CB mixture to reduce corrosion.

5. CB is actually 82% pure CB, 9% methylene bromide and 9% methylene chloride.

6. Without an inhibitor, CB and water will form hydrochloric acid.

3007 Answers to Frame 5: 1. T 2. T 3. 4. T 5. T 6. T

Frame 6

As previously stated, CB is effective on all types of fires and, since it has an inhibitor, it will not ruin the very materials you are trying to save from the fire. The main advantage that CB has over fire extinguishing agents that were previously used, is that it takes less CB to extinguish the same fire. In other words the covolume (agent versus oxygen by volume) of CB is 15%. The covolume of CO₂ is 45 percent, and water is 67 percent. Simply stated, on a given fire, you would have to cover 67% of the area with water, 45% with CO₂ and only 15% with CB to extinguish the fire by removing the oxygen.

Select the following statement(s) that is/are true.

The covolume of CB is 15 percent.

2. It takes more CB to put out a given fire than water.

3. Covolume reters to the amount of agent required to displace a given amount of exygen by volume.

4. CB will not ruin the items you are trying to save from the fire.

5. CB is effective on all types of fires.

Answers to Frame 6: 1. T. 2. 3. T 4. T 5. T

Frame 7


CB is the liquid agent most commonly used, the other two liquids should be mentioned. Bromo-tri-fluoro-methane, or more commonly known as "BT," and Di-bromo-di-fluoro-methane, which is known as "DB," are heavy, colorless liquids like CB and for all practical purposes, have the properties and characteristics of CB. However, the vapors produced by BT and DB are more toxic (poisonous) than those of CB. The same aircraft containers, system components, and recharging set-up is used with all three liquid agents. The only requirement is that all components have to be thoroughly cleaned when changing from one agent to another.

- 1. The characteristics of CB, BT, and DB are much the same.
- 2. The vapors produced by BT and DB are more toxic than those of CB.
- _____3. Different containers are used for all three agents.
- 4. Dibmomodifluoromethane is commonly called DB.

The containers used to store CB on the aircraft are generally spherical (round), but can be cylindrical. (See illustration below). The size of the containers will vary with the needs of a particular aircraft. At the present time, containers are made that hold anywhere between 8 and 33 pounds of CB. They are filled by weight. The containers are made of steel and painted brown to indicate that it contains a liquid fire extinguishing agent. Remember, each container is charged with 400 to 440 psi of nitrogen in addition to the specific weight of CB.

SPHERICAL COMMAINERS

CYLINDRICAL CONTAINER




CB CONTAINERS


Select	the	following	statement(s)	that	is/are	true.

- 2. All aircraft CB containers are cylindrical.
- 3. C3 containers are made that hold anywhere between 8 and 33 pounds.
- Each container is charged with 400 to 440 psi of nitrogen.
- 5. CB containers are painted brown.
- o. CB containers are made of aluminum.

CB containers or spheres are manufactured by two different companies, Walter Kidde and American-LaFrance. The containers made by Walter Kidde have no siphon tube and must be mounted valve end down. American-LaFrance containers have a siphon tube and are mounted valve end up in the aircraft: Proper positions of the two types of containers are shown below. Unlike CO, cylinders, CB containers do not require a hydrostatic test every five years. However, if an aircraft container is to be shipped fully charged through interstate commerce channels, it must be tested or have been tested within the past 5 years. The last hydrostatic test date (if performed) can be found on the valve end of the container. It will be stamped in the metal. The last test date is shown in the following manner, 1-65 or 2-65. This indicates the test was performed in the first half or second half of 1965.

WALTER, KIDDE






AÈRICAN-LAFRANCE

- The containers made by Walter Kidde are mounted va CB containers are removed from the aircraft for a hydrostatic 2. test every five years. American-LaFrance containers have a siphon tube. CB containers require a hydrostatic test only if they are, shipped fully charged. Walter Kidde containers have no siphon tube.
- If the figure 1-c0 is stamped on the valve end of a CB container, it was tested the first half of 1960.

In the illustration we have a CB container and bonnet assembly. The bonnet assembly includes the bonnet body, gasket, contact, strainer and cartridge assembly. The explosive cartridge (or squib) is fired by 28 VDC and ruptures the frangible disc. The frangible disc, lead washer and Orring packing is held in place in the container outlet by the retainer nut. The frangible disc is undercut into pie-shaped segments so it will break clean when hit by the slug from the cartridge. The strainer in the bonnet will catch the segments from the frangible disc to prevent them from going out into the system with the agent and obstructing flow. The fusible plug in the safety outlet will blow if thermal expansion causes too much pressure to build up in the container. The pressure gage is provided to indicate internal pressure.




CB container and bonnet assembly.

1.	The cartridge is part of the bonnet assembly.
2.	The frangible disc holds the agent in the container.
3.	The fisible safety plug takes care of thermal expansion.
4.	The careridge is fired by 110 VAC current.
5.	A slug from the cartridge breaks the frangible disc.

Answers to Frame i0: 1. 1 2. T 3. T 4. 5. T

· Frame 11


The Walter Kidde double-check tee valve, illustrated below connects two supply lines or inlet ports to a common distribution line for ditlet port. The double-check tee valve operates when C3 pressure pushes the flapper (or check) to one side, closing off either inlet port depending on which CB container is discharged. • When the flow of CB is completed, a spring returns the flapper to its original (center) position. The purpose of the double-check tee valve, is to prevent a full CB container from entering one that has already been discharged. For example, suppose the No. 2 container in the Illustration below had to be discharge after the No. 1 container was empty. Without the double-check tee valve, the No. 2 container would discharge into the empty No 1 container.



DOUBLE-CHECK TEE VALVE


- ____1. CB pressure positions the double-check tee valve.
- 2. The double-check tee valve is solenoid operated.
- ______3. The double-check tee valve prevents the agents from flowing into an empty container.
- 4. The flapper or check is spring loaded to the center position.

Two-way directional valves or selector valves used in the fire extinguishing system are solenoid operated as shown in the illustration. In most cases the selector valves are controlled by fire switches on the flight engineer's panel or pilot's panel. When a fire warning light comes on, the directional valves are positioned by switches in such a way as to direct the agent to the engine nacelle which has the fire. In the normal position, the engine selector valves close the line going to each engine. Note that ENG-2 selector valve is closed and ENG-1 selector valve is energized open and agent is flowing to that engine. In the schematic on the left below, when solenoid (G) is energized, the valve seal (A) is pivoted on the rotor (F) to close outlet port (H) as shown. The holding spring (E) normally holds the valve seal (A) over outlet port (D).



- Directional valves are also called selector valves.
- 2. Directional valves are solenoid operated.
- 3. Directional valves direct the flow of the extinguishing agent.
- 4. Directional valves are held in one position by a spring.
- 5. The double-check tee valve and directional valve operate the same.

Shown below is a typical CB fire extinguisher system. two-shot system, in that BANK NO. 1 or BANK NO. 2 can be discharged to the same engine as selected by the discharge selector switch (B). As illustrated below, CB is being discharged into ENG-1 nacelle. Let's follow the sequence of events that led up to this action. When the engine NO. 1 fire light came on, the engineer first shuts off fuel, bleed air, and hydraulic fluid to that engine. If the fire still exists. he positions the discharge selector switch (B) to BANK NO. 2 and places the ENG 1 selector switch (A) "on". (A selector switch is provided for each engine.) The cartridge in the bonnet assembly (D) on both containers of BANK NO. 2 now receive current. The ENG-1 selector switch (A) positions the wing directional valve (G) and engine selector valve (F) for ENG-1. The time delay relay (C) will delay current to the cartridge in either bank for about two seconds to give the directional valves time to position. If the fire is still not out, BANK NO. 1 can be discharged to the same engine by moving the discharge selector switch to BANK NO. 1




Typical CB Fire Extinguisher System.

- 1. The above system is referred to as a two-shot system.
- - 3. The discharge selector switch determines which bank is to be used.
- 4. The time delay relay allows the directional valves to position before releasing the agent.




Let's discuss the fire extinguishing system that is used on the aircraft shown below. This system uses Di-bromo-di-fluoro-methane or DB as the extinguishing agent. The DB containers (or bottles) are installed in the NO. 1 and NO. 4 engine pylons. NO. 1 pylon has a two containers which are used for engineral and 2. NO. 4 pylon has two containers for engines 3 and 4. Operation of this system differs from the typical CB system previously discussed (Frame 12). In a typical system, the emergency shutdown system must be used before the fire extinguishing system and engine emergency shutdown system are combined. In other words, provisions for isolating each engine from fuel, bleed air and hydraulic fluid is combined with the fire extinguishing system.




- 1. The fire extinguishing system on the aircraft shown above uses DB.
- 2. The DB containers are installed in NO. 1 and NO. 4 engine pylons.
- 3. On this aircraft the engine emergency shutdown system is combined with the fire extinguishing system.

Shown below are the components of the engine fire extinguishing system on the aircraft. Number 4 engine pylon has identical components for engines 3 and 4. Note that each agent container (1) has two discharge heads (3). The discharge head is similar to the bonnet assembly previously discussed. Pressure gages (2), discharge squib (4), and two-way check valves (5) have also been discussed. When bottle pressure drops below 225 psi or when a bottle is discharged, a low pressure warning switch (6) on each bottle turns on a light on the pilots instrument panel.




- 1. The DB bottles in the system have two discharge heads.
- 2. The engine fire extinguishing components are in NO. 2 and NO. 3 pylons.
- Each DB bottle in this system has a low pressur@ warning switch.
- 4. The discharge squib is an explosive device like a cartridge.

Let's take a look at the components in NO. 1 pylon and the controls for these components. Note that this system does not have directional valves as we discussed in the typical CB system. The agent is directed by the NORMAL or ALTERNATE discharge head . on each bottle. Look at agent #1 bottle (top bottle) in the schematic. Note that squib #1 is installed in the normal discharge head on this bottle. If squib #1 is fired, the agent will go out the normal discharge head and through the tubing to engine NO. 1. If squib #2 in the alternate discharge head of this bottle is fired, the agent will go down to the #2 tee check valve and out to the NO. 2 engine. Note that both bottles are connected with a crossover manifold. In bottle NO. 2 (agent #2) the normal discharge head sends the agent to engine NO. 2 and the alternate discharge head sends the agent up to the #1 tee check valve to NO. 1 engine. The components in NO. 4 pylon are identical to these.



- In agent #1 bottle, the normal discharge head sends agent to NO. 1 engine.
- 2. In agent #2 bottle, the alternate discharge head sends agent to NO. Y engine.
- _____3. A crossover manifold connects both DB bottles.
- 4. Only one tee check valve and one pressure switch is used.

Shown below is the complete system for engines 1 and 2. emergency engine shutdown panel, we show ENG NO. 1 and ENG NO. 2 agent discharge switches and ENG NO. 1 and 2 bottle selector switch. Note the bottle selector switch is in NORM position. Assume the fire is in NO. 2 engine and you just pushed the ENG NO. 2 agent discharge switch or button. Now follow power from the ENG NO. 2 isolated bus and main bus over and down to squib 2 in the normal discharge head of the agent #2 bottle. Whenthis squib fires, the agent is routed out to NO. 2 engine. Note that the squib receives power from two different circuits for positive firing. reason two circuits are provided for the squib is to insure its firing if one of the two circuits were to fail. A back-up circuit is provided for both the normal and the alternate squib in each agent bottle. Locate the pressure switch on each bottle. When pressure drops below 225 psi or when a bottle is discharged, a ground is made which lights the fire bottle #1 or fire bottle #2 light on the annunciator panel (shown). The flight engineer checks the condition of the bottles by these two lights.



Select the following statement(s) that is/are true.

1. With the bottle selector switch in "normal" the normal squibs will fire.


2. The alternate discharge head on agent #2 container sends agent to engine NO. 1.

3. Each squib has two circuits for positive firing.

4. The pressure switch on each bottle is connected to a light on the annunciator panel.



Now that you are familiar with the fire extinguishing system and components, let's discuss the engine emergency shutdown or isolation system for each engine. On the engine fire emergency control panel shown below we have four fire emergency control handles. Note that each handle is marked for the engine which it controls. When a fire exists, the pilot first positions the bottle selector switch to normal or alternate. He then pulls the fire handle for the effected engine and depresses the agent discharge button behind the handle. When a handle is pulled, it shuts off fuel, bleed air and hydraulic fluid to that engine. Each handle is connected by cable to the fuel shutoff valve for that engine. When the fuel valve is manually closed, contacts are closed to energize two relays which shutdown the other systems.




ENGINE FIRE EMERGENCY CONTROL PANEL

Select the following statement(s) that is/are true.

is shut off.

to prevent feeding the fire and apreading it to other areas.


The #1 engine emergency shutdown circuit is shown below. Notice when the engine #1 fire handle is pulled, emergency shutdown relays NO. 1 and NO. 2 are energized. Relay NO. 1 completes a circuit to close the bleed air shutoff valve and also allows the fuel shutoff actuator to close. Relay NO. 2 completes circuits to close the hydraulic shutoff valves (both pressure and supply) and also closes the zone 2 cooling ejector duct valve. When the zone 2 cooling ejector duct valve closes, the pressure decreases on a pressure switch which completes a circuit to close the zone 2 cooling ejector valve and stops the flow of cooling air. You can now see that hydraulic fluid, bleed air, fuel and cooling air are isolated from the engine



Engine Fire Isolation Circuit.

- 1. The fire isolation system prevents feeding fuel, hydraulic fluid, and cooling air to an engine fire.
- 2. When the hydraulic shutoff valve (pressure) closes, a light illuminates to indicate a loss in pressure.
- 3. The zone 2 cooling ejector duct valve will close before the zone 2 cooling ejector valve does.
- 4. The fire extinguishing agent is discharged before the pilot pulls the fire emergency handle.

The engine fire isolation components are located as shown below for engines 1 and 2. Keep in mind we have the same fire extinguishing and isolation components for engines 3 and 4.



Engine Fire Isolation Components for Engines 1 and 2.

Circle the correct answer, to the following questions.

- 1. The agent used in the fire extinguishing system shown above is
 - a. AB.
 - b. MB.
 - c. DB.
 - ca. CB.
- 2. In order to discharge the agent to an engine, the pilot must first
 - a. select the bottle to be used and pull all four fire handles.
 - b. select the bottle to be used and pull, the fire handle for that engine.
 - c. dump all the aircraft fuel overboard.
 - d. pull all four handles to see if the fire goes out.

Let's discuss some of the hazards and safety precautions that apply to working with and handling liquid fire extinguishing agents. We will discuss GB as the common agent but the same conditions apply to DB and BT or any other liquid agent. CB is a volatile (evaporates rapidly) liquid, and its vapors are toxic. It should be used with adequate ventilation whenever possible. Avoid exposure to high concentrations of CB for staggering, dizziness, lack of coordination, stupor, confusion, headache, nausea, ar unconsciousness may result. If overexposure is noted, leave the area at once. If this is impossible, use an oxygen or air supplying mask. After overexposure, report to first aid immediately. Personnel regularly exposed to CB will be given a medical examination at intervals set up by the base hospital.

Select the following statement(s) that is/are true.

1. CB produces a vapor that is toxic.

2. Overexposure to CB vapors can cause unconsciousness.

3. If you notice the symptoms of overexposure, you should report to first aid immediately.

4. Personnel who handle CB and are regularly exposed to the vapors will have a periodic medical examination.

5. CB should be used in a well/ventilated area.

. 3023

Answers to Frame 21: 1. T 2. T 3. T 4. T 5. T

Select the following statement(s) that is/are true.

Frame 22

6.

7.

A full face type shield will be worn when handling liquid agents, recharging or weight checking containers. Neoprene gloves and aprons will also be worn. A skin rash may result from prolonged or repeated contact with CB. If CB is spilled on the skin, it must be washed off with soap and water. Contaminated clothing must be removed immediately and thoroughly dried prior to reuse. Clean water must always be available in a CB area for washing the eyes. Although liquid agents are irritating to the eyes, no permanent injury will result if the eyes are thoroughly washed out immediately following the accident.

1. An eye shield, neoprene gloves and apron will be worn when recharging liquid agent containers.

2. CB will be washed off the skin with soap and water.

3. If CB gets into the eyes, they will be flushed out with clean water.

4. If CB is spilled on your clothing, the clothing will be removed immediately.

5. A skin rash will result from prolonged or repeated contact with CB.

8. No permanent damage will result if CB is washed out of the eyes immediately.

No special clothing is required when handling liquid agents.


Clean water will always be available in a CB area.

3024

Answers to Frame 22: 1. $\frac{T}{5}$ 2. $\frac{T}{T}$ 3. $\frac{T}{7}$ 4. $\frac{T}{T}$

Frame 23

Besides producing toxic vapors, CB is also dangerous in another respect. Since it is designed to exclude oxygen from a fire, it will exclude the oxygen from any enclosed area. This is the reason for having a well ventilated room when handling CB. If your CB work area becomes contaminated with a high concentration of CB, a "Bale Test" will be performed before reentering the area. This test is performed by the base medical office. For leak testing a fully charged CB container, a "Halide" leak detector is used. This detector is a torch affair that burns alcohol and produces a blue flame. When the detector tube is passed over a leak on a CB container, the flame turns green.



Halida Leak Detector Torch.

Select the following statement(s) that is/are t	true.	are true	18/	that	(S)	statement	ıg	following	the	serect
---	-------	----------	-----	------	-----	-----------	----	-----------	-----	--------


- 1. CB will be used in a well ventilated area.
- 2. A Rale Test will be performed in an area contaminated with CB.
- 3. A high concentration of CB will remove the oxygen from an enclosed area.
- 4. A Halide leak detector is used to leak check a fully charged CB container.
- 5. A green flame from a Halide leak detector indicates a CB leak.
- 6. A high concentration of CB vapors in an enclosed area will not harm you.
- 7. The Halide leak detector is a torch that produces a blue flame.

3025
Answers to Frame 23: 1. <u>T</u> 2. <u>T</u> 3. <u>T</u> 4. <u>T</u>
5. 6. T

France 24

Another safety hazard you will come in contact with is the cartridge or squib used to release the agent from the container or bottle. Never attempt to check cartridge continuity unless the cartridge is properly installed in the discharge bonnet. Be sure the bonnet is secure on the bottle, and the bottle is bolted to the installation brackets.

When checking cartridge continuity, use an ohmmeter which produces a current of 35 milliamperes or less. A larger current might detonate the cartridge. In other words, a PSM-37 multimeter might fire the cartridge. A cartridge or squib is a highly sensitive device.



- a. Cartridge
- b. Slug
- c. Positive terminal
- d. Washer
- e. Nut

- f. Crimped shoulder
- g. Ground terminal
- h. Gun cotton (explosive)
- i. Fusewire

Cartridge Assembly.

Select the following statement(s) that is/are true.

- 1. Not more than 35 milliamperes should be applied to the cartridge.
- 2. A PSM-37 is used to check cartridge continuity.
- 3. The cartridge or squib must be in the bonnet when checking continuity.
- 4. The cartridge is a highly sensitive evice.

Answers to Frame 24: 1. <u>T</u> 2. <u>3</u> 3. <u>T</u> 4. <u>T</u>

3ABR42331-PT-406A

Technical Training

Aircraft Environmental Systems Mechanic

AIRCTAFT FIRE EXTINGUISHING SYSTEM RECHARGING EQUIPMENT

14 November 1978



CHANUTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

Designed for ATC Course Use.

Do Not Use on the Job.



FOREWOFD

This programmed text was developed for use in the 3ABR42331 instructional system. The material contained herein was validated with 30 students from the subject course. Over 90% of the students achieved the objectives as stated. Average time for completion of the text was 17 minutes.

OBJECTIVES

After completion of this programmed text, you will be able to:

- 1. Relate four (4) out of five (5) components of the fire extinguishing servicing unit to their purpose.
- 2. Select safet/ precautions, without error, involved in handling five extinguishing agents.

INSTRUCTIONS

This programmed text presents information in small steps called "frames." After each frame you will be required to respond to questions or statements as directed. Read the information presented and make your response before you check the correct answer. If your answer does not agree, go over the material until you understand your error before proceeding to the next frame. When you have finished the programmed text, the instructor will give you the criterion test.

OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/TTGU-P - 600; TTVSA - 1



Supersedes 3ABR42231-PT-306, 3 November 1970; 3ABR42331-PT-407, 29 August 1977.

In previous lessons we discussed aircraft liquid agent bottles or containers. We said that the bottles or cylinders are filled by weight and contain pressure. We also mentioned that dry nitrogen (N_2) is added to the agent to assist in expelling it from the container of low temperatures.

At various intervals as prescribed by aircraft inspection TOs, these bottles or cylinders are removed from the aircraft and a weight check is performed. If recharging is required, this task will most likely fall on the Environmental Systems Shop

In this text we will discuss the equipment used to recharge liquid agent containers.

Sel	Select the following statement(s) that is/are true.							
1.	Aircraft fire bottles are filled by weight.							
2.	Dry nitrogen is added to all aircraft fire bottles.							
3.	A weight check is performed with the bottle installed in the aircraft.							
4.	Your shop may be responsible for recharging aircraft fire bottles.							




Answers to Frame 1: 1. T 2. T 3. 4. T

Frame 2

Shown below is a typical recharge setup for recharging aircraft CB spheres. The two agents most widely used are chlorobromomethane (CB) and dibromodifluoromethane (DB). Note in the illustration that the CB storage cylinder (F), has a syphon tube (J) and stands with the valve end up. The CB storage cylinder is pressurized with nitrogen (G) which pushes the CB out the syphon tube (J) and into the sphere (L).

On the other side of the setup, we have the nitrogen supply cylinder (N). Nitrogen is drawn from the supply cylinder, through the pressure regulator (A) and through the purifier unit (B) to the aircraft sphere (L) which is mounted on the scales (K). The purifier assembly is not a mandatory item on the liquid agent setup.



CB (Chlorobromomethane Recharge Setup.


- 1. CB and DB are the most common liquid agents used.
- 2. The purifier assembly is not mandatory in the CB setup.
- 3. The fire bottle is mounted on the scales during recharging.

Answers to Frame 2: 1. T

Frame 3

Shown below is the recharging setup for dibromodifluoromethane (DB). Note the only new component in this setup is the filter (P) which is the last unit in the manifold before the liquid agent reaches the fire bottle. Also note the DB cylinder is inverted.

In a fire extinguisher shop you will find only one liquid agent recharge setup. This one setup is used for all liquid agent recharging. The only requirement in doing this is that the setup must be purged with compressed air when changing from one agent to another.



- PRESSURE REGULATOR NITROGEN SUPPLY CYLINDER
- LINE VALVE LINE VALVE (PRESSURE
- E. LINE YALVE (NITROGEN
- SUPPLY)
 F. LINE VALVE (CP,80;
 SUPPLY CYLINDER)
- G. CP,8r; SUPPLY LINE
 H. CP,8r; SUPPLY CYLINDER
- J. STAND K. CHARGING BONNET L. CHARGING LINE M. EXTINGUISHER


DB (CF2Br2) Recharge Betup.

- The only difference in the CB and DB setup is the agent.
- One liquid agent recharge setup can be used to recharge all 2. liquid agents.
- When changing from one agent to another, the recharge setup must be completely purged.

Answers to Frame 3: 1. 2. T 3. T

Frame 4

One type of liquid agent container charging bonnet (adapter) is illustrated below. The charging bonnet in screwed into the thermal relief port or safety outlet (note fire bottle below). The bonnet unseats the thermal relief device without actually removing it from the container. Note the bonnet has a wrenching head at the top and flute engaging pins on the bottom. These pins engage the flutes in the thermal relief device (safety plug) and the wrenching head is turned to back off the safety plug and the agent enters the container. The charging line is connected to the servicing port.



Liquid Agent Charging Bonnet.


- 1. Liquid containers are filled through the thermal relief or safety tet.
 - When the charging bonnet is installed, the wrenching head is turned to unseat the safety plug.

Answers to Frame 4: 1. T 2. T

Frame 5

Once you have recharged a CB or DB container, it must be leak tested before being reinstalled on the aircraft. Special attention should be given to the thermal relief device (safety plug) when leak testing, as this is where a leak is most likely to occur. In general, you can make leak tests by timing pressure drops (pressure gage on container), soap and waser bubble tests, or with a halide leak detector (shown below). The 13F series technical orders will give specific leak tests to be performed on a particular container.

The halide leak detector burns methyl alcohol and the flame will change color when the open end of its flexible sniffer tube is held close to a liquid agent container that has a leak. The <u>normal</u> flame is <u>blue</u>; a small leak produces a <u>green</u> flame, and a large leak changes the color to a bright blue.



Halide Leak Detector Torch.

1.	A leak is most likely to occur around the safety plug.
2.	A leak test can be made by timing the pressure drop.
3.	The halide leak detector burns methyl alcohol.
<u> </u>	When burning, the normal color of the alcohol flame is red.
5.	When a leak is detected, the halide flame will turn green of a bright olue.

3033

Answers to Frame 5: 1. T 2. T 3. T 4. __ 5. _T

Frame 6

When handling liquid agents, such as recharging or weight checking containers, a full face type eye shield should be worn. Neoprene gloves and apron should also be worn when konsidered practicable. A skin rash may result from prolonged or repeated contact with CB. If CB is spilled on the skin, it should be washed off with soap and water. Contaminated clothing should be removed immediately and thoroughly dried prior to reuse. Clean water should always be available in a CB area for washing the eyes. Although CB is irritating to the eyes, no permanent injury should result if the eyes are thoroughly washed out immediately following the accident.

Select the following statement(s) that is/are true. An eye shield, neoprene gloves and apron should be worn when recharging a CB container. 2. CB should be washed off the skin with soap and water. If CB gets into the eyes, they should be flushed out with 3. clean water. If CB is spilled on your clothing, they should be removed immediately. 5: A skin rash may result from prolonged or repeated contact with CB. 6. Clean water should always be available in a CB area. No special clothing is required when handling CB. 8. No permanent damage should result if CB is washed out of the eyes immediately. Answers to Frame 6: 1. T 2. T

5. <u>T</u> 6. <u>T</u>

419

7.

Environmental Pneudraulic Branch Chanute AFB, Illinois

INSPECTION AND OPERATIONAL CHECK OF A FIRE EXTINGUISHING SYSTEM

OBJECTIVES

- 1. Using a fire extinguishing trainer, inspection workcard and maintenance data collection forms, inspect the fire extinguishing system, recording a minimum of five (5) discrepancies on appropriate forms.

 One instructor assist per form is permissible.
- 2. Using a trainer, do an operational check of the fire extinguishing system, with one instructor assist.

EQUIPMENT

Basis of Issue

Fire Extinguishing System Trainer 3180 1/4 students

Note: The last page of this text contains an illustration of the fire extinguishing trainer number 3180. This illustration can be used to locate any part not identified on the actual trainer. Compare it to the trainer as you read through the procedures the first time.

INSPECTION PROCEDURES

- 1. Have the instructor set up fire extinguishing film number AVA C-141.
- 2. Using the AFTO Form 26, provided by your instructor as a guide, inspect each item listed, record a minimum of 5 discrepancies on the AFTO Form 349. One instructor assist per form is permissible.

OPERATING PROCEDURES

Any trainer malfunction should be brought to the instructor's attention.

- 1. Remove all jewelry before operating this equipment.
- 2. Inspect the fire extinguishing trainer for the following:
 - a. All circuit breakers are pushed in.
 - b. All fire handles are pushed in.
- c. Bottle selector switch for engines 1 and 2 in NORM (normal).
- d. All trouble switches in the out position (located on back of trainer).

Suparsedes 3ABR40231-WB-406, 4 August 1975.

OPR: 3370 TCHTG DISTRIBUTION: X

3370 TCHTG/TTGU-P - 600; TTVSA - 1

Designed for ATC Course Use. Do Not Use on the Job.

- 3. Connect the trainer to 28V DC. The power cord is coiled up behind the trainer. 28V DC outlets are on the wall.
- 4. Place the trainer power master switch "ON." This switch is located directly below the box containing the trouble switches.
 - 5. Now visually check the following:
 - a. Squib firing lights (RED) should be "OFP."
- b. Annunciator panel lights (RED) for fire bottles Number 1 and Number 2 should be "OFF."
- c. The HYD shutoff valve (hydraulic) should be "OPEN" (amber indicating light "OFF").
 - d. The HYD supply shutoff valve "hould be "OPEN."
- e. The ejector valve should be "OPEN" (amber indicating light "ON"). The pressure switch holds the ejector valve open.
 - f. The bleed air shutoff valve should be "OPEN."
- g. The manual fuel shutoff valve should be "OPEN." On the trainer this valve is connected by cable to the <u>Number 1</u> (only) engine emergency fire handle. <u>In the aircraft</u> each fire handle is connected by cable to a manual fuel valve for that engine.
- h. The ejector <u>duct</u> valve actuator (cooling air) should be "OPEN" or extended. This actuator will open or close a small door on the engine cowling for cooling purposes.
- i. The fuel shutoff valve actuator should be extended (valve not shown on trainer).
- j. Only the two way check valves are shown since tubing is not used on the trainer. Mormally these two check valves are in the manifold tubing connecting the two fire bottles. The spring loaded "flappers" in the check valves position in response to the direction of agent flow.
- k. The wiring for the system is routed through the two margency shutdown relays on the lower right corner of the trainer.
- 6. To evergize the engine emergency shutdown system, "pull" the ngine Number 1 fire handle.
 - a. Check that all valves "close."
- b. Ejector valve amber light should go "off" (indicator valve osed and pressure dropped).
- c. HYD shutoff valve amber light should come "ON" (indicating lve has closed).


- d. We now have fuel, hydraulic fluid, bleed air, and cooling air shut off from the Number 1 engine.
- 7. To energize the fire extinguishing system, press the "push to discharge" button which was uncovered when Number 1 handle was pulled.
- a. With the bottle selector switch in "NORM," the circuit will fire the "NORM" squib in fire bottle Number 1 (check the red squib firing lights).
- b. The fire bottle Number 1 red light on the annunciator panel should come "ON" (these two lights are connected to the pressure switch in the fire bottles; a pressure drop to 225 psi or below will turn on these lights.) The pilot now knows that the agent in <u>fire bottle Number 1</u> has been sent to engine Number 1.
- 8. If for some reason one bottle did not extinguish the fire in engine Number 1, the bottle selector switch would be positioned to "ALT" (flip this switch down). Now press the "press to discharge" button for engine Number 1 again.
- a. The circuit will now fire the "alternate" squib in <u>fire</u> bottle Number 2 (check squib firing lights). The agent in this bottle will also go to engine Number 1.
- b. The fire bottle Number 2 red light on the annunciator panel should come "ON." (Drop in pressure to 225 psi or lower turns on this light.)
- c. If this firing sequence is not clear, use the wiring diagram on the trainer and trace the circuit out with a grease pencil. (Wiring diagrams are in the upper right hand corner of the trainer.)
 - 9. To reset the trainer for another operation:
 - a. Place the bottle selector switch back to "NORM."
 - b. Push fire handle Number 1 back in.
 - c. Check that all valves return to the "OPEN" position.
- d. The ejector valve amber light should be "ON" and the HYD shutoff valve amber light "OFF."
- e. Place the trainer power <u>master switch</u> "OFF" and then "ON" again to reset the squib firing and annunciator panel lights. (On the aircraft these bottles must be recharged to turn "OFF" the annunciator lights.)
 - 10. For this check, assume the fire is in the Number 2 engine.
- a. Pull the fire handle for engine Number 2. Check that all valves close.
- b. Press the "push to discharge" button behind the Number 2 handle.



- c. With the bottle selector switch in "NORM," the circuit will now fire the "NORM" squib in fire bottle Number 2. (Check squib firing lights.)
- d. The fire bottle Number 2 light on the annunciator panel should come "ON."
 - 11. If this did not extinguish the fire, bottle Number 1 can be used.
 - e. Position the bottle selector switch to "ALT."
 - b. Press the "push to discharge" button again.
- c. The circuit will now fire the "alternate" squib in fire bottle Number 1 end send the egent to engine Number 2. (Check the squib firing lights.)
- d. The fire bottle Number 1 light on the annunciator panel will now come "ON."
- e. Check the wiring diagram on the treiner to see how this happens.
 - 12. Shut the trainer down as follows:
 - a. Push engine Number 2 fire handle in.
 - b. Position the bottle selector switch beck to "NORM."
 - c. Place the trainer power master switch "OFF."
- d. Remove the trainer power cord from the 28V DC outlet and position it behind the trainer.
 - 13. Additional Information:

đ

- e. The complete operational checkout sequence for the fire extinguishing system is outlined in 1C-14LA-2-7. Hormally, the connector plugs are removed from the squibs and a test set is used to check the electrical circuit.
- b. The only indicating lights found on the eircraft fire extinguishing system are the fire bottle lights on the annunciator panel. The squib firing and valve operation lights are on the trainer only. This completes the operational cheek of the fire extinguishing system. Cheek with your instructor before continuing.



Engine Fire Isolation and Extinguishing System Trainer.

Environmental Pneudraulics Branch Chanute AFF, Illinois

34BR42331-WB-406A 14 July 19'8

TROUBLESHOOTING FIRE EXTINGUISHING AND ENGINE ISOLATION SYSTEMS

OBJECTIVES

After completing this workbook, you will be able to:

1. Use a fire extinguishing trainer and multimeter to trouble-shoot the system for maifunctions, locating four (4) of six (6) causes correctly.

EQUIPMENT

Trainer number 3180 Multimeter Basis of Issue 1/4 students 1/2 students

INFORMATION

By now you should have inspected and operated the fire exinguishing trainer. You should have a good idea of how the system operates. In this project, you will troubleshoot the system by locating defects that are put in the system by trouble switches. These defects will be open or shorted sires. Troubles ar placed in the units. Note that test jacks have been put in the circuit on the trainer. With test jacks there is no need to take off the AN connector plugs to check a circuit.

When you check the various circuits, use grease pencil to trace the circuit on the plastic covered wiring diagram. The diagram is on the trainer. This will keep you from checking the same Circuit twice.

Superseder 3ABR42331-WB-406A, 3 September 1975.

OPR: 3370 TCHTG DISTRIBUTION: X

3370TCHTG/TTGU-P - 500; TTVSA - 1

Designed for ATC Course Use. Do Not Use on the Job.



PROCEDURES

- 1. Set up the trainer for normal operation (power switch ON and master switch ON).
- 2. Find thouble switch number 3. The trouble switches are on the right side of the trainer.
 - 3. Place this trouble switch to the IN pc Ition.
 - 4. Look at Table 1 and read the discrepancy

Trouble Switch	Discrepancy
3	The squib firing light for circuit "A" does not come ON, when the bottle selector switch is in "NORM" and engine #I discharge button is pushed.
4	Alternate circuit "A" engine #1 will not fire.
7	No response from the electrical circuit when engine #1 fire handle is pulled.
	The hydraulic supply shutoff valve will not OPEN when engine #1 fire handle is pushed.
9	The ejector duct valve will not CLOSE when engine #i fire handle is pulled.
11	The bleed air shutoff valve will not CLOSE when the engine #1 handle is pulled. The shutoff valve will not OPEN when the engine #1 handle is pushed.

Table 1. Troubleshooting.

WARNING: When a fire extinguishing system needs maintenance, be sure that the AN connector plugs, are off the firing squibs before a multimeter is used. The battery in the meter has the current that would fire a squib. When a squib needs to be checked, use a meter than CANNOT give more than 35 milliamperes of curre... This type of meter will be taught in the next text. Be sure to check the technical order for the mircraft on which you are working.

- 5. Pull the number 1 fire handle.
- 6. Press the push to discharge button (located under the fire handle) for the number 1 engine.
 - 7. Watch the squib firing lights.



- 8. Since the circuit "A" squib firing light DID NOT come ON, check the trainer wiring diagram for test points.
 - 9. Check the circuit with the multimeter.

NOTE: You can troubleshoot t a trainer with power ON or OFF. Make sure you have the meter set correctly when making either a power ON or a power OFF check.

- 10. After the circuit is checked, you should have found that wire number 1W2B18 was OFEN. This wire is between the number 1 engine discharge button and the bottle selector switch.
- 11. Mark the wiring diagram to show the problem. Use an "X" and the trouble switch number.
 - 12. Place trouble switch number 3 to the OUT position.
- 13. Work the next five (5) problems listed in Table I by following steps 1 through 12.
- 14. Have the instructor check your answers before you start the next project.

BENCH CHECK FIRE EXTINGUISHING COMPONENTS

OBJECTIVES

After completing this workbook, you will be able to:

1. Using squibs container provided and igniter circuit tester, bench che a two (2) squibs for proper resistance value, while observing all safety precautions pertaining to explosive squibs. One (1) instruct assist permissible.

EOUIPMENT

Basis of Issue 1/student

Igniter Cirucit Tester, Type 101-5BF Agent Container

1/student

Squib

1/student

INFORMATION

In this project, you will bench check a fire extinguishing bottle squib to find 6.5% if it is good. Use the figure on the last page of this book when making this check. The diagram will help you to find some of the components that are not labeled on the tester. Read all of the steps one time, then start the test.

Caution: The squib must always be placed in the agent container when a continuity check is made. If the meter should detonate the squib, the container would discharge the liquid agent.

PROCEDURE

- 1. Check the condition of the squib tester before you use it.
- a. First, by sure that the SHORTING BAR is put between the binding posts, located at the top of the tester.

Caution: Never press the OPERATING KEY when the shorting bar is not in place, or when the SPRING CLIP LLADS are not hooked to the squib. This could damage parts in the tester.

Supersedes 3ABR42231-WB-406B, 10 September 1975.

OPP: 3370 TCHTG DISTRIBUTION: X

3370TCHTG/TTGU-P - 60C; TTVSA - 1

Designed for ATC Course Use. Do Not Use on the Job.

- b. Set the OHMS DIGITAL DIAL to read all zeros by turning the DIGITAL DIAL KNOB counterclockwise (CCW).
 - c. Set the OHMS ADD SELECTOR SWITCH to zero.
- d. Press the operating key and watch the pointer on the meter. If the pointer does not move, the tester circuit is good. If the pointer moves, there is an open in the tester circuit. Check with your instructor if the pointer moves.
 - 2. Using the Squib tester.
- a. Remove the shorting bar from between the two binding posts.
- b. The resistance value will vary with different squibs. The resistance value and tolerance of the squibs you will test are 2.33 ± 0.50 ohms. Set a resistance value of 2.30 ohms in the ohms digital dial by turning the digital dial knob clockwise (CW).
- c. Hook the spring clip leads to the AN connector plug located on the top of the tester.
- d. Hook a spring clip lead to one of the pins of the AN connector on the squib under test. Hook the other lead to the ground terminal of the squib.

Note: Since you will check both the A and B circuits in each squib, it is not too important whether A or B is checked first.

- e. Press the operating key and watch the meter pointer. If the pointer moves, increase or decrease the ohms value you had set in the ohms digital dial. Keep adjusting until the meter pointer is centered on the red line of the meter scale.
- With the operating key pressed, read the ohms digital dial. The reading should be 2.30 ± 0.50 ohms. If this is the reading, the squib is good. If the reading is not in tolerance, the squib is bad.
- g. If the circuit proves to be good, remove the spring clip lead from the pin and connect it to the other pin to check that circuit.
 - h. Do steps d, e and f.
- i. Let the instructor know the condition of the squib you are testing (good or bad).

EXAMPLE

Your instructor gave you a squib that has a resistance value and tolerance of 2.30 ± 0.50 ohms. Hook one lead to a rin of the squib and the other lead to the round connection. Set the ohms add selector switch to zero (0). Then, set 2.30 ± 0.50 ohms in the digital dial and press the operating key. If you can center



3044

the meter pointer (red line) by adding or subtracting not more than 0.50 ohms, the squib is good. Do the above steps with the other circuit.


Note: The ohms add selector switch settings are in ten ohm increments. If the squib resistance is between 0 and 10 ohms, use the zero (0) setting of the switch. If the resistance is between 10 and 20 ohms, set the switch on 10. If the resistance is over 20 ohms, set the switch on 20.

Securing the squib tester.

Remove the test leads from the squib and tester and store them in the top of the tester cover. Replace the shorting bar between the binding posts and set the OHMS DIGITAL DIAL to read all zeroes.

4. Squib disposal. If the test shows the squib to be bad, the squib must be removed and replaced. The old squib is not thrown into a trash can. Every Air Force base has explosive material disposal procedures that must be followed.





70-09013



3ABR42331-PT-407

Technical Training

Aircraft Environmental Systems Mechanic

LIQUID COOLANT SYSTEMS

21 October 1977



3350 TECHNICAL TRAINING WING 3370 Technical Training Group Chanute Air Force Base, Illinois

Designed for ATC Course Use.

Do Not Use on the Job.



FOREWORD

This programmed text was prepared for use in the 3ABR42331 Aircraft Environmental Systems Mechanic Course. The materials contained herein were validated with students from the subject course. At least 90% of the students taking this text achieved or surpassed the criteria established in the lesson objective. The average time for completion of this text was 2 hours.

OBJECTIVES

Relate eight (8) of ten (10) components of a liquid coolant system to its operation.

INSTRUCTIONS

This programmed text presents material in small steps called "frames." After each frame you are asked to select the statement(s) that are true, match items, or complete statements. Read the material in each frame before making your response. The answers to each frame can be found at the top of the next page. If you select the correct answers, continue to the next frame. If you are wrong or in doubt, read the material again and correct yourself before continuing.


OFR: 3370 TTG DISTRIBUTION: X

3370 TTGTC - 250; TTVSR - 1

In older aircraft, radar cooling was accomplished by a fan mounted to the radar unit. When the unit was operating the fan would blow air across it. This was found to be a very poor way to cool a unit that cost as much as the radar unit does. The fllot could not tell if the fan was running or not. A lot of radar units failed because the fan was not operating and the pilot continued to operate the radar unit. In the new aircraft a new type of cooling system has been made for the radar unit. It is called the Liquid Coolant System. We will refer to this as the LCS throughout this PT. The LCS cycles a liquid fluid through the radar unit. As the fluid flows through the radar unit it picks up heat. The fluid then flows through a heat exchanger where the heat is removed by cold air flowing across the fluid. After the heat exchanger the fluid is routed back to the radar unit and continues to cycle in this manner. The LCS operates any time the radar unit is operating. Now we know what the LCS is used for, let us take a look at the components and operation of the system.

Refer to figure A and locate each of the components listed below. Place the circled number of the unit in the blank space alongside the unit name.

a.		Low pressure switch
ъ.		Filter
c.	<u>·</u>	Bleed/overboard expansion relief valve
d.		Pump
e.		Solenoid shutoff valve
f.		Modulating valve
g.		Delta system bypass valve
h,		Reservoir
1.		Thermal pilot valve
j.		Temperature sensor
k.		Heat exchanger



ERIC

Answers to Frame 1: a. 8, b. 10, c. 11, d. 2, e. 6, f. 3
g. 9, h. 1, 1. 5, j. 7, k. 4
Frame 2

The aservoir is used to store the liquid. The reservoir holds 100 cubic inches (CI) of fluid and has a warning light that will come on when 20 CI or more of the fluid is lost. The reservoir is made up of three main parts which are (1) the housing, (2) the reservoir piston, and (3) the fill/refill potentiometer. The housing stores the liquid. The reservoir piston will keep a constant pressure of liquid supplied to the pump. This is done by the pressure of the liquid from the pump that is applied to the back of the reservoir piston. This pressure will allow only the needed liquid to be supplied to the system. The fill/refill potentiometer is connected to the reservoir piston. When the system has lost 20 CI or more of liquid the piston is moved to the right which will move the wiper of the potentiometer and turn on a warning light in the cockpit. This tells the pilot that the LCS is low on coolant.

Check the following statements that are true.

	1.	The warning light will come on in the cockpit when 10 or more
		cubic inches of fluid is lost.

- 2. The reservoir holds 100 cubic inches of coolant.
- 3. The warning light in the cockpit tells the pilot when the pressure in the reservoir is low.

Answers	to	Frame	2:	,	1.	 2.	 3.

The pump is the next item in the LCS. The pump is a three phase, AC motor which operates all the time the radar unit is on. It keeps a constant pressure and flow through the LCS any time the system is operating.

The heat exchanger is the next item. This is where the heat is removed from the liquid coolant. The LCS heat exchanger is placed in the Avionics Cooling air ducting. The cooling air going to the Avionics Equipment is what cools the liquid in the LCS. The cooling air flows across the heat exchanger and LCS is routed through the heat exchanger. Once the cooling air removes the heat from the liquid it continues to the Avionics equipment. The small amount of heat that is picked up from the LCS will not affect the effectiveness of the Avionics cooling system. If the temperature of the liquid coolant is too cold, the coclant can bypass the heat exchanger. How the system bypasses the heat exchanger will be explained in the next frame.

Check the following statements that are true.

******	1.	Ram air	flowing	across	the	LCS	heat	exchanger	cools	the	liquid
		coolant					•				


- 2. The LCS pump is a 3 phase, AC motor, which operates any time the radar unit is on.
- 3. The purpose of the pump is to keep a constant pressure and flow through the LCS.

Answers to Frame 3: _____1. \checkmark 2. \checkmark 3.

Frame 4

During normal system operation (see figure B) fluid flows from the heat exchanger to the pilot valve. The pressure and temperature of the fluid entering the pilot valve positions the valve. When both the pressure and temperature are normal, the bellows of the pilot is expanded which forces the valve closed. With the pilot valve closed, pressure is trapped on the back side of the modulating valve. When pressure on the inlet side of the modulating valve is the same as the pressure on the back side, the valve will close. This is due to a spring installed in the back side of the modulating valve. It takes both the spring tension and the trapped pressure to close the valve. This allows the fluid to flow from the heat exchanger through the pilot valve and on to the radar unit.

Match the items in Column B to the statement




Match the items in Column B to the statement in Column A.

Column A Column B ___ Fluid flows from heat exchanger to Modulating valve a. pilot valve. ъ. Normal system 2. ____ Pressure and temperature entering operation this valve positions it. Pilot valve с. 3. ____ It takes fluid pressure and spring d. Spring tension tension to close this valve.

Answers to Frame 4: 1. \underline{b} , 2. \underline{a} , 3. \underline{a}

Frame 5

When the temperature and pressure of the system decreases the modulating valve opens allowing the fluid to flow from the pump through the modulating pilot valve on to the radar unit. (See figure C.)



As the temperature and pressure of the fluid entering the pilot valve decreases, the bellows in the pilot valve contracts (opens). This pulls the valve off its seat, allowing the trapped pressure between the modulating valve and the pilot valve to bleed off. The pressure on the inlet side of the modulating valve is higher than the back side pressure. This inlet pressure can override the spring at the modulating valve and force the valve off its seat. This allows he fluid to flow from the pumpa through the modulating and pilot valves; to the radar unit, completely bypassing the heat exchanger.

Check the following statements that are true.

- 1. If the temperature and pressure of the liquid increased, the bellows in the pilot valve will expand and close the valve.
- 2. Closing the pilot valve will trap pressure on the back side of the modulating valve.
- 3 With the modulating valve open the fluid must flow through the heat exchanger.



WURAGLE C	o Frame 5: V 1. V2.		·
	-		Frame 6
Matc it in Col	h the component in Column B to the umn A.	state	ement that best describes
<u>Colu</u>	tim A		Column B
1.	Keeps a constant pressure of liquid flowing from the	a.	Modulating valve
	reservoir to the pump.	ъ.	Pump
2,	Must be closed by fluid pressure and spring tension	c.	Reservoir piston
	to direct the fluid through the heat exchanger.	d.	Pilot valve
3.	3 phase AC motor operated to	e.	Fill/refill potentiometer
	provide a constant pressure and flow through the LCS.	f.	Solenoid shutoff valve
4.	Moved by the reservoir piston to indicate a loss of 20 CI or more of fluid from the reservoir.	•	
5.	Has a bellows that reacts to temperature and pressure changes will open the modulating valve to		

Answers to Frame 6: c. 1. a. 2. b. 3. e. 4. d. 5.

Frana 7

The LCS has a two position master switch (normal and test). In the normal position, the solenoid shutoff valve is deenergized and opened. With the pilot valve also open, the pressure that is trapped between the pilot valve and the back side of the modulating valve will flow through the solenoid valve back to the pump return line. This means that the pilot and modulating valves are controlling the flow of coolant that goes through or bypasses the heat exchanger. The test position of the LCS switch is to let you perform an operational and leak check of the LCS on the ground. With the switch in the test position, the solenoid shutoff valve is energized closed. With the pilot valve open and the solenoid valve closed, pressure is trapped on the back side of the modulating valve. This keeps both the inlet and back side pressure equal, which keeps the modulating valve closed at all times. So no matter what the temperature of the coolant is, it has to go through the heat exchanger and cannot in any way bypass it. The maximum time you can run the LCS in test position is 6.5 minutes.

Check the following statements that are true.

is 6.5 minutes.

	1.	The test position of the LCS master switch is used to operational and leak check the system on the ground.
	2,	The solenoid shutoff valve is energized closed.
•	3.	When the LCS master switch is in the test position, the pilot and modulating valves are always closed.
	4.	When the LCS master switch is in the normal position, the flow of the liquid coolant is controlled by the pilot and modulating valves.
	5.	The maximum time the LCS can be operated in the test position

Answers 1	to Frame 7:	1.		2	3. <u>v</u>	4.		5.
						Fr	ame 8	• •
The	overtempera	v ture sensor	(7) is	installed	in the	LCS be	tween	the

The overtemperature sensor (7) is installed in the LCS between the thermal pilot valve and the low pressure switch. When the air flowing across the LCS heat exchange is not cold enough to remove the heat from the coolant flowing through the heat exchanger, the overtemperature sensor completes a circuit to the overtemperature waining light in the cockpit. If the warning light comes on, you have a malfunction in the cooling air system. The purpose of the sensor is to tell the pilot if the liquid coolant is too hot to cool the radar unit. If the overtemperature warning light comes on, the pilot must turn the radar unit off. With the radar unit off, the pilot must return to his base.

light comes on, the pilot must turn the radar unit off. With the radar unit off, the pilot must return to his base.

Check the following statements that are true.

1. The overtemperature sensor is located between the pump and filter.

2. If the overtemperature warning light comes on, it tells the pilot he has a malfunction in the modulating valve.


3. When the overtemperature warning light is on, the pilot could operate the radar unit for 6.5 seconds.

4. The pilot must turn the radar unit off and return to his base if the radar unit cannot be cooled.

Answers to Frame 8: ____ 1. ___ 2. __ 3. __ / 4

Frame 9

The low pressure switch in the LCS is used to indicate if the liquid level is too low to cool the radar unit. When you have no pressure or low pressure, the low pressure switch is collapsed which makes an electrical circuit that will turn on the low pressure warning light in the cockpit. (See figure D.)






Figure D. Low System Pressure

Figure E. Normal System Pressure

When the system is operating at normal system pressure, fluid enters an opening in the bottom of the low pressure switch, pushing the top of the switch up breaking the circuit to the warning light in the cockpit. (See figure E.)

Complete each of the following statements:

- 1. If the LCS is in the off position, the warning light will
- 2. If the LCS is in the on position, the warning light will


A

444

Answers to Frame 9: 1. stay on 2. go off

Frame 10

Now that you know what happens when you do not have enough pressure in the system, let's see what happens when you have too much pressure. The system bypass valve is spring-loaded to the closed position. The coolant flows from the pilot-valve toward the radar unit. If the pressure is normal, fluid will flow to the ball of the bypass valve but the spring will hold the valve closed which lets all the fluid in the system flow to the radar unit. (See figure F.)






Figure F. Normal Pressure

Figure G. Excessive or High Pressure

If the pressure is too high, the pressure of the fluid pushes against the ball of the bypass valve. (See figure G.) As the pressure builds up, it overrides the spring tension of the bypass valve which forces the ball off its seat. This lets the high pressure bypass the radar unit and return the fluid to the line going to the pump.

Check the following statements that are true.

- 1. The system bypass valve is spring loaded to the closed position.
- 2. The bypass valve protects the system from high pressure.
- 3. The fluid that flows through the bypass valve is routed back to the pump, bypassing the radar unit.

13

Answers to Frame 10: $\sqrt{}$ 1. $\sqrt{}$ 2. $\sqrt{}$ 3.

Frame 11

After the coolant leaves the radar unit, it must flow through some type of assembly to clean the fluid. This is called a filter and it is used to remove dirt, etc, from the fluid. The filter is made of a wire mash element, housed in an aluminum bowl. There are two ways to tell you that the filter is dirty. One way is a machanical pop-up indicator on the filter housing. When the filter is dirty, the pressure increases until it forces the pop-up indicator out. At the same time, this pressure is applied to the filter pressure switch which completes the circuit to the warning light in the cockpit.

The pilot must turn the radar unit off once the warning light has come on because there is no coolant flowing to the radar unit. You must remove and replace the filter element before the pop-up indicator or the warning light can be reset.

Match the component in CoTumn B to the statement in Column A that hest describes its use.

Column A Column B _ 1. Complete an electrical circuit Pop-up button 8. to a warning light to tell the pilot the filter is dirty. Wire mesh **b**. _ 2. Used to remove dirt from fluid Pressure switch c. as it leaves the radar unit. Aluminum bowl d. 3. Mechanical device that tells the filter is dirty.

Answers to Frame 11: c. 1. b. 2. a. 3.

1.

2.

Frame 12

The bleed/overboard expansion relief valve is located just off the reservoir. This valve has two functions. The first one is to allow you to bleed air out of the LCS and drain the LCS completely. The bleed is a manual opened or closed valve. Turn the handle clockwise to close the valve and counterclockwise to open it. If air is trapped in the system, it has to be removed. This is because air will not conduct the heat as the coolant will. If the coolant gets dirty and you need to change it you need a place to drain it. The coolant is just like the oil in a car engine. It has to be drained and new coolant installed at regular intervals in order to protect the system. The second function of the valve is expansion relief. This portion of the valve will protect the reservoir from high pressure. It consists of a ball and spring. During normal system operation, pressure is applied to the ball of the valve but cannot offseat it because of the spring tension. When the pressure increases, it overrides the spring tension forcing the ball off seat and vents the high pressure overboard. This way the high pressure will be vented overboard and not damage the reservoir.

The manual bleed handle must be turned ______ to open the bleed valve.

The bleed portion of the bleed/overboard expansion relief valve is used to bleed ______ out of the system and ______ the system completely.

The expansion relief portion of the valve is made up of a ______

To force the expansion relief valve open, the coolant pressure must

increase and override the ______

Answers to Frame 12: 1. counterclockwise 2. air drain

3. ball spring 4. spring tension

Frame 13	
figure A	r to figure A on page 4. Place the number of the component from in the blank space alongside the statement that best describes ion or operation in the Liquid Cooling System.
1.	The temperature and pressure of the liquid entering this valve will determine what route the liquid will take.
2.	When this valve is open, the liquid bypasses the heat exchanger.
3.	Picks up a high temperature indicator and turns on a warning light in the cockpit to let the pilot know about the condition.
4.	Starts the flow of liquid through the system when the radar unit is turned on.
5	Indicates that the liquid level is too low to cool the radar unit.
6.	Protects the reservoir from excess pressure.
7.	Used to remove dirt, etc., from the liquid as it leaves the radar unit.
8.	A spring loaded bypass valve that will relieve excess system pressure.
9.	Contains a manually operated valve that can be used to bleed air out of the system and drain the liquid from the system.
10.	A solenoid valve that allows for an operational and leak check of the Liquid Cooling System while the aircraft is on the ground
	o Frame 13:
If y that item	ou have missed any of the items, review the frame given for
2. 3 3. 7 4. 2 5. 8 6. 11	Frame 4 Frame 5 Frame 8 Frame 3 Frame 9 Frame 12
7. 10 8. 9 9. 11	Frame 11 Frame 10 Frame 12

PROGRAMMED TEXT

3ABR42331-PT- 407A

Technical Training

Aircraft Environmental Systems Mechanic

LIQUID CYCLE REFRIGERATION SYSTEM

31 October 1977



3350 TECHNICAL TRAINING WING 3370 Technical Training Group Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE



FOREWORD

This programmed text was prepared for use in the 3ABR42331, Aircraft Environmental Systems Mechanic Course. The materials contained herein were validated with students from the subject course. At least 90% of the students taking this text achieved or surpassed the criteria established in the lesson objective. The overage time for completion of this text was two hours 30 minutes.

OBJECTIVES

Relate eight (8) of ten (10) components of a liquid coolant and liquid cycle refrigeration system to its operation.

INSTRUCTIONS

This programmed text is divided into small sections called frames. Each frame contains information that you are required to know in order to satisfactorily complete the above listed objective. At the end of each frame there will be a form of questioning to which you will be required to respond in some manner. The correct answer(s) will be found at the end of the following frame. Due to the length of this programmed text, be certain you understand each frame before proceeding to the next.

Proceed to Frame 1

OPR: 3370TTG

DISTRIBUTION: X 3370TTGTC - 250; TTVSR - 1

2

The term air conditioning means "controlling the temperature, circulation, humidity, and purity of the air." A system which does only one or two of these functions is not considered to be a true air conditioner. The Air Force equipment which you maintain will do one, two or possibly three of these functions: Due to popular usage, these cooling units are all referred to as "air conditioners."

On the next page you will find a glossary of terms and definitions used throughout the text.



GLOSSARY

- AMBIENT AIR: The air surrounding an object.
- ATMOSPHERIC PRESSURE: Pressure at sea level. It is expressed in 14.695 pounds per square inch absolute pressure.
- BOILING POINT: The temperature at which a liquid vaporizes upon addition of heat. The boiling point will depend upon the pressure exerted upon the surface of the liquid.
- BTU (ERITISH THERMAL UNIT): The emount of heat required to raise the temperature of one pound of wat 2 one degree Fahrenheit.
- BY-PASS: A connection around a coil for the purpose of reducing the capacity of the coil.
- BY-PASS, HOT GAS: A connection from the discharge side, directly to the suction side of a compressor. Sometimes used as a means of capacity control.
- CAPACITY: It is the refrigerating effect produced and generally measured in BTUs or tons per hour.
- CAPILLARY TUBE: A tube having a very small internal and external dismeter. They are used to connect the thermal bulb to the upper disphragm chamber of an expansion valve and remote temperature controllers.
- CHANGE OF STATE: A change in the physical characteristic of a substance. For example, the change from a liquid to a gas.
- CONDENSE: To change state from a gas to a liquid.
- CONDENSER: An arrangement of pipes or tubing in which the vaporized refrigerant is liquified by the removal of heat.
- CONDUCTION: Heat transfer by contact of two substances.
- CONVECTION: Heat transfer by movement of fluid or air.
- CRITICAL TEMPERATURE: Temperature of a gas above which it cannot be liquified by pressure alone, regardless of the amount applied.
- CUT-IN POINT: The temperature or pressure at which a controller will function to start the equipment controlled.
- CUT-OUT POINT: The temperature or pressure at which a controller will function to stop the equipment controlled.
- CYCLE: Complete course of operation of refrigerant back to a starting point, also used in general for any repeated process of a system.
- DUMP VALVE: A valve used for controlling air flow.



- DRIER: A device containing a desiccant for the purpose of removing moisture from a refrigerant.
- DISCHARGE PRESSURE (HIGH SIDE PRESSURE): Operating pressure measured at the outlet of the compressor.
- EQUALIZER, EXTERNAL: A tube connecting the chamber under the disphragm of the thermostatic expansion valve to the outlet of the evaporator. Eliminate the effect of pressure drop through the evaporator on superheat response.
- EQUALIZER, INTERNAL: The port connecting the chamber under the diaphragm of the thermostatic expansion valve to the suction side of the valve passage.
- EVAPORATION: The process of converting liquid to a gas.
- EVAPORATOR: Any device in which a refrigerant is evaporated for the purpose of extracting heat from the surrounding medium.
- EXPANSION VALVE: A device designed to meter the flow of liquid refrigerant to an evaporator.
- FLASH GAS. Gas generated whenever pressure is reduced on a liquid held at boiling temperature.
- FLOODBACK: A carry-over of liquid refrigerant from the evaporator to the suction line.
- FUSIBLE PLUG: A safety device havir, an insert of low melting alloy.

 At excessive temperature this alloy will melt, and release the refrigerant.
- HEAT EXCHANGER: Any device which removes heat from one fluid and adds it to another,
- HEAT, LATENT: Heat added or removed which cannot be measured by a change in temperature but causes a change in state.
- HUMIDITY, RELATIVE: The amount of moisture in the air stated in terms of percentage of total saturation at the existing dry bulb temperature.
- LINE, DISCHARGE: Refrigerant piping or tubing between the compressor and Underser.
- LIN', LIQUID: Refrigerant piping or tubing between the receiver and expansion valve.
- LOAD, HEAT: The amount of heat per unit time imposed on a refrigerant system or the required rate of heat removed.
- LOW SIDE (SUCTION SIDE): Parts of a refrigerant system in which
 the regrigerant pressure corresponds to the evaporator pressure.



3. 7

CIL PRESSURE FAILURE SWITCH: A device which acts to shut off a compressor when oil pressure falls below a predecermined point.

PRESSURE: The force exerted upon a liquid or gas in a confined area.

PRESSURE DROP: The loss of pressure due to friction.

PU-PDOWN: The reduction of pressure within a system.

PURGE: The discharge of impurities, noncondensibles, or gases, or an overcharge of refrigerant into the atmosphere.

RECEIVER: A device for storing liquid refrigerant.

REFRIGERATION N'STEM: A system in which a refrigerant is circulated for the purpose of extracting heat.

SENSIBLE HEAT: Heat added or removed which can be measured by a change in temperature.

SIGHT GLASS: A glass installed in the liquid li e permitting visual inspection of the liqui refrigerent.

SUBCOOLING: The cooling of a liquid below its condensing temperature.

SUCTION LINE: Tubing or piping which connects the evaporator to the compressor.

SUPER HEAT: Temperature added to a substance above its boiling point.

TEMPERATURE, AMBIENT: The temperature of surrounding air.

TON OF REFRIGERATION: A unit of refrigeration capacity. Equal to 12,000 BTUs per hour or 288,000 BTUs per 24 hours.

USERUL OIL PRESSURE: The difference in pressure between suction pressure and compressor oil pressure.

VACUUM: A reduction in pressure below atmospheric pressure.

VAPOR: A fluid in the gaseous state following evaporation.

<u>VALVE PURGE</u>: A valve through which noncondensible gases or an over-charge of refrigerant may be purged from a condenser or receiver.

To put it in simple language, refrigeration and air conditioning are ways through which temperatures are reduced. Whatever the substance—solid, liquid, or gas—the process used to reduce its temperature is called refrigeration. In other words, it may be said that refrigeration is a way of removing heat from a substance when this heat is not wanted; then transferring it to another substance where it is not objectionable. For example, if the air of a room is too warm and some of the heat cap be removed and transferred to stother place, the way it is done would be called refrigeration or air conditioning.

Complete the statements in column A by placing the letter from column B in the space provided.

	Column A		Column B
1.	Refrigeration or air con- ditioning is the process	a.	a reduced temperature.
	of	ъ.	adding heat.
2.	The change in temperature by removing the heat is called	c.	refrigeration or air conditioning.
		d.	removing and transferring
3.	The result of air condi- tioning or refrigeration is		heat.

Answer to Frame 1: No Response Required.

The law that controls the transfer of heat points out that heat can be moved from a hot substance to a cool substance until both are the same temperature. Then there will be no transfer of heat. The rate at which heat will move from one substance to another will rest on the temperature difference of the two substances. The greater the temperature difference, the faster the rate of heat transfer. As the temperature difference becomes less, the rate of transfer will decrease and will stop when there is no temperature difference.


Heat can be transferred by any one of three methods: conduction, convection, or radiacion. These methods and their principles will be gone over in the frames that follow.

Answer the questions in column A by placing the letter from column A in the space provided.

	Column A		Column B
1.	Which of the temperature	+32°F and +60°F	
	groups has the most rapid rate of heat transfer?		0°F and 0°F
2.	Which one of the tempera-	c.	-32°F and +32°F
	ture groups has the slowest rate of heat transfer?		+1000°F and +950°F
3.	Which two temperature groups	e.	+68°F and +68°F
	has no heat transfer?		+30°F and +62°F

Answers to Frame 2: d 1. c 2. a 3.

When heat is transmitted from one part of a solid substance to another part of the same substance (see illustration below), or in direct contact from one solid substance to another solid substance, it is referred to as heat transfer by conduction.



Place a T (true) or F (false) in front of the statements below.

1. When one end of an iron bar is heated and the opposite end becomes warm, the transfer of heat is due to conduction.


2. Warm air from a furnace heat duct is referred to as heat transfer by conduction.

3. Heat felt over glowing charcoal in a barbecue grill is referred to as heat transfer by conduction.

4. When a solid substance that has been heated comes into direct contact with a cool solid object, and the cool object then becomes warm, the transfer is by conduction.

Answers to Frame 3: c 1. a 2. b & e3.

One of the methods of heat transfer that most of us are familiar with is called <u>convection</u>. This refers to any heat transferred by means of the movement of gas or liquids. When air (* mixture of gases) is heated, it expands and becomes lighter, which will cause it to rise. As the air becomes cold and heavy, it flows back to the source of heat where it is again heated. Thus, a circulation of air is set up that will continue as long as heat is provided. Look at the sketch below.




Place a T (true) or F (false) in front of the appropriate statements below.

- 1. Heat felt in water coming from a hot water faucet is heat transfer by convection.
- 2. Heat felt over glowing charcoal in a barbecue grill is referred to as heat trans by convection.
- 3. Warm air coming from a furnace heat duct is referred to as heat transfer by convection.
- 4. Heat transfer through a solid is referred to as convection.

Answers to Frame 4: T 1. F 2. F 3. T 4.

The other mode of heat transfer is referred to as radiation. This means that the heat is moved by rays as shown in the following sketch. In this case, a person's hand feels warm, though it is quite a distance from the source of heat. The rays pass through the air and heat the hand more than the air between the hand and heater. A good example of radiation is the rays from the sun heating our earth.



P1	ace a T (true) or F (false) in front of the statement below.
1,	Transferring heat by means of warm air is s form of radiation.
2.	The movement of heat through a solid is a form of radiation.
3.	Heat felt in water coming from a hot water faucet is heat transfer by convection.
4.	Heat felt over glowing charcoal in a barbecue grill is heat transfer by radiation.

Answers to Frame 5: T 1. F 2. T 3. F 4.

Heat intensity, or how warm a substance is, will be checked through the use of a thermometer, and the unit of measurement is called the degree. A change in temperature can be found by the thermometer, and also can be sensed by touch.

Sensible heat is referred to as heat that will cause a temperature change and can be checked with a thermometer. For example, an iron rod that is heated to 72°F then cooled to 40°F will show sensible heat loss of 32° (72°F minus 40°F equals 32°F difference).

Another form of sensible heat is <u>super heat</u>. This is known as heat added to a substante that is in its <u>gaseous state</u>. For example, water will change to steam at 212°F at sea level pressure, and the steam can then be heated to 250°F or higher. The sensible heat temperature difference between 250°F and 212°F is 38°F in the form of super heat gained while the water is a vapor. Super heat is extremely important in controlling the conditioned air temperature.

Complete the statements in column A by placing a letter from column B in the space provided. NOTE: More than one response may be used per statement.

	Column A		Column B
1.	Changing the temperature	a.	latent heat.
	of a substance is caused byadding	ъ.	sensible heat.
2.	Degreesthe unit of measure- ment for	c.	specific heat.
		d.	super heat.
3.	The thermometer will		-
	measure	e.	an increase in
4.	Sensible heat added to a		latent heat.
·	substance will cause	f.	a change of state.
		g.	a temperature change.
		h.	heat intensity.

Answers to Frame 6: F 1. F 2. T 3. T 4.

Temperature is defined as heat intensity, or, the heat level of a substance. Heat intensity is expressed in degrees and measured with a thermometer. The Fahrenheit scale is used in this country to measure refrigeration temperatures, so all measurements will be expressed in degrees Fahrenheit.

The term used to express heat quantity (amount) is the British Thermal Unit (BTU). Specifically, a single BTU is the amount of heat required to raise one pound of water one degree Fahrenheit. Two BTUs added to a pound of water will cause an increase of 2°F. The BTU is used to express the amount of heat an sir conditioner is capable of removing. A 12,000 BTU air conditioner is capable of removing 12,000 BTUs in one hour.

Place	e a T (true) or F (false) in f	ront	of the statements below.					
1.	1. Temperature is a measure of heat into sity.							
2.	Heat intensity is expressed in degrees.							
3.	Heat quantity is expressed in BTUs.							
4.	A BTU is the amount of hear required to raise the temperature of one pound of water one dagree Fahrenheit.							
	lete the statements in column . In the space provided.	A by	placing the letter from					
	Column A		Column B					
5.	Host intensity is another name for	a.	super heat.					
6.	Heat intensity is expressed	ъ.	degrees.					
	in	c.	temperature.					
7.	The British Thermal Unit	d.	sensible heat.					
	(BTU) is used to express	€.	heat quantity.					
Indicate the true statements by placing a checkmark in the spac rovided.								
8.	Two BTUs will raise 2 pounds of water 1 degree.							
<u></u> s.	It would require 6 BTUs to raise 3 pounds of water 9°F.							
10.	Five BTUs will raise 1 pound	of wa	ter 5°F.					
Answers to	o Frame 7: <u>b</u> 1. <u>b,d</u> 2.	b,g,d	3. <u>g</u> 4.					

Water will boil at 212°F at sea level pressure. To bring water to its boiling point, heat must be applied to raise its temperature. The water temperature will raise until it reaches 212°F. When water boils, it gives off a water vapor in the form of steam. (Boiling water is water that undergoes a change of state from a liquid to a gas.) After reaching its boiling point, the temperature of the water will not increase, and cannot be measured as a change in temperature even though the heat is still applied. It will stay at 212°F until all of the water is changed to steam. This hidden heat is called LATENT HEAT, and this term refers to heat gained or lost by a substance when it has a change of state (from solid to liquid, liquid to gas, gas to liquid, or liquid to solid).

Complete the statements in column A by placing the letter from column B in the space provided. Some responses will be used more than once.

	Column A		Column B
1.	When changing from a liquid to a gas, a substance absorbs	a.	sensible heat.
	• , ,	ь.	latent heat.
2.	When latent heat is added or		
	removed, there will be no	c.	change of state.
3.	The thermometer will not measure	d.	change of temperature.
		e.	super heat.
4.	Super heat is a form of		
		f.	conduction.

Answers	to	Frame	8:	T	_1.	<u>T</u>	_2.	<u>T</u>	_3.	T	4.	<u> </u>
				ь	_6.	е_	_7.	/	_8.		9.	<u>√</u> 10

SPECIFIC HEAT is defined as the amount of heat (in BTUs) that is used to raise one pound of a substance one degree Fahrenheit.


Water is used as the standard from which all specific heats are ranked. If any kind of solid, liquid, or gas takes more or less heat than water to raise its temperature one degree Fahrenheit, that percentage or ratio is known as its specific heat. One pound of water needs the use of 1 BTU (British Thermal Unit) to raise its temperature one degree. Carbon dioxide, for example, takes the use of only .6 BTUs to raise its temperature one degree. This means that carbon dioxide soaks up heat more readily than water because it needs less than one BTU to raise its temperature one degree.

Complete the statements in column A by placing the letter from column B in the space provided.

	Column A		Column B
<u>1.</u>	Specific heat of a substance	a.	causes a change of state.
2.	Water is the standard used when figuring	be	is the amount of heat required to raise the sub- stance one degree Fahrenheit.
3.	Sensible heat is referred to as the heat which	c.	causes a change of temperature.
4.	Carbon dioxide boils at -109.3°F. If its tempera-	đ.	specific heat values.
	-87°F, the temperature difference would be a form	e.	super heat.
	of sensible heat called	f.	sensible heat values.

Answers	to	Frame	9:	<u>b</u> 1.	<u>d</u> 2.	<u>b</u> 3.	<u>a</u> 4.
---------	----	-------	----	-------------	-------------	-------------	-------------





A-B to heat ice from 0° to 32° (Sensible Heat)	16	BTU
B-C to melt ice 32° to 32° (Latent Heat)	144	BTU
C-D to heat water from 32° to 212° (Sensible Heat)	180	BTU
D-E to change water to steam 212° to 212° (Latent Heat)	970	BTU
E-F to heat steam to desired temperature in closed vessel (Super Heat)		
The amount of BTUs required to change one pound of 0°F ice to 212°F Steam	1310	BTU

Chart 1.

All matter can be found in either a solid, liquid, or gaseous state and most can be changed from one state to another. While changing from one state to another, the material must gain or lose heat.

To change a liquid to a gas (boiling), the liquid must take in a great amount of heat (BTUs). For example, to change one pound of 212°F water to 212°F steam will take 970 BTUs (see chart 1). At atmospheric pressure, this change (liquid to gas) needs the greatest amount of BTUs to cause the change. We use this characteristic in refrigeration to take heat from the air. Changing a gas to a liquid (condensing) is an equally important change of state used in refrigeration. By removing the heat taken in while changing the refrigerant from liquid to gas, we can convert the gas back to its liquid state and start the cycle again.

Complete the statements in column A by placing the letter from column B in the space provided.

	Column A		Column B
1.	To cause a change of state, a material must	a	lese sensible heat.
2.	Changing from liquid to gas,	ъ.	gain latent heat.
	a material must		gain sensible heat.
3.	Changing from gas to a liquid, a material must	d.	lose latent heat.
4.	The thermometer will not	e.	gain or lose heat.
	measure		latent heat.
5.	How many BTUs are required to change 1 pound of 32°F	g.	180 BTUs.
	ice to 32°F water? Use illustration 2A in HO-601.		144 BTUs.
	III no-out.	i.	16 BTUs.

Answers	to	Frame	10:	b 1.	d 2.	c 3.	e 4.

The boiling point of water at sea level pressure (14.7 psia) is 212°F. Water can be made to boil at a different temperature by changing the pressure. See the following chart. A decrease in pressure will cause the boiling point to be lower (for example, when the pressure is reduced to 7.5 psia*, water will boil at 180°F, where it needs less heat to boil). An increase in pressure will cause the boiling point to raise. If the pressure is raised to 20.7 psia, water will boil at 230°F (where it needs much more heat to boil).

Any increase in heat when a liquid is boiling will only cause the boiling rate to increase (boil faster). This rule is true for all liquids and is used in refrigeration to control the boiling and condensation points of the refrigerants.

*		
180		7.51
190		9.34
200	*	11.53
210		14.12
212	•	14.70
215		15.79
220		17.19
230		20.78
240		24.97
250		29.82

Temperature-Pressure Relation for Boiling Water.

*psia -- pounds per squre inch absolute.

Pi below.	ace a checkmark (/) in front of the correct statement(s)
1	Paising the pressure on a liquid will require less heat for the liquid to boil.
2	Lowering the pressure on a liquid will require more heat for the liquid to boil.
3	Lowering the pressure on a liquid will cause the liquid to boil at a lower temperature.
4	Lowering the pressure on a liquid will cause the liquid to boil at a higher temperature.
A	and France 11. on 1 by 2 d 3 f // b 5.

The temperature and pressure that will cause a gas to change to a liquid is called the condensing point. The condensing point c.n also be made to take place at a different temperature by a change in pressure. An increase in pressure will cause a gas to condense at a higher temperature. A cacrease in pressure will cause a gas to condense at a lower temperature. When a gas does change to a liquid, it must give out the same amount of heat that was soaked up in the change to a gas. The rate (speed) that a gas will turn to a liquid can be controlled by controlling the temperature of the substance used to catry the heat away. The most common substances used to remove heat, to condense a gas, are air and water.

Complete the statements in column A by placing the letter from column B in the space provided.

	Column A		Column B
1.	To condense at a lower temperature	a.	will decrease the condensing rate.
2.	Increasing the tamparature of the substance carrying away the heat	b.	the material must give up less heat than was absorbed changing to a gas
3.	To cause condensation	c.	will increase the condensing race.
4.	Increasing the pressure will cause a substance in its gaseous state to	d.	the pressure must be reduced.
		e.	the substance must give up the same amount of heat absorbed while changing to a gas.
		f.	condense at a higher temperature.
		g.	condense at a lower temperature.
nnswers (to Frame 12:12.		4.

When selecting an air conditioning unit, the heat load must be known. The ambient (surrounding) air temperature, the amount of air to be cooled, and the amount of moisture in the air (humidity) are conditions which make up the heat load. An increase in any of the above factors puts an additional load on the unit, and reduces its efficiency. Heat load and unit cooling capacity are expressed in BTUs or tons. A unit rated at one ten means that it has the capability of removing 12,000 BTUs per hour. (Refer to the chart below.)

BTU per hour	Tons
24,000	2
12,000	1
9,000	3/4
6,000	1/2

Complete the statements in column A by placing the letter from column B in the space provided. Use the chart as necessary.

	Column A		Column B
1.	Reducing the amount of air to be cooled	a.	any of the heat load factors is reduced.
2.	Any unit will be more efficient if	ъ.	increases the heat lord.
_		c.	decreases the heat load.
3.	A unit capable of removing 54,000 BTUs is equal to (quantity)	đ.	any of the heat load factors is increased.
4.	A unit capable of removing	e.	6 1/4 tons.
	138,000 STUs is equal to (quantity)	f.	12 tons.
		g.	4 1/2 tons.
	,	h.	11 1/2 tons.

Answers to Frame 13: d 1. a 2. e 3. f 4.

In an air conditioning unit, the liquid used for cocling is called the "refrigerant". A refrigerant is any substance which is used for the purpose of removing and transferring heat. Materials with low boiling points are better suited for refrigerants than ones with high boiling points. The most common refrigerant used in Air Force air conditioning equipment is Freon 12, which has a boiling point of -21.7°F at sea level pressure. When this fact is related to water (boiling point 212°F at sea level pressure), it is plain to see that Freon 12 can absorb heat at very low temperatures. Freon 12 (R-12) is kept in the liquid state at normal room temperatures by storing it in steel cylinders under pressure.

_1.	A refrigerant is any material used to absorb and transfe heat.
2.	A substance with a high boiling point is well suited for air conditioning.
3,	To prevent R-12 from hoiling at room temperature; it must be kept under pressure.
4.	A liquid used for cooling air is referred to as a refrigerant.

Answers	to	Frame	14:	c 1.	a 2.	g 3.	h 4
					~~~~		

A good refrigerant should have as many of the following properties as possible:

- 1. Low boiling point.
- 2. Low condensing pressure so that air-cooled condensers can be used.
  - 3. Non-toxic.
  - 4. Non-flammable.
  - 5. Will not of oct the lubricating oil.
  - 6. Non-corros.ve.

regardless of the type refrigerant used, there are always some precautions which should be observed. When working with R-12, the operator must observe the following precautions:

- 1. Always insure adequate ventilation.
- 2. Always wear face shields or goggles.
- 3. Store cylinders in a cool, dry area away from flammable materials.
- 4. Refrigerant cylinders should be chained upright in storage and have protective caps over the valves.

NO RESPONSE REQUIRED.

Answers to Frame 15:  $\underline{T}$  1.  $\underline{2}$ .  $\underline{T}$  3.  $\underline{T}$  4.

Complete the statements below by circling the correct response.

- 1. Refrigeration or air conditioning is the process of
  - a. adding heat.
  - b. circulating humidity.
  - c. purifying air.
  - d. removing and transferring heat.
- 2. Which of the following temperature groups has the most rapid rate of heat transfer?
  - 4. 52°F and 62°F.
  - b. -32°F and +32°F.
  - c. 800°F and 850°F.
  - d. 212°F and 240°F.
- When a solid object is heated and the opposite end becomes warm, the transfer of heat is due to
  - a. convection.
  - b. conduction.
  - c. radiation and convection.
  - d. conduction and radiation.
- 4. Warm air coming from a furnace heat duct is referred to as heat transfer by
  - a. convection.
  - b. conduction.
  - c. radiation and convection.
  - d. radiation and conduction.
- 5. Heat felt from the sun is referred to as heat transfer by
  - a. convection.
  - b. radiation.
  - c. conduction.
  - d. thermal rays.



23

### 3085

### Frame 17 (Cont'd)

- 6. Changing the temperature of a substance is caused by adding
  - a. super heat.
  - b. latent heat.
  - c. specific heat.
  - d. sensible heat.
- 7. When the term "degree" is used, it indicates
  - a. heat quantity.
  - b. heat intensity.
  - c. hest amount.
  - d. heat values.
- 8. Three BTUs will raise 3 pounds of water
  - a. one degree.
  - b. three degrees.
  - c. six degrees.
  - d. nine degrees.
- Heat gained or lost by a substance during a change of state is referred to as
  - a. super heat.
  - b. sensible heat.
  - c. latent heat.
  - d. specific hear.
- 10. The percentage of any substance requiring more or less heat than water to raise its temperature one degree Fahrenheit is called
  - a. specific heat.
  - b. super heat.
  - c. latent heat.
  - d. sensible heat.

472

### Frame 17 (Cont'd)

- 11 Changing from a liquid to gas, a material must
  - a. gain latent heat.
  - b. gain sensible heat.
  - c. lose latent heat.
  - d. lose sensible heat.
- 12. An increase in pressure will
  - a. require less heat for water to boil.
  - b. require more heat for water to boil.
  - c. cause the boiling point to be lower.
  - d. none of the above.
- 13. Which of the following statements is true?
  - a. Raising the pressure on a liquid will require less heat for the liquid to boil.
  - b. Lowering the pressure on a liquid will require more heat for the liquid to boil.
  - c. Lowering the pressure on a liquid will cause the liquid to boil at a lower temperature.
  - d. Lowering the pressure on a liquid will cause the liquid to boil at a higher temperature.
- 14. To cause condensation,
  - a. the pressure must be reduced.
  - b. the temperature must be increased.
  - c. the material must give up less heat than was absorbed in changing to a gas.
  - d. the subscance must give up the same amount of heat absorbed in changing to a gas.

# 3087

## Frame 17 (Cont'd)

- 15. The heat load is determined by
  - a. ambient air temperature.
  - b. amount of air to be cooled.
  - c. humidity.
  - d. all of the above.

### Answers to Frame 17:

If you answered any of the statements incorrectly, review the following frames.

QUESTION . UMBER	Answers	review F <u>rame</u> s
1	ď	2
2	ъ	3
3	Ъ	4
4	a	5
5	ъ	6
6	đ	7
7	Ъ	8
8	a	8
9	c	9
10	a	10
11	<b>a</b> '	11
12	ь	12
13	C	12
i <b>4</b>	đ	13
<b>½</b> 5	đ	14

471




Figure 1.



Frame 18

The refrigeration system has five basic components--receiver, expansion valve, evaporator, compressor and condenser (look at figure 1). As the refrigerant flows through these components, it will go through changes in its pressure and state. All refrigeration and air conditioning units have a high and low pressure side, each side having a distinct function. The cooling of ambient air takes place in the low pressure side (evaporator), where the refrigerant changes state (low pressure liq ld to a low pressure gas). The refrigerant boiling at a low temperature under low pressure absorbs heat from the ambient air.

The high side of the system provides the conditions to condense and store the liquid refrigerant. The compressor increases the pressure and temperature of the low pressure gas to a point at which it can be changed to a liquid. As the high pressure gas flows through the condenser, the heat is released to the ambient air. As heat is given off by the high pressure gas, it will return to its liquid state. The five basic components will be explained in detail later.

Complete the statements below by filling in the blanks with the correct terms.

	1.	In a refrigeration system, the components where the
refr	igera	ant changes state are he and
	2.	The low pressure side of a refrigeration system is where
the .		takes place.
	3.	The refrigerant is liquified and stored in
		·
	4.	The refrigerant in the condenser is liquified by



When the refrigeration system is not in operation, the liquid refrigerant is stored in the <u>receiver</u>. (Look at figure 1, item 1 for the location of the receiver in the system.) The receiver is a steel tank and should never be completely filled with liquid. Eighty (80) percent liquid is the general rule when filling the receiver.

The Temperature Pressure Chart was devised from this general rule (see figure 2). The remaining 20% of the tank is used to allow the refrigerant to expand and contract when the outside temperature changes. As the ambient temperature increases, pressure in the tank also increases. An ambient temperature of 90°F will result in a pressure of 100 psig in the tank (look at figure 2).

If the outside temperature decreases, some of the gas will condense and reduce the pressure. An 80°F ambient temperature will result in 84 psig in the receiver.

Complete the statements in column A by placing the letter from column B in the space provided. Some responses may be used more than once.

	Column A		Column B
1.	The pressure in the receiver is determined by the	a.	size of the receiver.
2.	A wide in subject temperature	ъ.	ambient air temperature.
	A rise in ambient temperature will cause	c.	condensation in the receiver.
3.	More than 80% liquid in the receiver will cause	d.	the pressure to increase
4.	Using figure 2, compute the		in the receiver.
	pressure for 96°F ambient temperature.	e.	normal pressure.
	temperature.	f.	106.5 psig.
		g.	less pressure in the raceiver.
		h.	110 psig.

Answers to Frame 18: 1. evaporator, condenser 2. cooling
3 the high side 4. removing heat



TEO F	PSIG	TEMP ^o F	PSIG	TEMP F	PSIG
0	9.2	54	51	108	132.4
2	10.2	56	53.1	110	136.4
4	11.3	58	<b>35.</b> 6	112	140.5
6	12.4	60	57.7	114	144.7
8	13.5	62	60.1	116	150.0
10	14.7	64	62.5	118	153.2
12	15.9	66	65.0	120	<b>-57.7</b>
14	17.1	68	67.6	122	162.1
16	18.4	70	70.1	124	166.7
18	19.7	72	72.9	126	171.4
20	21.1	74	75.6	128	176.1
22	22.5	76	78.4	130	181.0
24	23.9	78	81.2	132	185.9
26	25.4	80	84.1	134	191.0
28	27.0	82	87.1	136	. 196.1
30	28.5	84	90.2	138	201.3
32	30.1	86	93.3	140	, 206.6
34	31.7	88	96.5	142	212.0
36	33.4	90	99.8	144	217.5
38	35.2	92	103.1	146	223.1
40	37.0	94	106.5	148	228.9
42	38.8	96	110.0	1,50	234.0
44	40.7	98	113.5	152	240.5
46	42.7	100	117.1	154	246.5
48	44.7	102	120.9	156	252.6
50	46.7	104	124.6	158	258.8
52	48.8	106	128.5	160	265.1

Pressure and Temperature of Refrigeranc 12.

Figure 2.

178




Figure 3.

As with any tank, there must be an inlet and outlet. This has been provided on the refrigerant receiver. Manual valves are placed at both points. An inlet valve is put in between the condenser and the receiver. Generally this is mounted on the receiver itself. This valve is a common valve, just like a valve used with water, but may have a back seat position and an access port to the system. (See figure 3.) The back seat position (full counterclockwise) will close the access port so at gages may be put in to check the pressures in the system.

The outlet valve always has the back seat position to close the access port (charging port). This port is used for charging with a liquid (build up the amount of liquid refrigerant). A tube (dip tube) is hooked to the outlet valve and extends well below the liquid level of the receiver (see figure 1, item G). This makes sure that only liquid refrigerant gets into the liquid line. Both valves, when closed, will isolate the receiver from the remainder of the system (see figure 1, items G and H).

Fill in the blanks with the correct terms.

1. Manual valves are used to _______ the receiver.

2. The access port on the receiver outlet valve provides a place to _______ the system with liquid.

3. The back seat position of the valve _______ the access port.

4. The tube (dip tube) attached to the receiver outlet valve insures _______ enters the liquid line.

Answers to Frame 19: b 1. d 2. d 3. h 4.

The refrigeration system is under constant pressure with the high side having the highest pressure. A protective device is placed in the high side to prevent overpressurization of the system. The excessive pressure can cause leaks, resulting in loss of the refrigerant. One of the most common protective devices is the <u>fusible plug</u> (see figure 1). This is a threaded male plug that is placed in each end of the receiver. A lead alloy substance, placed in the center of the plug, will melt at a set temperature. If the pressure increases, temperature will also increase. When the melting point of the alloy is reached, the pressure that is in the tank will blow out the softened lead, relieving all pressure.

Complete the stateme ts in column A by placing the letter from column B in the space provided.

Note: Some questions may require more than one response.

	Column A		Column B
1.	The fusible plug protects	a.	the low side of the system.
2.	Excessive system pressure can cause	ъ.	better cooling.
3.	Leaks will result in	ċ.	the high side of the system.
4.	When pressure in the system increases	d.	leaks at the soldered joint.
,	1	e.	increased efficiency.
	•	f.	loss of refrigerant.
		g.	temperature decreases.
		ь.	temperature increases.

Answers to Frame 20: 1. isolate 2. charge 3. isolates
4. only liquid refrigerant

Frame 22

While the refrigeration system is in operation, the high pressure liquid refrigerant flows through the liquid line on its way to the expansion valve. The expansion valve is most important to efficient system operation. For this reason, a filtering device is placed in the liquid line. This filter is referred to as the "dehydrator" (see figure 1, item I). It takes out moisture and foreign particles from the refrigerant. Moisture in the system can cause the following: sludge in the compressor, freezing at the expansion valve, and corrosion in the system. The drier, part of the filter soaks up any moisture that may have been left in the system. The strainer, placed in the outlet end of the filter, takes out any foreign particles that may be in the refrigerant.

Complete the statements in column A by placing the letter from column B in the space provided.

	Column A		Column B
1.	If moisture enters the	a.	strainer.
	system it can cause	ъ.	efficient operation.
2.	Foreign particles are removed by the	c.	moisture from entering the system.
3.	Good maintenance practices	_	
,	can prevent	. <b>đ.</b>	sludge.
<u> </u>	The drier absorbs	e.	drier.
	•	· f.	moisture.

Anguare	to	Frame	21:	<u>c</u> 1.	d&f 2.	f 3.	h 4
Witamera	LU	rrame	<b>~ -</b> •				

The refrigerant will pass by a "sight glass" after leaving the dehydrator. The sight glass is a port placed in the liquid line, with a glass insert that will let the mechanic visually check the condition of the refrigerant. Look at figure 1, item J, to find the sight glass. A normal sight glass indication is a completely clear glass. If bubbles are seen, it can mean a shortage of refrigerant or a restriction in t' liquid line. If the refrigerant is discolored, it may mean that oil is circulating with the refrigerant. If discoloration is noted but disappears after a few minutes of operation, this would be considered normal. If the discoloration continues, a problem is indicated which will be explained in the troubleshooting section.

Complete the statements in column A by placing the letter from column B in the space provided.

	Column A	•	Column B
1.	The sight glass is installed in the	a.	discoloration of the refrigerant.
	A clear sight glass is an indication of		bubbles in the sight glass.
3:	A shortage of refrigerant will be indicated by	c.	an adequate refrigerant supply.
4.	Oil circulating with the refrigerant may cause	d.	liquid line.
1	ć*	e.	receiver.
,			

Answers to Frame 22: d 1. a 2. c 3. f 4.




Figure 4.




Figure 5.

After it goes through the sight glass, the liquid refrigerant goes in the expansion valve (look at figure 1, item=M). The expansion valve is a metering device that lets the liquid refrigerant go in the cooling coil (evaporator) in the amount needed to cool the heat load. The liquid refrigerant goes in the expansion valve as a high pressure liquid and flows out as low pressure liquid. This is possible because the outlet and the connecting tubing are larger than the inlet. Look at figures 4 and 5 on the preceding page.

The cut in pressure will cause the refrigerant to boil at a low temperature in the evaporator. For example, the pressure keeping the refrigerant as a liquid at 90°F must be at 99.8 psig. If, after passing through the expansion valve, the pressure is cut down to 40 psig, the refrigerant will boil at a lower temperature (44°F). Look at figure 2 on page 30.

Complete the statements below by placing the missing words in the blanks.

	1,.	After leaving the receiver, the liquid refrigerant enters					
the	,	on its way to the					
	¹ 2.	The expansion valve is a device.					
	3. An increase in heat load will cause the expansi						
to	allow	to enter the evaporator.					
	4.	The refrigerant enters the expansion valve as a					
,							
	5.	With the pressure reduced to 35.2 paig, the boiling point					
of :	F-12 ´1	sF. Refer to illustration 2 of HO-601.					
the	6, out,1e	The inlet to the expansion valve is than					

Answers to Frame 23: d 1. c 2. b 3. a 4



Framc 25

After it leaves the expansion valve, the refrigerant goes through the evaporator, where the real cooling takes place (see figure 1, item A).

An evaporator is a device (usually finned copper tubing when F-12 is used) in which the refrigerant is evaporated for the purpose of taking heat from the surrounding air.

As the refrigerant goes in the evaporator, it is a low pressure liquid. After it soaks up heat from the surrounding air through the walls of the evaporator, it changes from a low pressure liquid to a low pressure ges; so, on the inlet side of the evaporator, there is mostly liquid. As the refrigerant goes through the evaporator coils, more and more of the liquid is vaporized (boiled off) until at the outlet end, there is nothing but vapor. Look at figure 5 on page 36.

Complete the statements below by placing the correct terms in the space provided.

1.	The refrigerant changes from a		
, 7,		•	£ th
<del></del>	to a		
in the e	vaporator.	•	•
12.	The refrigerant boils at a low temperature	in the	evaporator
because	is lowered.		
3.	Cooling the heat load actually takes place	in the	•
			•
4.	The refrigerant leaves the evaporator as 1	${\bigcirc}$	
		,	

Answers to Frame 24: 1. liquid line, expansion line 2. metering

3. more refrigerant 4. high pressure liquid.

. 38'F 6. smaller

The refrigerant leaves the evaporator and goes in the suction line as a low pressure gas (vapor). The suction line hooks the evaporator to the suction service valve on the compressor. The suction service valve provides a place to charge the refrigerant supply on the low side (gas). The valve has the same positions as the receiver outlet valve (forward and back seat position), see figure 3, page 31. The refrigerant now goes in the compressor (figure 1, item E) where it is set up for the condensing process. This takes in the raising of its pressure and temperature. Ambient air is used to take heat from the refrigerant so the compressor must raise the temperature of the refrigerant above ambient temperature. The refrigerant temperature that leaves the compressor will be approximately 30°F above ambient temperature. If for example, the ambient air is 80°F, the temperature of the refrigerant gas will be raised to approximately 110°F when it leaves the compressor. As the ambient air temperature increases, the temperature and pressure of the refrigerant that leaves the compressor also increases.

Complete the statements in column A by placing the letter from column B in the space provided.

•	Column A		Column B
1.	Pressure leaving the com- pressor is determined by	a.	size of the receiver.
	the	ъ.	receiver.
2.	Changing the low pressure gas to high pressure gas to	c.	suction service valve.
, A.,	is done by the	* d.	ambient air temperature.
3.	The refrigerant leaving the evaporator must be	e.	compressor.
4.	An increase in ambient	f. へ	high pressure gas.
	air temperature will.	g.	compressor discharge pressure to remain
5.	Charging with gas is done	*	constant .
·	at the	h.	compressor discharge préssure to increase.
, ~ ,		i.	low pressure gas.

Answers to Frame 25: 1. low pressure liquid, low pressure gas

2. pressure 3. evaporator

low pressure gas

The refrigerant now leaves the compressor through the compressor discharge valve. The valve is manual type and, when it is closed, it isolates the compressor from the high side. The high pressure refrigerant gas then goes in the discharge line and flows into the condenser, see figure 1, item B. The condenser is a coil of finned copper tubing similar in design to a car radiator. The heat picked up by the refrigerant in the evaporator, and the heat of compression are passed on to the air in the condenser. When the heat is taken from the hot high pressure refrigerant vapor, it will go back to its liquid state. Gravity now returns the liquid to the receiver where it is stored until it is needed by the expansion valve. This liquid will go in the receiver through the receiver inlet valve, look at figure 1, item H.

Complete the statements in column A by placing the letter from column B in the space provided.

Column B Column A low pressure gas. The function of the condenser is to it remains a gas. The refrigerant entering the change high pressure gas condensar is a to a high pressure liquid. When heat is removed from the high pressure gas. hot refrigerant gas it changes to liquid. When the expansion valve a. meters refrigerant into the low pressure liquid. f. evaporator, it is a

Answers to Frame 26: d 1. e 2. i 3. h 4. c 5.

The basic system operation starts with the high pressure liquid refrigerant in the receiver. When the system is started, the liquid refrigerant flows to the expansion valve where its pressure is cut down. The refrigerant goes in the evaporator as a low pressure liquid. where it boils at a low temperature and soaks up heat from the surrounding air. The refrigerant leaves the evaporato, as a low pressure gas and flaws to the compressor. The compressor gets the refrigerant ready for the condensing mode by raising its pressure and temperature. When it is compressed, the temperature of the refrigerant will be " close to 30°F above the ambient temperature. The discharge pressure can be found with ease by using figure 1. For example, 70° ambient temperature plus the 30° from compression is 100°F. Looking at figure 2, we find a pressure of 117, psig would be the discharge pressure. To complete the cycle, the gaseous refrigerant must be returned to its liquid state. This is accomplished by the condenser where the hot refrigerant gas gives up its heat to the surrounding ambient air. The refrigerant returns by gravity to the receiver, where it is stored until needed by the expansion valve.

Complete the statements in column A by placing the letter from column B in the space provided.

#### Part I

#### Column A Column B The increase in refrigerant condenser. pressure is done by the expansion valve. In the evaporator, the refrigerant changes from . compressor. When the ambient temperad. evaporator. ture is 90°F, and the unit operating, the discharge liquid to gas. pressure will be eas to diquid. The refrigerent absorbs heat in the 157. 7 psig. The refrigerant leaves the 136.4 psig. condenser as a high pressure liquid. low pressure liquid.

Frame 28 (Cont'd)

Match the component in column A to its function by placing the letter (preceding the correct function) from column E in the space provided.

				•
•	*	Part II		· · · · · · · · · · · · · · · · · · ·
•	Column A	, •	,	Column B
1.	Receiver / .	¢	a.	Permits charging on the low side.
2. 3.	Receiver charging property of the Control of the Co	oort •	b.	Removes moisture and foreign particles.
4.	Expansion valve		<b>c.</b>	Meters refrigerant into the condenser.
5.	Evaporator	٦,		Meters refrigerant into
,	C	, h	e. _	Permits charging on the high side.
•		· <b>5</b>	f.	Stores refrigerant.
		•	<b>g.</b> .	Where heat is removed from the air.
	•	,	ψ.	Where heat is given up to the air.

Answers to Frame 27: 490




Figure 6.

## Frame 29

The temperature control unit (thermostat) works like the thermostat used in the home. It is built to open or close an electrical circuit in line with changes in temperature. The thermostats used are referred to as ramote bulb thermostats. The remote bulb is placed in the zone where control of the temperature is needed. The bulb is filled with refrigerant and is hooked to a pressure operated switch by means of a capillary tube. When the temperature of the air rises above the thermostat setting, some of the refrigerant will boil and cause a pressure rise in the bulb and capillary tube. The pressure rise will close the electrical switch and start the system operating. (Look at figure 6, view 2, on the preceding page.) The system will continue to work until the air temperature drops to the thermostat setting. The reduced air temperature will cause some of the refrigerant to bondense in the bulb. When the refrigerant in the bul's condenses, pressure will be reduced and the switch will open (look at figure 6, view 1) and stop system operation.

Complete the statements in column A b, placing the letter from column B in the space provided.

•	Column A	,	Cc mn 3
1.	To control the conditioned	A.	causos pressure to
	sir temperature the remote bulb must be		increase in the bulb.
	carp mas be	ъ.	causes pressure to change
2.	A pressure increase in the bulb will		in the bulb.
-	•	c.	start the system
<del>3</del> .	Air temperature changes		operating.
4:	The refrigerant in the bulb will condense if	<b>d.</b> ':	stop the system operation.
•		e.	the air townerature drops
	•	f.	the air ature rises
		g.	placed where control of

Answers to Frame 28:

needed.

Frame 30

Match the response (component to function) from column B to the statement in column A by placing the letter preceding the response in the space provided.

· · \	Column A		Column B
1.	The basic refrigeration system consists of the	<b>a.</b>	suction line.
•	••	ъ.	evaporator.
2.	Cooling of the heat load takes place in the	c.	the low pressure cutout will stop the compressor.
3.	The receiver is filled with	d.	expansion valve.
<b>4.</b>	The receiver outlet valve	٠.	enpairoson vazvo.
<del></del>	provides a place to	e.	moisture from the liquid refrigerant.
5.	The drier-strainer removes	f.	thermostat.
6.	The sight glass is installed in the	g.	liquid line.
7.	Liquid refrigerant i metered into the evaporator by the	h.	80% liquid and 20% gas.
		i.	low pressure gas to high.
8.	The change from low pressure liquid to low pressure gas occurs in the	j.	high side of the system.
		k.	receiver, expansion valve,
9.	The low pressure gas enters the compressor through the		avaporator, compressor and condenser.
10.	The compressor changes	1.	replenish the refrigerant on the high side.
11.	The temperature control unit		•
<del></del>	is referred to as a	m.	high pressure gas to high pressure liquid.

Angwars	to	Frame	29:	<u>g</u> 1.	c 2.	ъ 3.	<b>e</b> 4
VITTO M C F 2							



3/07

Answers to Frame 30:

Refer to the frame number listed in the right-hand column for additional information on items missed.

	•
<u>k</u> 1.	F-18
1_2.	F-18
<u>h_3.</u>	F-19
1_4.	F-20 .
<u>e</u> 5.	F-22
<u>8</u> 6.	F-23 •
<u>d</u> 7.	F-24
<u>b'</u> 8.	F-25
<u>a</u> 9.	F-26
<u>i</u> 10.	F-28-
<u>f</u> 11.	F-29

When you have completed frame 30 and reviewed the items missed, report to your instructor. You are now ready to take the test. When successfully completed, the instructor will assign your next project.

Frame 31

Because of the tubing and connections used in a refrigeration system, the possibilities of a leak of the refrigerant exists. Either of two methods can be used to detect leaks.

The most widely used leak detactor for refrigeration systems is the "halide torch." The torch consists of bottled gas, a chimney chamber with a glow plate, and a sampling tube. To use the torch as a leak detector, move the sampling tube slowly around the outside of any gasketed joint, seal, or fitting. At the same time, watch the flame for the slightest change in color. The color of the flame changes when a leak is found. A very faint color change indicates a small refrigerant leak. A very bright and vivid color change indicates a very large leak. The torch must be used in a well ventilated area. It only indicates that the leak is in the general area. It does not pin-point the leak.

The safest method for leak detection is the use of a soap and water solution. This method requires that you use a thick, almost pasty, mixture of soap and water. The solution is made up of 50% soap and 50% water. To make sure that the solution bubbles well, you can add a few drops of glycerine. Apply the mixture to the points where you suspect the leak to be. The leak will cause the solution to bubble and give you the exact location of the hole.

Place a checkmark (/) in front of the correct statement(s) below.

1. When using the halide torch a very bright and vivid color change in the flame indicates a very large leak.

2. The safest method for leak detection is to use a soap and water solution.

3. When using a soap and water solution to detect leaks a very faint color change in the solution indicates a small leak.

4. The most widely used refrigeration leak detector is the halide leak detector.

Answers to Frame 31:  $\sqrt{1.4}$   $\sqrt{2}$ .  $\sqrt{4}$ 

٠,

78-47712

WORKBOOK

3ABR42331-WB-407

Technical Training

Aircraft Environmental Systems Mechanic

LIQUID REFRIGERANT SYSTEM MAINTENANCE

8 December 1978.



CHANGTE TECHNICAL TRAINING CENTER (ATC)
3370 Technical Training Group
Chanute Air Force Base, Illinois

DESIGNED FOR ATC COURSE USE

DO NOT USE ON THE JOB



Environmental Pneudgaulics Branch Chanute AFB, Illinois 3ABR42331-WB-407

· LIQUID REFRIGERANT SYSTEM MAINTENANCE

#### OBJECTIVES

- 1. Using an inspection workcard, maintenance data collection forms, and a trainer, inspect a liquid refrigeration system recording a minimum of two discrepancies. One instructor assist, per form, is pormissible.
- 2. Using a trainer, perform an operational check of a liquid refrigerant system with one instructor assist.
- 3. Using a trainer and schematic, troubleshoot a liquid refrigerant system with one instructor assist.
- 4. Using a trainer and the necessary equipment, bench check and repair system components with one instructor assist.

### **EQUIPMENT**

•		Dasis of issue
Inspection Workcard		1/student
AFTO Form 349		8/student
Toolkit		1/student
Freon cylinder		1/student
Manifold gage assembly		1/student
H-10 leak detector	1	1/stydent
Leak Tec soap solution	i	1/stůdent
Vacuum pump		1/student
Trainer 4369, liquid refrig	د	1/student

This workbook deals with inspecting, operating, and trouble-shooting the refrigerant system. At strategic points throughout the procedures you will be required to have the instructor check your work and initial the workbook when the work is satisfactory. At the end of each section you will be required to have the instructor sign the completed workbook.

#### INSPECTION PROCEDURES

Using the AFTO Form 26 provided by your instructor as a guide, inspect each item listed thereon, recording a minimum of two discrepancies on the AFTO Form 349. One instructor assist is permissible on each discrepancy.

This supersedes 3ABR42331-WE-409, 15 November 1977. OPR # 3370 TCHTG

DISTRIBUTION: X

3570 TCHTG/TTGU-P - 400; TTVSA - 1




## OPERATING PROCEDURES

This workbook is to be used as the source for procedures to operate the air conditioner trainer. During operation, remember to observe the gages and indicators so you can determine the serviceability of the unit. The readings observed must be compared with the specifications found in table 1 to determine the exact status of the unit. Read at least one

(1) step shead throughout this workbook.

Refer to PT-409A to complete the following diagram. This is a basic refrigeration system.



Color the system according to the key at the right of the diagram and also show direction flow.

Figure 1.

3



# REFRIGERATION SYSTEM

Before Refrige	e beginning the operational check, view the film Principles	<b>\$</b> ,
OPERATIONA	• / •	
Note:	Place your initials in the space provided when you complestep in the workbook.	ete
1.	Obtain the manifold gage assembly and toolkit from the trainer cabinet.	
2.	Hang the manifold gage assembly on the back of the trainer	•
3.	Locate the "refrigeration system deagram" on the trainer.	
4.	Using a grease pencil, trace on the diagram to show how the manifold gage lines should be connected to the system components for reading system operating pressures. When you are complete, have your instructor check your work.	0-
·	INSTRUCTOR'S INITIALS	•
5.	Remove the two large caps from the discharge and suction service valves on the compressor. BACKSEAT BOTH VALVES SLOWLY BY TURNING THE STEMS COUNTERCLOCKWISE ALL THE WAY BACK. DO NOT OVERTIGHTEN.	`\
6.	Remove the two small caps from the discharge and suction ports on the compressor.	•
7.	Connect the lines to the system components as you have draw them on the system diagram, the low side on the manifold g to the suction service port and the high side on the manif gage to the discharge service port.	age
	INSTRUCTOR'S INITIALS	•
8.	Check the LOW and HIGH side valves on the manifold gage assembly to make sure they are in the closed (clockwise) position.	
9.	Take the ratchet wrench from the toolkit and position the suction and discharge service valves on the compressor to the "GAGE" position. (3 turns in)	
	INSTRUCTOR'S INITIALS	
10.	Put on goggles and purge the HIGH and LOW hoses by looseni the connections to the manifold assembly. When the hoses have been satisfacterily purged (one at a time) tighten the connection. Place a cloth around the connections to prevere from spraying.	ne
	Both gages (high and low) on the manifold should indicate the same amount of pressure. NOTE: This is due to the compressor not operating. The pressure pushes out of the receiver and through the system. Read the pressure by looking at the black scale.	٠,
	INSTRUCTOR'S INITIALS	

12.	Record the ten	merature of	the evaporat	tor coils (	on Table I	
13.	Connect the popular significant control of the cont	ower cord to	110/115V AC	wall outle	t. The trai	nei
14.	Place the comp sight glass. as they circul operating. No a green dot. moiscure in the means that the should be clea	The freon and the through office in the So long as the system.	nd oil will the system of the center of the center of the green excessive me	rise in the due to the he sight go green, the turns to	e sight glass compressor lass there is is indicates yellow, this	no
`	_ INSTRUCTOR'S 1	•		/	,	, ,
15.	Operate the unany unit readiblenks in table gages on the name and the second se	ings. After le 1. Take y manifold gage	at least ter your reading assembly (	n (10) minus from the	utes fill in high and low	the
		Normal Reading	Unit Reading	SAŢ.	UNSAT.	
DISCHARG	E PRESSURE GAGE	90-130 psi		***************************************		
SUCTION 1	PRESSURE GAGE	20-35 psi			<del></del>	
SIGHT GL	ASS JRE OF EVAPORATO	<u>clear</u> OR a.	b. 3	c.		
, _	-	Table	1.	k.		
•	•	•			4	•
Note var	r The reading y in psi due to Record the ten (space "b").	ambient temp	the evaporation	und the eve tor coils (	pporator.	
. Shutdown	PROCEDURES	•		. ,		
1.	Place the comp	ressor switch	th to the "O	FF" position	on,	
2.	Unplug the pow	er cord from	the wall re	cceptacle.	•	,
TROUBLES	HOOTING PROCEDUR	ŒS				
Î. provided	If an CUMPATIS	FACTORY" cor	ndirion was	noted, reço	ord in the sp	ace
	a. TROUBLE _	,		<del> </del>		-
						-
-			-			

ERIC

^		· '
	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·
,		<u> </u>
ble to eliminate of clumn as you go the final operation	lyze all probable causes careffeach listed cause as indicated arough this workbook. Then whe hal check, you can reverify the inated the problem.	in the "REMEDY" en you have completed
TROUBLE	PROBABLE CAUSE	REMEDY )
Subbles appear in sight glass	Shortage of freon (system pressure will also be low)	Compare suction pressure to TP chart. Service system.
· •	Moisture	Check moisture indicato in sight glass. If yellow, evacuate the system.
1	Clogged drier strainer	R&P drier strainer
	Superheat adjusted too high	Adjust expansion valve (ccw)
Low suction '	Shortage of freon	Service.system
- ম	Dirty air filter	Purge and evacuate system
~	Oil clogged evaporator	Purge and evacuate system
•	Low load	R&R drier strainer
High discharge	Air in the system	Evacuate and reservice system
,	Overcharge of freon	Partially drain and reservice
	Receiver inlet valve not fully open	Open valve fully
High suction	Oversized expansion valve	Replace expansion valve
pressure	Expansion valve seat leak	Replace expansion valve
	Low superheat adjustment	Adjust expansion valve (cw)
4	(6501	

# DRAINING SYSTEM PRESSURE

SAFETY: Put on soggles (located in trainer cabinet) for steps one through five.

	one	through five.
REMQ	VAI.	
•	_1.	Backseat the compressor's discharge valve by backing it out.  Leave the suction valve in the "GAGE" position.
		TION: DO NOT OVERTIGHTEN THE VALVE(S) WHEN YOU ARE FRONT ING OR BACK SEATING THEM.
	_2.	Obtain the drain can from the trainer cabinet.
	_3.*	Connect one end of the line to the manifold gage assembly service port (see trainer diagram). Place the other and of the hose into the drain can.
	., 4.	Open the high valve on the manifold assembly to bleed the pressure out of the line which connects to the compressor's discharge port. Then close after the pressure escapes completely.
	_5. •	Crack open (counter lockwise) slowly (little by little) the low valve on the manifold gage assembly until all the pressur has escaped and the low pressure gage reads "O." NOTE: THE REASON TO DO THIS IS THAT THE HIGH SIDE CONTAINS THE RECEIVER WHICH HOLDS THE FREON, AND SOME, IF NOT MOST, OF THE OIL. TH REST OF THE OIL IS EITHER IN THE SYSTEM LINES OR IN THE COMPRESSOR. SO REMEMBER, THE SLOWER THE PRESSURE COMES OUT, THE LESS OR NO OIL THAT WILL COME OUT OF THE SYSTEM. THEN YOU WINT HAVE TO SERVICE THE COMPRESSOR OR SYSTEM WITH OIL. HAVE THE INSTRUCTOR CHECK THIS STEP WHILE YOU DO IT.
		INSTRUCTOR'S INITIALS
		FVACUATE THE SYSTEM
Serv	Refo icing	ore beginning to evacuate the system, view film Evacuating and
VACI	JUM TE	EST PROCEDURES
	The	vacuum test will be performed three times.
	<del></del>	Vacrum Test #1 (Do steps 1, 2, 3, 4, 5, 6, 6a, 7, 8, 9).
<del></del>	<del></del>	Vacuum Test #2 (Do steps 4, 5, 6, 6a, 7, 8, 9).
	-	Vacuum Test #3 (Do steps 4, 5, 6, 6a, 7, 8, 9).
	_1.	Obtain the vacuum pump location from the lab instructor.
	_2.	Using a grease pencil, trace on the diagram to show how the manifold gage lines should be connected to the system

	components for reading system vacuum pressure. When complete, have the lab instructor check your work.
	INSTRUCTOR'S INITIALS (TEST #1)
3.	Connect the manifold assembly using the lines going to the system components as you have shown them on your diagram.
	INSTRUCTOR'S INITIALS (TEST #1)
÷ ;	INSTRUCTOR'S INITIALS (TEST #2).
	INSTRUCTOR'S INITIALS (TEST #3)
4.	Ensure that the discharge valve is back seated and suction valve is in the GAGE" position. (3 turns in)
	INSTRUCTOR'S INITIALS
5.	Plug in the vacuum pump to a 110/115V AC wall outlet. NOTE: VACUUM PUMP WILL OPERATE AS SOON AS THE CORD IS CONNECTED TO THE WALL OUTLET.
6.	Open the low valve on the manifold assembly. NOTE: REMEMBER TO OPEN IT SLOWLY SO THAT YOU WILL NOT THROW ANY OIL OUT OF THE SYSTEM. THE PRESSURE IS ESCAPING AND GOING THROUGH THE VACUUM PUMP AND INTO THE DRAIN CAN.
•	. INSTRUCTOR'S INITIALS .
6a.	When you have obtained a vacuum of 28" Hg, crack open the high valve so that all the pressure can escape completely. This lets the pressure out of the manifold gage. (LOW GAGE GREEN SCALE is vacuum).
7.4	Operate the pump five minutes more after obtaining a reading 28" Hg (vacuum is the low gage Green Scale).
	INSTRUCTOR'S INITIALS
8.	Close the low valve on the manifold assembly and unplug the vacuum pump. This will stop the air from entering the system when you disconnect the vacuum line.
·—9.	Disconnect the service line from the vacuum pump. Set aside the pump on a bench so that it will be out of your way.
THE	R: AFTER THE FIRST VACUUM TEST, PERFORM THE PURGING PROCEDURES, N PERFORM THE SECOND VACUUM TEST AND PURGE THE SYSTEM AGAIN.  ER THE SECOND PURGE, PERFORM THE THIRD VACUUM TEST THEN

# PURGING THE SYSTEM

٠		سل	Obtain the location of the R-12 refrigerant from the instructor
L	. •	_2.	Place the refrigerant (R-12) container on the trainer.
,		THE THIS	: PURGING IS TO REMOVE ANY CONTAMINANTS THAT MIGHT BE IN SYSTEM (SUCH AS MOISTURE, DUST, DIRT, ETC). EVEN THOUGH IS WHAT THE DRIER STRAINER IS USED FOR, IT CAN SAVE THE VAL AND REPLACEMENT OF THE DRIER AT SUCH AN EARLY TIME.
\		_3.	Using a grease pencil, trace on the diagram to show how the manifold assembly lines should be connected to the system components for purging.
			INSTRUCTOR'S INITIALS
	<u> </u>	_4 .	Connect the lines to the trainer components as you have drawn them on the diagram.
•	•		INSTRUCTOR'S INITIALS
		SAFE	TY: PUT ON GOGGLES FOR STEP NOs 5 and 6.
<b>}</b>		_5_	Open the refrigerant service valve on the container. NOTE: THIS ALLOWS GASEOUS R-12 REFRIGERANT TO YOUR MANIFOLD ASSEMBLY.
		<b>.</b> 6.	Purge the service hose by loosening slightly the connection to the manifold assembly. This will allow the air to be pushed out and the freon to take its place. Then tighten the connection when you have satisfactorily purged the hose. If you do not purge the hoses correctly the vacuum and purging will have to be done again.
•			ION: FREON IS COLD, SO PLACE A CLOTH AROUND THE CONNECTION ROTECT YOURSELF.
	,	7.	Plug in the trainer power to a 110/115V AC wall outlet. Trainer power light should come "ON."
	especially design and control	_8. ·	Open the high valve on the manifold assemb y. Both gages should indicate the same amount of pressure. NOTE: IMMEDIATELY DO STEP 8 and PAY CLOSE ATTENTION TO STEP Nos 9, 10, and 11.
		9.	Place the compressor switch to the "ON" position.
	1	10.	Operate the system for thirty seconds. Then close the high valve on the manifold assembly.
		11;	Turn the compressor switch "OFF" and unplug the trainer.
	1	.2.	Close the service valve on the freon container.
			•

13.	Put on your safety goggles and crack-open the line at connection to the freon container and let the pressure escape slowly. NOTE: IF THE GAGES ON THE MANIFOLD ASSEMBLY DECREASE IN PRESSURE ON THE BLACK SCALE, THIS MEANS THE HIGH AND LOW VALVES ARE NOT CLOSED ALL THE WAY ON THE MANIFOLD ASSEMBLY.
	ION: FREON IS COLD, SO PLACE A CLOTH AROUND THE CONNECTION PROTECT YOURSELF.
14.	Slowly disconnect the service line at connection to the freon container the rest of the way, making sure that the pressure has escaped.
15.	Cap open connection ca freon container and set it aside.
—— <del>1</del> 16.	PERFORM VACUUM TEST AFTER THE FIRST AND SECOND PURGE.  THE THIRD VACUUM, PERFORM THE SERVICING PROCEDURES.
	SERVICING
1.	Place refrigerant (R-12) container on trainer.
2.	Using a grease pencil, trace on diagram to show how the manifold gage lines should be connected to the system components for servicing.
	INSTRUCTOR'S INITIALS
3.	Connect the lines on the trainer as you have drawn them on the diagram.
	INSTRUCTOR'S INITIALS
	SAFETY: PUT ON GOGGLES FOR STEP 4.
4.	Open the service valve on the freon container. Leave the container upright so that you service the system with gas.  Purge the service hose.
5.	Plug in the trainer to a 110/115V AC wall outlet.
6.	Open the low valve on the manifold gage assembly. Both gages should indicate pressure.
<del></del>	Place the trainer switch to the "ON" position and operate the system until the discharge pressure gage indicates about 100 psig.
8.	Now, carefully watch sight glass on trainer. When the sight glass is HALF (1/2) FULL OF FREON liquid, notify the lab instructor. When the sight glass is 3/4 full, close the service valve on the freon container and this will possibly allow the gas or liquid freon in the lines to top off the sight glass and the system.
	INSTRUCTOR'S INITIALS $50^{5}$

9.		connected as is and operate for se the following readings:	r ten more
	SIGHT GLASS	SUCTION GAGE	DISCHARGE GAGE
10.	Now compare the ab	ove readings with table 1.	, UAU2
H.	Is the unit operat	ing correctly?	, h.,
	UNSAT.	SAT.	
· <del></del>	instructor's initi	ALS	
12.	Close the low valv	e on the manifold assembly.	<b>,</b>
<u>– 1</u> 13.	the compressor. N	on and discharge service valve OTE: REMEMBER, DO NOT <u>OVERTOR</u> TOR TO CHECK THE POSITION OF T	QUE.
	INSTRUCTOR'S INITI	ALS	
	SAFETY: PUT ON GO	GGLES FOR STEP NOS 14 - 18.	
14.		vice hose from the freon conta OTH AROUND THE CONNECTION.	iner.
15.	Place the service	hose in the drain can.	, 1
16.	all the pressure, c	w valve on the manifold assemb an escape. NOTE: LEAVE THE V FREON THAT WILL BE IN THE LINE	ALVE OPEN
17.	Repeat step 16 for	the high side.	
18.		h and low side hoses from the Torque caps to 90 inch lbs.	
19.	Connect the hoses a low valves on the s	as on figure 2 and close the h manifold assembly.	igh and
20.	Place the manifold dabinets properly.	assembly and drain can in the	trainer
21.	Turn the suction as TURN IN. (TO THE	nd discharge service valves a 'GAGE' POSITION)	HALF (1/2)
NOTE BACK	THIS WILL KEEP THE	HE SERVICE VALVES FROM FREEZIN	G IN THE
	INSTRUCTOR'S INITIA	ALS	
22.	Cap the service val	lves.	
23.	Turn off the compre	essor switch.	
NOTE	: NOW YOU ARE READY	TO PERFORM THE LEAK TEST. $506^{11}$	•




Figure 2. LEAK TEST

Before beginning the lask test, view film Thermostatic Expansion Valve.
USING THE SOAP SOLUTION

- 1. Obtain the location of the "Leak Tec" solution from the instructor.
- 2. Shake the bottle until you have enough bubbles to apply to each tubing connection which might have a possible leak.

  Apply the solution and look for leaks. Remove the Leak Tec solution (using a cloth) from the area in which you applied it after verifying that there are no leaks.
- 3. Troubleshot and found the following leaks:



	LEAKING CONNECTIONS AT THIS TIME, because you will verify the system using the H-10 leak detector.
	INSTRUCTOR'S INITIALS
<u>~</u> 5.	Place the "Leah Tec" solution back where you found it.
6.	Now perform another leak test using the H-10 leak detector.
	LEAK TEST USING THE H-10 LEAK DETECTOR
1.	Obtain the leak detector from your lab instructor.
2.	Plug in the power cord of the leak detector into the trainer outlet which is located next to the temperature control box.
3.	The leak detector will start to warm up immediately after the power cord is plugged into a 110/115V AC outlet.
4.	Check for sufficient airflow by pointing the probe tip towar the floor and observing the airflow ball (in the probe). The height the ball rises is not important as long as it rises. If the airflow ball DOES NOT RISE, tap the probe lightly to make sure the ball isn't sticking. If the ball does not rise at all, inform your instructor.
5.	Place the "Sensitivity" switch in either the $\underline{\text{HIGH}}$ or $\underline{\text{LOW}}$ positions.
	: THE LOW" RANGE POSITION IS USED TO DETECT <u>LARGE LEAKS</u> IS USED WHEN THE SENSING ELEMENTS OF THE TESTER ARE NEW. "HIGH" RANGE POSITION IS USED TO DETECT <u>SMALL LEAKS</u> .
NOT THE	TION: IN A HIGHLY CONTAMINATED AREA, THE FLASH RATE WILL BE STABLE AND IT WILL BE ALMOST IMPOSSIBLE TO "BALANCE" DETECTOR. UNDER THESE CONDITIONS, LEAK CHECKING WOULD BE POSSIBLE.
6.	Adjust the flash rate of the neon lamp in the probe by rotating (clockwise-or-counterclockwise) the "balance" control so that the neon lamp just ceases to flash. If adjusted properly, the light WILL FLASH and continue to flash when the probe is held at the "Reference Leak." When the probe is removed from the "Reference Leak," the flashing rate will slow down and STOP.
	INSTRUCTOR'S INITIALS
7.	The "Reference Leak" may be used as often as necessary to assure proper operation of the leak detector, or as a comparing means to assist you in determining the size of the leak. (R-11 is used in the H-10 detector for adjusting the reference leak by setting the flash rate of the probe.)



3/22

8•	tested and move the tip at ONE INCH PER SEGOND (cr less) along the seams or joints suspected of leaking. When the probe encounters a leak, the flashing rate of the meon lamp will increase and will continue to flash at the faster rate as long as the probe is held at the leak.
9.	Troubleshot and found the following leaks:
-	
10.	Have instructor check your work. If there are any leaks, the instructor will advise you what to do.
	INSTRUCTOR'S INITIALS
11.	Unplug the trainer and the tester. Place the tester back where you found it
12	Notify the instructor of your completion.

